

Where Used: Part Number 0203130

Model Name	Diagram
3802A 1968	POWERHEAD GROUP
3802M 1968	POWERHEAD GROUP
3803A 1968	POWERHEAD GROUP
3803M 1968	POWERHEAD GROUP
3806A 1968	POWERHEAD GROUP
3806M 1968	POWERHEAD GROUP
3807A 1968	POWERHEAD GROUP
3807M 1968	POWERHEAD GROUP
3832A 1968	POWERHEAD GROUP
3832M 1968	POWERHEAD GROUP
3833A 1968	POWERHEAD GROUP
3833M 1968	POWERHEAD GROUP
3836A 1968	POWERHEAD GROUP
3836M 1968	POWERHEAD GROUP
3837A 1968	POWERHEAD GROUP
3837M 1968	POWERHEAD GROUP
4006E 1970	POWERHEAD GROUP
4007E 1970	POWERHEAD GROUP
4036E 1970	POWERHEAD GROUP
4037E 1970	POWERHEAD GROUP
4106D 1971	CYLINDER & CRANKCASE
4107D 1971	CYLINDER & CRANKCASE
4136D 1971	CYLINDER & CRANKCASE
4137D 1971	CYLINDER & CRANKCASE
4206S 1972	CYLINDER & CRANKCASE
4236S 1972	CYLINDER & CRANKCASE
4306C 1973	CYLINDER & CRANKCASE
4336C 1973	CYLINDER & CRANKCASE
4406R 1974	CYLINDER AND CRANKCASE
4436R 1974	CYLINDER AND CRANKCASE
4506A 1975	CYLINDER & CRANKCASE
4536A 1975	CYLINDER & CRANKCASE
4606M 1976	CYLINDER & CRANKCASE

4636M 1976	CYLINDER & CRANKCASE
4706B 1977	CYLINDER & CRANKCASE
4736B 1977	CYLINDER & CRANKCASE
4806E 1978	CYLINDER AND CRANKCASE
4836E 1978	CYLINDER AND CRANKCASE
4837E 1978	CYLINDER AND CRANKCASE
4902B 1969	POWERHEAD GROUP
4904D 1979	CYLINDER AND CRANKCASE
4906B 1969	POWERHEAD GROUP
4932D 1979	CYLINDER AND CRANKCASE
4933D 1979	CYLINDER AND CRANKCASE
4936B 1969	POWERHEAD GROUP
4R69B 1969	POWERHEAD GROUP
4R70E 1970	POWERHEAD GROUP
4R71D 1971	CYLINDER & CRANKCASE
4R72S 1972	CYLINDER & CRANKCASE
4R73C 1973	CYLINDER AND CRANKCASE
4R74R 1974	CYLINDER & CRANKCASE
4R75A 1975	CYLINDER & CRANKCASE
4R76M 1976	CYLINDER & CRANKCASE
4R77B 1977	CYLINDER & CRANKCASE
4R78E 1978	CYLINDER AND CRANKCASE
4R79D 1979	CYLINDER AND CRANKCASE
4RL70E 1970	POWERHEAD GROUP
4RL71D 1971	CYLINDER & CRANKCASE
4RL78E 1978	CYLINDER AND CRANKCASE
4RL79D 1979	CYLINDER AND CRANKCASE
4W69B 1969	POWERHEAD GROUP
4W70E 1970	POWERHEAD GROUP
4W71D 1971	CYLINDER & CRANKCASE
4W72S 1972	CYLINDER & CRANKCASE
4W73C 1973	CYLINDER AND CRANKCASE
4W74R 1974	CYLINDER & CRANKCASE
4W75A 1975	CYLINDER & CRANKCASE
4W76M 1976	CYLINDER & CRANKCASE

4W77B 1977	CYLINDER & CRANKCASE
4W78E 1978	CYLINDER AND CRANKCASE
4W79D 1979	CYLINDER AND CRANKCASE
4WF69B 1969	POWERHEAD GROUP
4WL70E 1970	POWERHEAD GROUP
4WL71D 1971	CYLINDER & CRANKCASE
E4RLCSS 1980	CYLINDER & CRANKCASE
E4WCSS 1980	CYLINDER & CRANKCASE
E5RCSS 1980	CYLINDER & CRANKCASE-4.5 & INTAKE MANIFOLD
E5RHCSS 1980	CYLINDER & CRANKCASE-4.5 & INTAKE MANIFOLD
E5RHLCSS 1980	CYLINDER & CRANKCASE-4.5 & INTAKE MANIFOLD
E5RLCSS 1980	CYLINDER & CRANKCASE-4.5 & INTAKE MANIFOLD
E8RCSS 1980	CYLINDER & CRANKCASE-4.5 & INTAKE MANIFOLD
E8RLCSS 1980	CYLINDER & CRANKCASE-4.5 & INTAKE MANIFOLD
J4RLCSS 1980	CYLINDER & CRANKCASE
J4WCSS 1980	CYLINDER & CRANKCASE
J5RCSS 1980	CYLINDER & CRANKCASE-4.5 & INTAKE MANIFOLD
J5RHCSS 1980	CYLINDER & CRANKCASE-4.5 & INTAKE MANIFOLD
J5RHLCSS 1980	CYLINDER & CRANKCASE-4.5 & INTAKE MANIFOLD
J5RLCSS 1980	CYLINDER & CRANKCASE-4.5 & INTAKE MANIFOLD
J8RCSS 1980	CYLINDER & CRANKCASE-4.5 & INTAKE MANIFOLD
J8RLCSS 1980	CYLINDER & CRANKCASE-4.5 & INTAKE MANIFOLD
JH-23A 1968	POWERHEAD GROUP
JH-23M 1968	POWERHEAD GROUP
JHF-23A 1968	POWERHEAD GROUP
JHF-23M 1968	POWERHEAD GROUP
JHFL-23A 1968	POWERHEAD GROUP
JHFL-23M 1968	POWERHEAD GROUP
JHL-23A 1968	POWERHEAD GROUP
JHL-23M 1968	POWERHEAD GROUP
JW-23A 1968	POWERHEAD GROUP
JW-23M 1968	POWERHEAD GROUP
JWF-23A 1968	POWERHEAD GROUP
JWF-23M 1968	POWERHEAD GROUP
JWFL-23A 1968	POWERHEAD GROUP

JWFL-23M 1968	POWERHEAD GROUP
JWL-23A 1968	POWERHEAD GROUP
JWL-23M 1968	POWERHEAD GROUP