

## Where Used: Part Number 0584381

| Model Name                                  | Diagram                                                   |
|---------------------------------------------|-----------------------------------------------------------|
| 25/35HP (2 Stroke - 3 Cylinder)             | TILLER ELECTRIC START KIT - 25, 35 (3-CYLINDER)           |
| 25/35HP (2 Stroke - 3 Cylinder)             | REMOTE ELECTRIC START KIT - 25, 35 (3-CYLINDER ROPE)      |
| 40/50HP (2 Stroke)                          | ELECTRIC START KIT (1993-Current models w/CD II Ignition) |
| 40HP Rope 45-55HP Comm (2 Stroke) 1992-2001 | TILLER ELECTRIC START KIT - 40, 55                        |
| 65HP (2 Stroke - 3 CYLINDER)                | TILLER ELECTRIC START KIT - 65 MODELS                     |
| BE20SEECB 1998                              | BATTERY CABLE                                             |
| BE20SEECB 1998                              | ELECTRIC STARTER & SOLENOID                               |
| BE20SEEDA 1996                              | BATTERY CABLE                                             |
| BE20SEEDA 1996                              | ELECTRIC STARTER & SOLENOID                               |
| BE20SEEUM 1997                              | BATTERY CABLE                                             |
| BE20SEEUM 1997                              | ELECTRIC STARTER & SOLENOID                               |
| BE20SELECB 1998                             | BATTERY CABLE                                             |
| BE20SELECB 1998                             | ELECTRIC STARTER & SOLENOID                               |
| BE20SELEDA 1996                             | BATTERY CABLE                                             |
| BE20SELEDA 1996                             | ELECTRIC STARTER & SOLENOID                               |
| BE20SELEUM 1997                             | BATTERY CABLE                                             |
| BE20SELEUM 1997                             | ELECTRIC STARTER & SOLENOID                               |
| BE25ARECA 1998                              | IGNITION SYSTEM -- REMOTE                                 |
| BE25ARECA 1998                              | IGNITION SYSTEM -- TE                                     |
| BE25ARECA 1998                              | IGNITION SYSTEM -- TNT                                    |
| BE25AREDC 1996                              | IGNITION SYSTEM - TEL                                     |
| BE25AREDC 1996                              | IGNITION SYSTEM - TNT                                     |
| BE25AREDC 1996                              | IGNITION SYSTEM - REMOTE                                  |
| BE25AREUR 1997                              | IGNITION SYSTEM - TE                                      |
| BE25AREUR 1997                              | IGNITION SYSTEM - TNT                                     |
| BE25AREUR 1997                              | IGNITION SYSTEM - REMOTE                                  |
| BE25ARLECA 1998                             | IGNITION SYSTEM -- REMOTE                                 |
| BE25ARLECA 1998                             | IGNITION SYSTEM -- TE                                     |
| BE25ARLECA 1998                             | IGNITION SYSTEM -- TNT                                    |
| BE25ARLEDC 1996                             | IGNITION SYSTEM - TEL                                     |
| BE25ARLEDC 1996                             | IGNITION SYSTEM - TNT                                     |
| BE25ARLEDC 1996                             | IGNITION SYSTEM - REMOTE                                  |

|                 |                             |
|-----------------|-----------------------------|
| BE25ARLEUR 1997 | IGNITION SYSTEM - TE        |
| BE25ARLEUR 1997 | IGNITION SYSTEM - TNT       |
| BE25ARLEUR 1997 | IGNITION SYSTEM - REMOTE    |
| BE25EECE 1998   | BATTERY CABLE               |
| BE25EECE 1998   | ELECTRIC STARTER & SOLENOID |
| BE25EEDM 1996   | BATTERY CABLE               |
| BE25EEDM 1996   | ELECTRIC STARTER & SOLENOID |
| BE25EEUB 1997   | BATTERY CABLE               |
| BE25EEUB 1997   | ELECTRIC STARTER & SOLENOID |
| BE25ELECE 1998  | BATTERY CABLE               |
| BE25ELECE 1998  | ELECTRIC STARTER & SOLENOID |
| BE25ELEDM 1996  | BATTERY CABLE               |
| BE25ELEDM 1996  | ELECTRIC STARTER & SOLENOID |
| BE25ELEUB 1997  | BATTERY CABLE               |
| BE25ELEUB 1997  | ELECTRIC STARTER & SOLENOID |
| BE25EREDC 1996  | BATTERY CABLE               |
| BE25EREDC 1996  | ELECTRIC STARTER & SOLENOID |
| BE25ERLEDC 1996 | BATTERY CABLE               |
| BE25ERLEDC 1996 | ELECTRIC STARTER & SOLENOID |
| BE25KECA 1998   | IGNITION SYSTEM -- REMOTE   |
| BE25KECA 1998   | IGNITION SYSTEM -- TE       |
| BE25KECA 1998   | IGNITION SYSTEM -- TNT      |
| BE25KEDC 1996   | IGNITION SYSTEM - TEL       |
| BE25KEDC 1996   | IGNITION SYSTEM - TNT       |
| BE25KEDC 1996   | IGNITION SYSTEM - REMOTE    |
| BE25KEUR 1997   | IGNITION SYSTEM - TE        |
| BE25KEUR 1997   | IGNITION SYSTEM - TNT       |
| BE25KEUR 1997   | IGNITION SYSTEM - REMOTE    |
| BE25KLECA 1998  | IGNITION SYSTEM -- REMOTE   |
| BE25KLECA 1998  | IGNITION SYSTEM -- TE       |
| BE25KLECA 1998  | IGNITION SYSTEM -- TNT      |
| BE25KLEDC 1996  | IGNITION SYSTEM - TEL       |
| BE25KLEDC 1996  | IGNITION SYSTEM - TNT       |
| BE25KLEDC 1996  | IGNITION SYSTEM - REMOTE    |
| BE25KLEUR 1997  | IGNITION SYSTEM - TE        |

|                |                             |
|----------------|-----------------------------|
| BE25KLEUR 1997 | IGNITION SYSTEM - TNT       |
| BE25KLEUR 1997 | IGNITION SYSTEM - REMOTE    |
| BE25QLECA 1998 | IGNITION SYSTEM -- REMOTE   |
| BE25QLECA 1998 | IGNITION SYSTEM -- TE       |
| BE25QLECA 1998 | IGNITION SYSTEM -- TNT      |
| BE25QLEDC 1996 | IGNITION SYSTEM - TEL       |
| BE25QLEDC 1996 | IGNITION SYSTEM - TNT       |
| BE25QLEDC 1996 | IGNITION SYSTEM - REMOTE    |
| BE25QLEUR 1997 | IGNITION SYSTEM - TE        |
| BE25QLEUR 1997 | IGNITION SYSTEM - TNT       |
| BE25QLEUR 1997 | IGNITION SYSTEM - REMOTE    |
| BE30EECS 1998  | BATTERY CABLE               |
| BE30EECS 1998  | ELECTRIC STARTER & SOLENOID |
| BE30EEDE 1996  | BATTERY CABLE               |
| BE30EEDE 1996  | ELECTRIC STARTER & SOLENOID |
| BE30EEUD 1997  | BATTERY CABLE               |
| BE30EEUD 1997  | ELECTRIC STARTER & SOLENOID |
| BE30ELECS 1998 | BATTERY CABLE               |
| BE30ELECS 1998 | ELECTRIC STARTER & SOLENOID |
| BE30ELEDE 1996 | BATTERY CABLE               |
| BE30ELEDE 1996 | ELECTRIC STARTER & SOLENOID |
| BE30ELEUD 1997 | BATTERY CABLE               |
| BE30ELEUD 1997 | ELECTRIC STARTER & SOLENOID |
| BE35ARECR 1998 | IGNITION SYSTEM -- REMOTE   |
| BE35ARECR 1998 | IGNITION SYSTEM -- TE       |
| BE35ARECR 1998 | IGNITION SYSTEM -- TNT      |
| BE35AREDS 1996 | IGNITION SYSTEM - TEL       |
| BE35AREDS 1996 | IGNITION SYSTEM - TNT       |
| BE35AREDS 1996 | IGNITION SYSTEM - REMOTE    |
| BE35AREEA 1999 | IGNITION SYSTEM -- E, EL    |
| BE35AREEA 1999 | IGNITION SYSTEM -- PL       |
| BE35AREEA 1999 | IGNITION SYSTEM -- TEL      |
| BE35AREUC 1997 | IGNITION SYSTEM - TE        |
| BE35AREUC 1997 | IGNITION SYSTEM - TNT       |
| BE35AREUC 1997 | IGNITION SYSTEM - REMOTE    |

|                                                                 |                                         |
|-----------------------------------------------------------------|-----------------------------------------|
| BE35ARLECR 1998                                                 | IGNITION SYSTEM -- REMOTE               |
| BE35ARLECR 1998                                                 | IGNITION SYSTEM -- TE                   |
| BE35ARLECR 1998                                                 | IGNITION SYSTEM -- TNT                  |
| BE35ARLEDS 1996                                                 | IGNITION SYSTEM - TEL                   |
| BE35ARLEDS 1996                                                 | IGNITION SYSTEM - TNT                   |
| BE35ARLEDS 1996                                                 | IGNITION SYSTEM - REMOTE                |
| BE35ARLEUC 1997                                                 | IGNITION SYSTEM - TE                    |
| BE35ARLEUC 1997                                                 | IGNITION SYSTEM - TNT                   |
| BE35ARLEUC 1997                                                 | IGNITION SYSTEM - REMOTE                |
| BE35ARSIB rope start, tiller, 15 in shaft, wht, n/a usa 2001    | IGNITION SYSTEM - K - E - EL - EV - EVL |
| BE35ARSIB rope start, tiller, 15 in shaft, wht, n/a usa 2001    | IGNITION SYSTEM - PL - VL               |
| BE35ARSIB rope start, tiller, 15 in shaft, wht, n/a usa 2001    | IGNITION SYSTEM - TEL - TVL             |
| BE35ARSSM 3 Cyl, Rope Start, Tiller, 15 IN. shaft, N/A USA 2000 | IGNITION SYSTEM - K, E, EL              |
| BE35ARSSM 3 Cyl, Rope Start, Tiller, 15 IN. shaft, N/A USA 2000 | IGNITION SYSTEM - PL                    |
| BE35ARSSM 3 Cyl, Rope Start, Tiller, 15 IN. shaft, N/A USA 2000 | IGNITION SYSTEM - TEL                   |
| BE35KECA 1998                                                   | IGNITION SYSTEM -- REMOTE               |
| BE35KECA 1998                                                   | IGNITION SYSTEM -- TE                   |
| BE35KECA 1998                                                   | IGNITION SYSTEM -- TNT                  |
| BE35KEDC 1996                                                   | IGNITION SYSTEM - TEL                   |
| BE35KEDC 1996                                                   | IGNITION SYSTEM - TNT                   |
| BE35KEDC 1996                                                   | IGNITION SYSTEM - REMOTE                |
| BE35KEEM 1999                                                   | IGNITION SYSTEM -- E, EL                |
| BE35KEEM 1999                                                   | IGNITION SYSTEM -- PL                   |
| BE35KEEM 1999                                                   | IGNITION SYSTEM -- TEL                  |
| BE35KEUR 1997                                                   | IGNITION SYSTEM - TE                    |
| BE35KEUR 1997                                                   | IGNITION SYSTEM - TNT                   |
| BE35KEUR 1997                                                   | IGNITION SYSTEM - REMOTE                |
| BE35KLECA 1998                                                  | IGNITION SYSTEM -- REMOTE               |
| BE35KLECA 1998                                                  | IGNITION SYSTEM -- TE                   |
| BE35KLECA 1998                                                  | IGNITION SYSTEM -- TNT                  |
| BE35KLEDC 1996                                                  | IGNITION SYSTEM - TEL                   |
| BE35KLEDC 1996                                                  | IGNITION SYSTEM - TNT                   |
| BE35KLEDC 1996                                                  | IGNITION SYSTEM - REMOTE                |
| BE35KLEUR 1997                                                  | IGNITION SYSTEM - TE                    |

|                                                                |                                                            |
|----------------------------------------------------------------|------------------------------------------------------------|
| BE35KLEUR 1997                                                 | IGNITION SYSTEM - TNT                                      |
| BE35KLEUR 1997                                                 | IGNITION SYSTEM - REMOTE                                   |
| BE35KSIE elec start, tiller, 15 in shaft, wht, n/a usa 2001    | IGNITION SYSTEM - K - E - EL - EV - EVL                    |
| BE35KSIE elec start, tiller, 15 in shaft, wht, n/a usa 2001    | IGNITION SYSTEM - PL - VL                                  |
| BE35KSIE elec start, tiller, 15 in shaft, wht, n/a usa 2001    | IGNITION SYSTEM - TEL - TVL                                |
| BE35KSSB 3 Cyl, Rope Start, Tiller, 15 IN. shaft, N/A USA 2000 | IGNITION SYSTEM - K, E, EL                                 |
| BE35KSSB 3 Cyl, Rope Start, Tiller, 15 IN. shaft, N/A USA 2000 | IGNITION SYSTEM - PL                                       |
| BE35KSSB 3 Cyl, Rope Start, Tiller, 15 IN. shaft, N/A USA 2000 | IGNITION SYSTEM - TEL                                      |
| BE35QLECA 1998                                                 | IGNITION SYSTEM -- REMOTE                                  |
| BE35QLECA 1998                                                 | IGNITION SYSTEM -- TE                                      |
| BE35QLECA 1998                                                 | IGNITION SYSTEM -- TNT                                     |
| BE35QLEDC 1996                                                 | IGNITION SYSTEM - TEL                                      |
| BE35QLEDC 1996                                                 | IGNITION SYSTEM - TNT                                      |
| BE35QLEDC 1996                                                 | IGNITION SYSTEM - REMOTE                                   |
| BE35QLEUR 1997                                                 | IGNITION SYSTEM - TE                                       |
| BE35QLEUR 1997                                                 | IGNITION SYSTEM - TNT                                      |
| BE35QLEUR 1997                                                 | IGNITION SYSTEM - REMOTE                                   |
| BE40EECR 1998                                                  | ELECTRIC STARTER & SOLENOID                                |
| BE40EECR 1998                                                  | IGNITION SYSTEM -- 40-50 ELECTRIC START                    |
| BE40EEDS 1996                                                  | ELECTRIC STARTER & SOLENOID                                |
| BE40EEDS 1996                                                  | IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS |
| BE40EEDS 1996                                                  | IGNITION SYSTEM - ELECTRIC START 40TE MODELS               |
| BE40EEUC 1997                                                  | ELECTRIC STARTER & SOLENOID                                |
| BE40EEUC 1997                                                  | IGNITION SYSTEM - 40-50 ELECTRIC START                     |
| BE40ELECR 1998                                                 | ELECTRIC STARTER & SOLENOID                                |
| BE40ELECR 1998                                                 | IGNITION SYSTEM -- 40-50 ELECTRIC START                    |
| BE40ELEDs 1996                                                 | ELECTRIC STARTER & SOLENOID                                |
| BE40ELEDs 1996                                                 | IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS |
| BE40ELEDs 1996                                                 | IGNITION SYSTEM - ELECTRIC START 40TE MODELS               |
| BE40ELEUC 1997                                                 | ELECTRIC STARTER & SOLENOID                                |
| BE40ELEUC 1997                                                 | IGNITION SYSTEM - 40-50 ELECTRIC START                     |
| BE40TLECR 1998                                                 | ELECTRIC STARTER & SOLENOID                                |
| BE40TLECR 1998                                                 | IGNITION SYSTEM -- 40-50 ELECTRIC START                    |
| BE40TLEDs 1996                                                 | ELECTRIC STARTER & SOLENOID                                |

|                 |                                                            |
|-----------------|------------------------------------------------------------|
| BE40TLEDS 1996  | IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS |
| BE40TLEDS 1996  | IGNITION SYSTEM - ELECTRIC START 40TE MODELS               |
| BE40TLEUC 1997  | ELECTRIC STARTER & SOLENOID                                |
| BE40TLEUC 1997  | IGNITION SYSTEM - 40-50 ELECTRIC START                     |
| BE50BEEDS 1996  | ELECTRIC STARTER & SOLENOID                                |
| BE50BEEDS 1996  | IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS |
| BE50BEEDS 1996  | IGNITION SYSTEM - ELECTRIC START 40TE MODELS               |
| BE50BELEDS 1996 | ELECTRIC STARTER & SOLENOID                                |
| BE50BELEDS 1996 | IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS |
| BE50BELEDS 1996 | IGNITION SYSTEM - ELECTRIC START 40TE MODELS               |
| BE50DTLEDC 1996 | BATTERY CABLE                                              |
| BE50DTLEDC 1996 | ELECTRIC STARTER                                           |
| BE50DTLEUR 1997 | BATTERY CABLE                                              |
| BE50DTLEUR 1997 | ELECTRIC STARTER                                           |
| BE50ESECC 1998  | ELECTRIC STARTER & SOLENOID                                |
| BE50ESECC 1998  | IGNITION SYSTEM -- 40-50 ELECTRIC START                    |
| BE50RLECR 1998  | ELECTRIC STARTER & SOLENOID                                |
| BE50RLECR 1998  | IGNITION SYSTEM -- 40-50 ELECTRIC START                    |
| BE50RLEUC 1997  | ELECTRIC STARTER & SOLENOID                                |
| BE50RLEUC 1997  | IGNITION SYSTEM - 40-50 ELECTRIC START                     |
| BE50TLECR 1998  | ELECTRIC STARTER & SOLENOID                                |
| BE50TLECR 1998  | IGNITION SYSTEM -- 40-50 ELECTRIC START                    |
| BE50TLEDS 1996  | ELECTRIC STARTER & SOLENOID                                |
| BE50TLEDS 1996  | IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS |
| BE50TLEDS 1996  | IGNITION SYSTEM - ELECTRIC START 40TE MODELS               |
| BE50TLEUC 1997  | ELECTRIC STARTER & SOLENOID                                |
| BE50TLEUC 1997  | IGNITION SYSTEM - 40-50 ELECTRIC START                     |
| BE50TSLECC 1998 | ELECTRIC STARTER & SOLENOID                                |
| BE50TSLECC 1998 | IGNITION SYSTEM -- 40-50 ELECTRIC START                    |
| BE50TSLEUS 1997 | ELECTRIC STARTER & SOLENOID                                |
| BE50TSLEUS 1997 | IGNITION SYSTEM - 40-50 ELECTRIC START                     |
| BE60ELEDR 1996  | BATTERY CABLE                                              |
| BE60ELEDR 1996  | ELECTRIC STARTER                                           |

|                 |                             |
|-----------------|-----------------------------|
| BE60ELEUA 1997  | BATTERY CABLE               |
| BE60ELEUA 1997  | ELECTRIC STARTER            |
| BE60TLECM 1998  | BATTERY CABLE               |
| BE60TLECM 1998  | ELECTRIC STARTER            |
| BE60TLEDR 1996  | BATTERY CABLE               |
| BE60TLEDR 1996  | ELECTRIC STARTER            |
| BE60TLEUA 1997  | BATTERY CABLE               |
| BE60TLEUA 1997  | ELECTRIC STARTER            |
| BE70ELECB 1998  | BATTERY CABLE               |
| BE70ELECB 1998  | ELECTRIC STARTER            |
| BE70ELED A 1996 | BATTERY CABLE               |
| BE70ELED A 1996 | ELECTRIC STARTER            |
| BE70ELEUM 1997  | BATTERY CABLE               |
| BE70ELEUM 1997  | ELECTRIC STARTER            |
| BE70TLECB 1998  | BATTERY CABLE               |
| BE70TLECB 1998  | ELECTRIC STARTER            |
| BE70TLEDA 1996  | BATTERY CABLE               |
| BE70TLEDA 1996  | ELECTRIC STARTER            |
| BE70TLEUM 1997  | BATTERY CABLE               |
| BE70TLEUM 1997  | ELECTRIC STARTER            |
| BJ20SEECB 1998  | BATTERY CABLE               |
| BJ20SEECB 1998  | ELECTRIC STARTER & SOLENOID |
| BJ20SEEDA 1996  | BATTERY CABLE               |
| BJ20SEEDA 1996  | ELECTRIC STARTER & SOLENOID |
| BJ20SEEUM 1997  | BATTERY CABLE               |
| BJ20SEEUM 1997  | ELECTRIC STARTER & SOLENOID |
| BJ20SELECB 1998 | BATTERY CABLE               |
| BJ20SELECB 1998 | ELECTRIC STARTER & SOLENOID |
| BJ20SELEDA 1996 | BATTERY CABLE               |
| BJ20SELEDA 1996 | ELECTRIC STARTER & SOLENOID |
| BJ20SELEUM 1997 | BATTERY CABLE               |
| BJ20SELEUM 1997 | ELECTRIC STARTER & SOLENOID |
| BJ25ARECA 1998  | IGNITION SYSTEM -- REMOTE   |
| BJ25ARECA 1998  | IGNITION SYSTEM -- TE       |
| BJ25ARECA 1998  | IGNITION SYSTEM -- TNT      |

|                 |                             |
|-----------------|-----------------------------|
| BJ25AREDC 1996  | IGNITION SYSTEM - TEL       |
| BJ25AREDC 1996  | IGNITION SYSTEM - TNT       |
| BJ25AREDC 1996  | IGNITION SYSTEM - REMOTE    |
| BJ25AREUR 1997  | IGNITION SYSTEM - TE        |
| BJ25AREUR 1997  | IGNITION SYSTEM - TNT       |
| BJ25AREUR 1997  | IGNITION SYSTEM - REMOTE    |
| BJ25ARLECA 1998 | IGNITION SYSTEM -- REMOTE   |
| BJ25ARLECA 1998 | IGNITION SYSTEM -- TE       |
| BJ25ARLECA 1998 | IGNITION SYSTEM -- TNT      |
| BJ25ARLEDC 1996 | IGNITION SYSTEM - TEL       |
| BJ25ARLEDC 1996 | IGNITION SYSTEM - TNT       |
| BJ25ARLEDC 1996 | IGNITION SYSTEM - REMOTE    |
| BJ25ARLEUR 1997 | IGNITION SYSTEM - TE        |
| BJ25ARLEUR 1997 | IGNITION SYSTEM - TNT       |
| BJ25ARLEUR 1997 | IGNITION SYSTEM - REMOTE    |
| BJ25EECE 1998   | BATTERY CABLE               |
| BJ25EECE 1998   | ELECTRIC STARTER & SOLENOID |
| BJ25EEDM 1996   | BATTERY CABLE               |
| BJ25EEDM 1996   | ELECTRIC STARTER & SOLENOID |
| BJ25EEED 1999   | BATTERY CABLE               |
| BJ25EEED 1999   | ELECTRIC STARTER & SOLENOID |
| BJ25EEEN 1999   | BATTERY CABLE               |
| BJ25EEEN 1999   | ELECTRIC STARTER & SOLENOID |
| BJ25EEUB 1997   | BATTERY CABLE               |
| BJ25EEUB 1997   | ELECTRIC STARTER & SOLENOID |
| BJ25ELECE 1998  | BATTERY CABLE               |
| BJ25ELECE 1998  | ELECTRIC STARTER & SOLENOID |
| BJ25ELEDM 1996  | BATTERY CABLE               |
| BJ25ELEDM 1996  | ELECTRIC STARTER & SOLENOID |
| BJ25ELEED 1999  | BATTERY CABLE               |
| BJ25ELEED 1999  | ELECTRIC STARTER & SOLENOID |
| BJ25ELEEN 1999  | BATTERY CABLE               |
| BJ25ELEEN 1999  | ELECTRIC STARTER & SOLENOID |
| BJ25ELEUB 1997  | BATTERY CABLE               |
| BJ25ELEUB 1997  | ELECTRIC STARTER & SOLENOID |



|                                                              |                             |
|--------------------------------------------------------------|-----------------------------|
| BJ25ELSIC elec start, remote, 20 in shaft, n/a usa 2001      | BATTERY CABLE               |
| BJ25ELSIC elec start, remote, 20 in shaft, n/a usa 2001      | ELECTRIC STARTER & SOLENOID |
| BJ25ELSSS Elec. Start, 20 IN. shaft, N/A USA 2000            | BATTERY CABLE               |
| BJ25ELSSS Elec. Start, 20 IN. shaft, N/A USA 2000            | ELECTRIC STARTER & SOLENOID |
| BJ25EREDC 1996                                               | BATTERY CABLE               |
| BJ25EREDC 1996                                               | ELECTRIC STARTER & SOLENOID |
| BJ25ERLEDC 1996                                              | BATTERY CABLE               |
| BJ25ERLEDC 1996                                              | ELECTRIC STARTER & SOLENOID |
| BJ25ESIC elec start, remote, 15 in shaft, n/a usa 2001       | BATTERY CABLE               |
| BJ25ESIC elec start, remote, 15 in shaft, n/a usa 2001       | ELECTRIC STARTER & SOLENOID |
| BJ25ESSS Elec. Start, 15 IN. shaft, N/A USA 2000             | BATTERY CABLE               |
| BJ25ESSS Elec. Start, 15 IN. shaft, N/A USA 2000             | ELECTRIC STARTER & SOLENOID |
| BJ25EVSIC elec start, remote, 20 in shaft, wht, n/a usa 2001 | BATTERY CABLE               |
| BJ25EVSIC elec start, remote, 20 in shaft, wht, n/a usa 2001 | ELECTRIC STARTER & SOLENOID |
| BJ25EVSIC elec start, remote, 15 in shaft, wht, n/a usa 2001 | BATTERY CABLE               |
| BJ25EVSIC elec start, remote, 15 in shaft, wht, n/a usa 2001 | ELECTRIC STARTER & SOLENOID |
| BJ25KECA 1998                                                | IGNITION SYSTEM -- REMOTE   |
| BJ25KECA 1998                                                | IGNITION SYSTEM -- TE       |
| BJ25KECA 1998                                                | IGNITION SYSTEM -- TNT      |
| BJ25KEDC 1996                                                | IGNITION SYSTEM - TEL       |
| BJ25KEDC 1996                                                | IGNITION SYSTEM - TNT       |
| BJ25KEDC 1996                                                | IGNITION SYSTEM - REMOTE    |
| BJ25KEUR 1997                                                | IGNITION SYSTEM - TE        |
| BJ25KEUR 1997                                                | IGNITION SYSTEM - TNT       |
| BJ25KEUR 1997                                                | IGNITION SYSTEM - REMOTE    |
| BJ25KLECA 1998                                               | IGNITION SYSTEM -- REMOTE   |
| BJ25KLECA 1998                                               | IGNITION SYSTEM -- TE       |
| BJ25KLECA 1998                                               | IGNITION SYSTEM -- TNT      |
| BJ25KLEDC 1996                                               | IGNITION SYSTEM - TEL       |
| BJ25KLEDC 1996                                               | IGNITION SYSTEM - TNT       |
| BJ25KLEDC 1996                                               | IGNITION SYSTEM - REMOTE    |
| BJ25KLEUR 1997                                               | IGNITION SYSTEM - TE        |
| BJ25KLEUR 1997                                               | IGNITION SYSTEM - TNT       |
| BJ25KLEUR 1997                                               | IGNITION SYSTEM - REMOTE    |
| BJ25PL3EEM 1999                                              | IGNITION SYSTEM -- E, EL    |

|                                                                |                                         |
|----------------------------------------------------------------|-----------------------------------------|
| BJ25PL3EEM 1999                                                | IGNITION SYSTEM -- PL                   |
| BJ25PL3EEM 1999                                                | IGNITION SYSTEM -- TEL                  |
| BJ25PL3SIE elec start, TNT, 20 in shaft 2001                   | IGNITION SYSTEM - K - E - EL - EV - EVL |
| BJ25PL3SIE elec start, TNT, 20 in shaft 2001                   | IGNITION SYSTEM - PL - VL               |
| BJ25PL3SIE elec start, TNT, 20 in shaft 2001                   | IGNITION SYSTEM - TEL - TVL             |
| BJ25PL3SSB 3 Cyl, Elec. Start, TNT, 20 IN. shaft, N/A USA 2000 | IGNITION SYSTEM - K, E, EL              |
| BJ25PL3SSB 3 Cyl, Elec. Start, TNT, 20 IN. shaft, N/A USA 2000 | IGNITION SYSTEM - PL                    |
| BJ25PL3SSB 3 Cyl, Elec. Start, TNT, 20 IN. shaft, N/A USA 2000 | IGNITION SYSTEM - TEL                   |
| BJ25QLECA 1998                                                 | IGNITION SYSTEM -- REMOTE               |
| BJ25QLECA 1998                                                 | IGNITION SYSTEM -- TE                   |
| BJ25QLECA 1998                                                 | IGNITION SYSTEM -- TNT                  |
| BJ25QLEDC 1996                                                 | IGNITION SYSTEM - TEL                   |
| BJ25QLEDC 1996                                                 | IGNITION SYSTEM - TNT                   |
| BJ25QLEDC 1996                                                 | IGNITION SYSTEM - REMOTE                |
| BJ25QLEUR 1997                                                 | IGNITION SYSTEM - TE                    |
| BJ25QLEUR 1997                                                 | IGNITION SYSTEM - TNT                   |
| BJ25QLEUR 1997                                                 | IGNITION SYSTEM - REMOTE                |
| BJ25VL3SIE elec start, TNT, 20 in shaft, wht, n/a usa 2001     | IGNITION SYSTEM - K - E - EL - EV - EVL |
| BJ25VL3SIE elec start, TNT, 20 in shaft, wht, n/a usa 2001     | IGNITION SYSTEM - PL - VL               |
| BJ25VL3SIE elec start, TNT, 20 in shaft, wht, n/a usa 2001     | IGNITION SYSTEM - TEL - TVL             |
| BJ30EECS 1998                                                  | BATTERY CABLE                           |
| BJ30EECS 1998                                                  | ELECTRIC STARTER & SOLENOID             |
| BJ30EEDE 1996                                                  | BATTERY CABLE                           |
| BJ30EEDE 1996                                                  | ELECTRIC STARTER & SOLENOID             |
| BJ30EEEC 1999                                                  | BATTERY CABLE                           |
| BJ30EEEC 1999                                                  | ELECTRIC STARTER & SOLENOID             |
| BJ30EEEN 1999                                                  | BATTERY CABLE                           |
| BJ30EEEN 1999                                                  | ELECTRIC STARTER & SOLENOID             |
| BJ30EEUD 1997                                                  | BATTERY CABLE                           |
| BJ30EEUD 1997                                                  | ELECTRIC STARTER & SOLENOID             |
| BJ30ELECS 1998                                                 | BATTERY CABLE                           |
| BJ30ELECS 1998                                                 | ELECTRIC STARTER & SOLENOID             |
| BJ30ELEDE 1996                                                 | BATTERY CABLE                           |
| BJ30ELEDE 1996                                                 | ELECTRIC STARTER & SOLENOID             |
| BJ30ELEEC 1999                                                 | BATTERY CABLE                           |

|                                                               |                             |
|---------------------------------------------------------------|-----------------------------|
| BJ30ELEEC 1999                                                | ELECTRIC STARTER & SOLENOID |
| BJ30ELEEN 1999                                                | BATTERY CABLE               |
| BJ30ELEEN 1999                                                | ELECTRIC STARTER & SOLENOID |
| BJ30ELEUD 1997                                                | BATTERY CABLE               |
| BJ30ELEUD 1997                                                | ELECTRIC STARTER & SOLENOID |
| BJ30ELSIA elec start, remote, 20 in shaft, n/a usa 2001       | BATTERY CABLE               |
| BJ30ELSIA elec start, remote, 20 in shaft, n/a usa 2001       | ELECTRIC STARTER & SOLENOID |
| BJ30ELSSR Elec. Start, 20 IN. shaft, N/A USA 2000             | BATTERY CABLE               |
| BJ30ELSSR Elec. Start, 20 IN. shaft, N/A USA 2000             | ELECTRIC STARTER & SOLENOID |
| BJ30ESIA elec start, remote, 15 in shaft, n/a usa 2001        | BATTERY CABLE               |
| BJ30ESIA elec start, remote, 15 in shaft, n/a usa 2001        | ELECTRIC STARTER & SOLENOID |
| BJ30ESSR Elec. Start, 15 IN. shaft, N/A USA 2000              | BATTERY CABLE               |
| BJ30ESSR Elec. Start, 15 IN. shaft, N/A USA 2000              | ELECTRIC STARTER & SOLENOID |
| BJ30EVLSIA elec start, remote, 20 in shaft, wht, n/a usa 2001 | BATTERY CABLE               |
| BJ30EVLSIA elec start, remote, 20 in shaft, wht, n/a usa 2001 | ELECTRIC STARTER & SOLENOID |
| BJ30EVSIA elec start, remote, 15 in shaft, wht, n/a usa 2001  | BATTERY CABLE               |
| BJ30EVSIA elec start, remote, 15 in shaft, wht, n/a usa 2001  | ELECTRIC STARTER & SOLENOID |
| BJ35ARECR 1998                                                | IGNITION SYSTEM -- REMOTE   |
| BJ35ARECR 1998                                                | IGNITION SYSTEM -- TE       |
| BJ35ARECR 1998                                                | IGNITION SYSTEM -- TNT      |
| BJ35AREDS 1996                                                | IGNITION SYSTEM - TEL       |
| BJ35AREDS 1996                                                | IGNITION SYSTEM - TNT       |
| BJ35AREDS 1996                                                | IGNITION SYSTEM - REMOTE    |
| BJ35AREEA 1999                                                | IGNITION SYSTEM -- E, EL    |
| BJ35AREEA 1999                                                | IGNITION SYSTEM -- PL       |
| BJ35AREEA 1999                                                | IGNITION SYSTEM -- TEL      |
| BJ35AREUC 1997                                                | IGNITION SYSTEM - TE        |
| BJ35AREUC 1997                                                | IGNITION SYSTEM - TNT       |
| BJ35AREUC 1997                                                | IGNITION SYSTEM - REMOTE    |
| BJ35ARLECR 1998                                               | IGNITION SYSTEM -- REMOTE   |
| BJ35ARLECR 1998                                               | IGNITION SYSTEM -- TE       |
| BJ35ARLECR 1998                                               | IGNITION SYSTEM -- TNT      |
| BJ35ARLEDS 1996                                               | IGNITION SYSTEM - TEL       |
| BJ35ARLEDS 1996                                               | IGNITION SYSTEM - TNT       |
| BJ35ARLEDS 1996                                               | IGNITION SYSTEM - REMOTE    |

|                                                           |                                         |
|-----------------------------------------------------------|-----------------------------------------|
| BJ35ARLEUC 1997                                           | IGNITION SYSTEM - TE                    |
| BJ35ARLEUC 1997                                           | IGNITION SYSTEM - TNT                   |
| BJ35ARLEUC 1997                                           | IGNITION SYSTEM - REMOTE                |
| BJ35E3EEM 1999                                            | IGNITION SYSTEM -- E, EL                |
| BJ35E3EEM 1999                                            | IGNITION SYSTEM -- PL                   |
| BJ35E3EEM 1999                                            | IGNITION SYSTEM -- TEL                  |
| BJ35E3SIE elec start, 15 in shaft, n/a usa 2001           | IGNITION SYSTEM - K - E - EL - EV - EVL |
| BJ35E3SIE elec start, 15 in shaft, n/a usa 2001           | IGNITION SYSTEM - PL - VL               |
| BJ35E3SIE elec start, 15 in shaft, n/a usa 2001           | IGNITION SYSTEM - TEL - TVL             |
| BJ35E3SSB 3 Cyl, Elec. Start, 15 IN. shaft, N/A USA 2000  | IGNITION SYSTEM - K, E, EL              |
| BJ35E3SSB 3 Cyl, Elec. Start, 15 IN. shaft, N/A USA 2000  | IGNITION SYSTEM - PL                    |
| BJ35E3SSB 3 Cyl, Elec. Start, 15 IN. shaft, N/A USA 2000  | IGNITION SYSTEM - TEL                   |
| BJ35EL3EEM 1999                                           | IGNITION SYSTEM -- E, EL                |
| BJ35EL3EEM 1999                                           | IGNITION SYSTEM -- PL                   |
| BJ35EL3EEM 1999                                           | IGNITION SYSTEM -- TEL                  |
| BJ35EL3SIE elec start, 20 in shaft, wht, n/a usa 2001     | IGNITION SYSTEM - K - E - EL - EV - EVL |
| BJ35EL3SIE elec start, 20 in shaft, wht, n/a usa 2001     | IGNITION SYSTEM - PL - VL               |
| BJ35EL3SIE elec start, 20 in shaft, wht, n/a usa 2001     | IGNITION SYSTEM - TEL - TVL             |
| BJ35EL3SSB 3 Cyl, Elec. Start, 20 IN. shaft, N/A USA 2000 | IGNITION SYSTEM - K, E, EL              |
| BJ35EL3SSB 3 Cyl, Elec. Start, 20 IN. shaft, N/A USA 2000 | IGNITION SYSTEM - PL                    |
| BJ35EL3SSB 3 Cyl, Elec. Start, 20 IN. shaft, N/A USA 2000 | IGNITION SYSTEM - TEL                   |
| BJ35EV3SIE elec start, 15 in shaft, wht, n/a usa 2001     | IGNITION SYSTEM - K - E - EL - EV - EVL |
| BJ35EV3SIE elec start, 15 in shaft, wht, n/a usa 2001     | IGNITION SYSTEM - PL - VL               |
| BJ35EV3SIE elec start, 15 in shaft, wht, n/a usa 2001     | IGNITION SYSTEM - TEL - TVL             |
| BJ35EVL3SIE elec start, 20 in shaft, wht, n/a usa 2001    | IGNITION SYSTEM - K - E - EL - EV - EVL |
| BJ35EVL3SIE elec start, 20 in shaft, wht, n/a usa 2001    | IGNITION SYSTEM - PL - VL               |
| BJ35EVL3SIE elec start, 20 in shaft, wht, n/a usa 2001    | IGNITION SYSTEM - TEL - TVL             |
| BJ35KECA 1998                                             | IGNITION SYSTEM -- REMOTE               |
| BJ35KECA 1998                                             | IGNITION SYSTEM -- TE                   |
| BJ35KECA 1998                                             | IGNITION SYSTEM -- TNT                  |
| BJ35KEDC 1996                                             | IGNITION SYSTEM - TEL                   |
| BJ35KEDC 1996                                             | IGNITION SYSTEM - TNT                   |
| BJ35KEDC 1996                                             | IGNITION SYSTEM - REMOTE                |
| BJ35KEEM 1999                                             | IGNITION SYSTEM -- E, EL                |
| BJ35KEEM 1999                                             | IGNITION SYSTEM -- PL                   |

|                                                                |                                         |
|----------------------------------------------------------------|-----------------------------------------|
| BJ35KEEM 1999                                                  | IGNITION SYSTEM -- TEL                  |
| BJ35KEUR 1997                                                  | IGNITION SYSTEM - TE                    |
| BJ35KEUR 1997                                                  | IGNITION SYSTEM - TNT                   |
| BJ35KEUR 1997                                                  | IGNITION SYSTEM - REMOTE                |
| BJ35KLECA 1998                                                 | IGNITION SYSTEM -- REMOTE               |
| BJ35KLECA 1998                                                 | IGNITION SYSTEM -- TE                   |
| BJ35KLECA 1998                                                 | IGNITION SYSTEM -- TNT                  |
| BJ35KLEDC 1996                                                 | IGNITION SYSTEM - TEL                   |
| BJ35KLEDC 1996                                                 | IGNITION SYSTEM - TNT                   |
| BJ35KLEDC 1996                                                 | IGNITION SYSTEM - REMOTE                |
| BJ35KLEUR 1997                                                 | IGNITION SYSTEM - TE                    |
| BJ35KLEUR 1997                                                 | IGNITION SYSTEM - TNT                   |
| BJ35KLEUR 1997                                                 | IGNITION SYSTEM - REMOTE                |
| BJ35PL3EEM 1999                                                | IGNITION SYSTEM -- E, EL                |
| BJ35PL3EEM 1999                                                | IGNITION SYSTEM -- PL                   |
| BJ35PL3EEM 1999                                                | IGNITION SYSTEM -- TEL                  |
| BJ35PL3SIE elec start, TNT, 20 in shaft 2001                   | IGNITION SYSTEM - K - E - EL - EV - EVL |
| BJ35PL3SIE elec start, TNT, 20 in shaft 2001                   | IGNITION SYSTEM - PL - VL               |
| BJ35PL3SIE elec start, TNT, 20 in shaft 2001                   | IGNITION SYSTEM - TEL - TVL             |
| BJ35PL3SSB 3 Cyl, Elec. Start, TNT, 20 IN. shaft, N/A USA 2000 | IGNITION SYSTEM - K, E, EL              |
| BJ35PL3SSB 3 Cyl, Elec. Start, TNT, 20 IN. shaft, N/A USA 2000 | IGNITION SYSTEM - PL                    |
| BJ35PL3SSB 3 Cyl, Elec. Start, TNT, 20 IN. shaft, N/A USA 2000 | IGNITION SYSTEM - TEL                   |
| BJ35QLECA 1998                                                 | IGNITION SYSTEM -- REMOTE               |
| BJ35QLECA 1998                                                 | IGNITION SYSTEM -- TE                   |
| BJ35QLECA 1998                                                 | IGNITION SYSTEM -- TNT                  |
| BJ35QLEDC 1996                                                 | IGNITION SYSTEM - TEL                   |
| BJ35QLEDC 1996                                                 | IGNITION SYSTEM - TNT                   |
| BJ35QLEDC 1996                                                 | IGNITION SYSTEM - REMOTE                |
| BJ35QLEUR 1997                                                 | IGNITION SYSTEM - TE                    |
| BJ35QLEUR 1997                                                 | IGNITION SYSTEM - TNT                   |
| BJ35QLEUR 1997                                                 | IGNITION SYSTEM - REMOTE                |
| BJ35VL3SIE elec start, TNT, 20 in shaft, wht, n/a usa 2001     | IGNITION SYSTEM - K - E - EL - EV - EVL |
| BJ35VL3SIE elec start, TNT, 20 in shaft, wht, n/a usa 2001     | IGNITION SYSTEM - PL - VL               |
| BJ35VL3SIE elec start, TNT, 20 in shaft, wht, n/a usa 2001     | IGNITION SYSTEM - TEL - TVL             |
| BJ40EECR 1998                                                  | ELECTRIC STARTER & SOLENOID             |

|                                                        |                                                            |
|--------------------------------------------------------|------------------------------------------------------------|
| BJ40EECR 1998                                          | IGNITION SYSTEM -- 40-50 ELECTRIC START                    |
| BJ40EEDS 1996                                          | ELECTRIC STARTER & SOLENOID                                |
| BJ40EEDS 1996                                          | IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS |
| BJ40EEDS 1996                                          | IGNITION SYSTEM - ELECTRIC START 40TE MODELS               |
| BJ40EEEE 1999                                          | IGNITION SYSTEM -- ELECTRIC START                          |
| BJ40EEEE 1999                                          | ELECTRIC STARTER & SOLENOID                                |
| BJ40EEUC 1997                                          | ELECTRIC STARTER & SOLENOID                                |
| BJ40EEUC 1997                                          | IGNITION SYSTEM - 40-50 ELECTRIC START                     |
| BJ40ELECR 1998                                         | ELECTRIC STARTER & SOLENOID                                |
| BJ40ELECR 1998                                         | IGNITION SYSTEM -- 40-50 ELECTRIC START                    |
| BJ40ELEDs 1996                                         | ELECTRIC STARTER & SOLENOID                                |
| BJ40ELEDs 1996                                         | IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS |
| BJ40ELEDs 1996                                         | IGNITION SYSTEM - ELECTRIC START 40TE MODELS               |
| BJ40ELEEA 1999                                         | IGNITION SYSTEM -- ELECTRIC START                          |
| BJ40ELEEA 1999                                         | ELECTRIC STARTER & SOLENOID                                |
| BJ40ELEUC 1997                                         | ELECTRIC STARTER & SOLENOID                                |
| BJ40ELEUC 1997                                         | IGNITION SYSTEM - 40-50 ELECTRIC START                     |
| BJ40ELSIF elec start, 20 in shaft, n/a usa 2001        | IGNITION SYSTEM - ELECTRIC START                           |
| BJ40ELSIF elec start, 20 in shaft, n/a usa 2001        | ELECTRIC STARTER & SOLENOID                                |
| BJ40ELSSM Elec. Start, 20 IN. shaft, N/A USA 2000      | IGNITION SYSTEM - ELECTRIC START                           |
| BJ40ELSSM Elec. Start, 20 IN. shaft, N/A USA 2000      | ELECTRIC STARTER & SOLENOID                                |
| BJ40ESIF elec start, 15 in shaft, n/a usa 2001         | IGNITION SYSTEM - ELECTRIC START                           |
| BJ40ESIF elec start, 15 in shaft, n/a usa 2001         | ELECTRIC STARTER & SOLENOID                                |
| BJ40ESSM Elec. Start, 15 IN. shaft, N/A USA 2000       | IGNITION SYSTEM - ELECTRIC START                           |
| BJ40ESSM Elec. Start, 15 IN. shaft, N/A USA 2000       | ELECTRIC STARTER & SOLENOID                                |
| BJ40PLEEA 1999                                         | IGNITION SYSTEM -- ELECTRIC START                          |
| BJ40PLEEA 1999                                         | ELECTRIC STARTER & SOLENOID                                |
| BJ40PLSIF elec start, TNT, 20 in shaft, n/a usa 2001   | IGNITION SYSTEM - ELECTRIC START                           |
| BJ40PLSIF elec start, TNT, 20 in shaft, n/a usa 2001   | ELECTRIC STARTER & SOLENOID                                |
| BJ40PLSSM Elec. Start, TNT, 15 IN. shaft, N/A USA 2000 | IGNITION SYSTEM - ELECTRIC START                           |
| BJ40PLSSM Elec. Start, TNT, 15 IN. shaft, N/A USA 2000 | ELECTRIC STARTER & SOLENOID                                |
| BJ40TLECR 1998                                         | ELECTRIC STARTER & SOLENOID                                |
| BJ40TLECR 1998                                         | IGNITION SYSTEM -- 40-50 ELECTRIC START                    |
| BJ40TLEDs 1996                                         | ELECTRIC STARTER & SOLENOID                                |

|                                                                |                                                            |
|----------------------------------------------------------------|------------------------------------------------------------|
| BJ40TLEDS 1996                                                 | IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS |
| BJ40TLEDS 1996                                                 | IGNITION SYSTEM - ELECTRIC START 40TE MODELS               |
| BJ40TLEUC 1997                                                 | ELECTRIC STARTER & SOLENOID                                |
| BJ40TLEUC 1997                                                 | IGNITION SYSTEM - 40-50 ELECTRIC START                     |
| BJ50BEEDS 1996                                                 | ELECTRIC STARTER & SOLENOID                                |
| BJ50BEEDS 1996                                                 | IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS |
| BJ50BEEDS 1996                                                 | IGNITION SYSTEM - ELECTRIC START 40TE MODELS               |
| BJ50BELEDs 1996                                                | ELECTRIC STARTER & SOLENOID                                |
| BJ50BELEDs 1996                                                | IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS |
| BJ50BELEDs 1996                                                | IGNITION SYSTEM - ELECTRIC START 40TE MODELS               |
| BJ50DTLEDC 1996                                                | BATTERY CABLE                                              |
| BJ50DTLEDC 1996                                                | ELECTRIC STARTER                                           |
| BJ50DTLEUR 1997                                                | BATTERY CABLE                                              |
| BJ50DTLEUR 1997                                                | ELECTRIC STARTER                                           |
| BJ50EEER 1999                                                  | IGNITION SYSTEM -- ELECTRIC START                          |
| BJ50EEER 1999                                                  | ELECTRIC STARTER & SOLENOID                                |
| BJ50ELEER 1999                                                 | IGNITION SYSTEM -- ELECTRIC START                          |
| BJ50ELEER 1999                                                 | ELECTRIC STARTER & SOLENOID                                |
| BJ50ELSIF elec start, 20 in shaft, n/a usa 2001                | IGNITION SYSTEM - ELECTRIC START                           |
| BJ50ELSIF elec start, 20 in shaft, n/a usa 2001                | ELECTRIC STARTER & SOLENOID                                |
| BJ50ELSSA Elec. Start, 20 IN. shaft, N/A USA 2000              | IGNITION SYSTEM - ELECTRIC START                           |
| BJ50ELSSA Elec. Start, 20 IN. shaft, N/A USA 2000              | ELECTRIC STARTER & SOLENOID                                |
| BJ50ESECC 1998                                                 | ELECTRIC STARTER & SOLENOID                                |
| BJ50ESECC 1998                                                 | IGNITION SYSTEM -- 40-50 ELECTRIC START                    |
| BJ50ESIF elec start, 15 in shaft, n/a usa 2001                 | IGNITION SYSTEM - ELECTRIC START                           |
| BJ50ESIF elec start, 15 in shaft, n/a usa 2001                 | ELECTRIC STARTER & SOLENOID                                |
| BJ50ESSA Elec Start, 15 IN. shaft, N/A USA 2000                | IGNITION SYSTEM - ELECTRIC START                           |
| BJ50ESSA Elec Start, 15 IN. shaft, N/A USA 2000                | ELECTRIC STARTER & SOLENOID                                |
| BJ50PLEEA 1999                                                 | IGNITION SYSTEM -- ELECTRIC START                          |
| BJ50PLEEA 1999                                                 | ELECTRIC STARTER & SOLENOID                                |
| BJ50PLSIF elec start, TNT, 20 in shaft, n/a usa 2001           | IGNITION SYSTEM - ELECTRIC START                           |
| BJ50PLSIF elec start, TNT, 20 in shaft, n/a usa 2001           | ELECTRIC STARTER & SOLENOID                                |
| BJ50PLSSM Elec. Start, TNT, Tiller, 20 IN. shaft, N/A USA 2000 | IGNITION SYSTEM - ELECTRIC START                           |
| BJ50PLSSM Elec. Start, TNT, Tiller, 20 IN. shaft, N/A USA 2000 | ELECTRIC STARTER & SOLENOID                                |

|                                                  |                                                            |
|--------------------------------------------------|------------------------------------------------------------|
| BJ50RLECR 1998                                   | ELECTRIC STARTER & SOLENOID                                |
| BJ50RLECR 1998                                   | IGNITION SYSTEM -- 40-50 ELECTRIC START                    |
| BJ50RLEEA 1999                                   | IGNITION SYSTEM -- ELECTRIC START                          |
| BJ50RLEEA 1999                                   | ELECTRIC STARTER & SOLENOID                                |
| BJ50RLEUC 1997                                   | ELECTRIC STARTER & SOLENOID                                |
| BJ50RLEUC 1997                                   | IGNITION SYSTEM - 40-50 ELECTRIC START                     |
| BJ50RLSIF elec start, 20 in shaft, n/a usa 2001  | IGNITION SYSTEM - ELECTRIC START                           |
| BJ50RLSIF elec start, 20 in shaft, n/a usa 2001  | ELECTRIC STARTER & SOLENOID                                |
| BJ50RLSSM Rope Start, 20 IN. shaft, N/A USA 2000 | IGNITION SYSTEM - ELECTRIC START                           |
| BJ50RLSSM Rope Start, 20 IN. shaft, N/A USA 2000 | ELECTRIC STARTER & SOLENOID                                |
| BJ50TLECR 1998                                   | ELECTRIC STARTER & SOLENOID                                |
| BJ50TLECR 1998                                   | IGNITION SYSTEM -- 40-50 ELECTRIC START                    |
| BJ50TLEDS 1996                                   | ELECTRIC STARTER & SOLENOID                                |
| BJ50TLEDS 1996                                   | IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS |
| BJ50TLEDS 1996                                   | IGNITION SYSTEM - ELECTRIC START 40TE MODELS               |
| BJ50TLEUC 1997                                   | ELECTRIC STARTER & SOLENOID                                |
| BJ50TLEUC 1997                                   | IGNITION SYSTEM - 40-50 ELECTRIC START                     |
| BJ50TSLECC 1998                                  | ELECTRIC STARTER & SOLENOID                                |
| BJ50TSLECC 1998                                  | IGNITION SYSTEM -- 40-50 ELECTRIC START                    |
| BJ50TSLEUS 1997                                  | ELECTRIC STARTER & SOLENOID                                |
| BJ50TSLEUS 1997                                  | IGNITION SYSTEM - 40-50 ELECTRIC START                     |
| BJ60ELED R 1996                                  | BATTERY CABLE                                              |
| BJ60ELED R 1996                                  | ELECTRIC STARTER                                           |
| BJ60ELEUA 1997                                   | BATTERY CABLE                                              |
| BJ60ELEUA 1997                                   | ELECTRIC STARTER                                           |
| BJ60TLECM 1998                                   | BATTERY CABLE                                              |
| BJ60TLECM 1998                                   | ELECTRIC STARTER                                           |
| BJ60TLEDR 1996                                   | BATTERY CABLE                                              |
| BJ60TLEDR 1996                                   | ELECTRIC STARTER                                           |
| BJ60TLEUA 1997                                   | BATTERY CABLE                                              |
| BJ60TLEUA 1997                                   | ELECTRIC STARTER                                           |
| BJ70ELECB 1998                                   | BATTERY CABLE                                              |
| BJ70ELECB 1998                                   | ELECTRIC STARTER                                           |
| BJ70ELED A 1996                                  | BATTERY CABLE                                              |



|                                                      |                             |
|------------------------------------------------------|-----------------------------|
| BJ70ELED A 1996                                      | ELECTRIC STARTER            |
| BJ70ELEUM 1997                                       | BATTERY CABLE               |
| BJ70ELEUM 1997                                       | ELECTRIC STARTER            |
| BJ70PLEEE 1999                                       | ELECTRIC STARTER            |
| BJ70PLEEE 1999                                       | BATTERY CABLE               |
| BJ70PLSIS elec start, TNT, 20 in shaft, n/a usa 2001 | ELECTRIC STARTER            |
| BJ70PLSIS elec start, TNT, 20 in shaft, n/a usa 2001 | BATTERY CABLE               |
| BJ70PLSSD Elec Start, TNT, 20 IN. shaft 2000         | ELECTRIC STARTER            |
| BJ70PLSSD Elec Start, TNT, 20 IN. shaft 2000         | BATTERY CABLE               |
| BJ70TLECB 1998                                       | BATTERY CABLE               |
| BJ70TLECB 1998                                       | ELECTRIC STARTER            |
| BJ70TLEDA 1996                                       | BATTERY CABLE               |
| BJ70TLEDA 1996                                       | ELECTRIC STARTER            |
| BJ70TLEUM 1997                                       | BATTERY CABLE               |
| BJ70TLEUM 1997                                       | ELECTRIC STARTER            |
| E20EEND 1992                                         | ELECTRIC STARTER & SOLENOID |
| E20EEOR 1995                                         | BATTERY CABLE               |
| E20EEOR 1995                                         | ELECTRIC STARTER & SOLENOID |
| E20EERC 1994                                         | BATTERY CABLES              |
| E20EERC 1994                                         | ELECTRIC STARTER & SOLENOID |
| E20EETS 1993                                         | BATTERY CABLES              |
| E20EETS 1993                                         | ELECTRIC STARTER & SOLENOID |
| E20ELEND 1992                                        | ELECTRIC STARTER & SOLENOID |
| E20ELEOR 1995                                        | BATTERY CABLE               |
| E20ELEOR 1995                                        | ELECTRIC STARTER & SOLENOID |
| E20ELERC 1994                                        | BATTERY CABLES              |
| E20ELERC 1994                                        | ELECTRIC STARTER & SOLENOID |
| E20ELET S 1993                                       | BATTERY CABLES              |
| E20ELET S 1993                                       | ELECTRIC STARTER & SOLENOID |
| E25EECE 1998                                         | BATTERY CABLE               |
| E25EECE 1998                                         | ELECTRIC STARTER & SOLENOID |
| E25EEDM 1996                                         | BATTERY CABLE               |
| E25EEDM 1996                                         | ELECTRIC STARTER & SOLENOID |
| E25EENS 1992                                         | ELECTRIC STARTER & SOLENOID |
| E25EEOA 1995                                         | BATTERY CABLE               |

|               |                             |
|---------------|-----------------------------|
| E25EEOA 1995  | ELECTRIC STARTER & SOLENOID |
| E25EERR 1994  | BATTERY CABLES              |
| E25EERR 1994  | ELECTRIC STARTER & SOLENOID |
| E25EETC 1993  | BATTERY CABLES              |
| E25EETC 1993  | ELECTRIC STARTER & SOLENOID |
| E25EEUB 1997  | BATTERY CABLE               |
| E25EEUB 1997  | ELECTRIC STARTER & SOLENOID |
| E25ELECE 1998 | BATTERY CABLE               |
| E25ELECE 1998 | ELECTRIC STARTER & SOLENOID |
| E25ELEDM 1996 | BATTERY CABLE               |
| E25ELEDM 1996 | ELECTRIC STARTER & SOLENOID |
| E25ELENS 1992 | ELECTRIC STARTER & SOLENOID |
| E25ELEOA 1995 | BATTERY CABLE               |
| E25ELEOA 1995 | ELECTRIC STARTER & SOLENOID |
| E25ELERR 1994 | BATTERY CABLES              |
| E25ELERR 1994 | ELECTRIC STARTER & SOLENOID |
| E25ELETG 1993 | BATTERY CABLES              |
| E25ELETG 1993 | ELECTRIC STARTER & SOLENOID |
| E25ELEUB 1997 | BATTERY CABLE               |
| E25ELEUB 1997 | ELECTRIC STARTER & SOLENOID |
| E25KLECA 1998 | IGNITION SYSTEM -- REMOTE   |
| E25KLECA 1998 | IGNITION SYSTEM -- TE       |
| E25KLECA 1998 | IGNITION SYSTEM -- TNT      |
| E25KLEDC 1996 | IGNITION SYSTEM - TEL       |
| E25KLEDC 1996 | IGNITION SYSTEM - TNT       |
| E25KLEDC 1996 | IGNITION SYSTEM - REMOTE    |
| E25KLEUR 1997 | IGNITION SYSTEM - TE        |
| E25KLEUR 1997 | IGNITION SYSTEM - TNT       |
| E25KLEUR 1997 | IGNITION SYSTEM - REMOTE    |
| E25QLECA 1998 | IGNITION SYSTEM -- REMOTE   |
| E25QLECA 1998 | IGNITION SYSTEM -- TE       |
| E25QLECA 1998 | IGNITION SYSTEM -- TNT      |
| E25QLEDC 1996 | IGNITION SYSTEM - TEL       |
| E25QLEDC 1996 | IGNITION SYSTEM - TNT       |
| E25QLEDC 1996 | IGNITION SYSTEM - REMOTE    |

|                |                             |
|----------------|-----------------------------|
| E25QLEUR 1997  | IGNITION SYSTEM - TE        |
| E25QLEUR 1997  | IGNITION SYSTEM - TNT       |
| E25QLEUR 1997  | IGNITION SYSTEM - REMOTE    |
| E25RMECA 1998  | IGNITION SYSTEM -- REMOTE   |
| E25RMECA 1998  | IGNITION SYSTEM -- TE       |
| E25RMECA 1998  | IGNITION SYSTEM -- TNT      |
| E25RMEDC 1996  | IGNITION SYSTEM - TEL       |
| E25RMEDC 1996  | IGNITION SYSTEM - TNT       |
| E25RMEDC 1996  | IGNITION SYSTEM - REMOTE    |
| E25RMEUR 1997  | IGNITION SYSTEM - TE        |
| E25RMEUR 1997  | IGNITION SYSTEM - TNT       |
| E25RMEUR 1997  | IGNITION SYSTEM - REMOTE    |
| E25RMLECA 1998 | IGNITION SYSTEM -- REMOTE   |
| E25RMLECA 1998 | IGNITION SYSTEM -- TE       |
| E25RMLECA 1998 | IGNITION SYSTEM -- TNT      |
| E25RMLEDC 1996 | IGNITION SYSTEM - TEL       |
| E25RMLEDC 1996 | IGNITION SYSTEM - TNT       |
| E25RMLEDC 1996 | IGNITION SYSTEM - REMOTE    |
| E25RMLEUR 1997 | IGNITION SYSTEM - TE        |
| E25RMLEUR 1997 | IGNITION SYSTEM - TNT       |
| E25RMLEUR 1997 | IGNITION SYSTEM - REMOTE    |
| E25TEECB 1998  | ELECTRIC STARTER & SOLENOID |
| E25TEEDA 1996  | ELECTRIC STARTER & SOLENOID |
| E25TEEOR 1995  | ELECTRIC STARTER & SOLENOID |
| E25TEERC 1994  | ELECTRIC STARTER & SOLENOID |
| E25TEEUM 1997  | ELECTRIC STARTER & SOLENOID |
| E25TELECB 1998 | ELECTRIC STARTER & SOLENOID |
| E25TELEDA 1996 | ELECTRIC STARTER & SOLENOID |
| E25TELEOR 1995 | ELECTRIC STARTER & SOLENOID |
| E25TELEUM 1997 | ELECTRIC STARTER & SOLENOID |
| E25TKECA 1998  | IGNITION SYSTEM -- REMOTE   |
| E25TKECA 1998  | IGNITION SYSTEM -- TE       |
| E25TKECA 1998  | IGNITION SYSTEM -- TNT      |
| E25TKEDC 1996  | IGNITION SYSTEM - TEL       |
| E25TKEDC 1996  | IGNITION SYSTEM - TNT       |

|                |                             |
|----------------|-----------------------------|
| E25TKEDC 1996  | IGNITION SYSTEM - REMOTE    |
| E25TKEUR 1997  | IGNITION SYSTEM - TE        |
| E25TKEUR 1997  | IGNITION SYSTEM - TNT       |
| E25TKEUR 1997  | IGNITION SYSTEM - REMOTE    |
| E25TKLECA 1998 | IGNITION SYSTEM -- REMOTE   |
| E25TKLECA 1998 | IGNITION SYSTEM -- TE       |
| E25TKLECA 1998 | IGNITION SYSTEM -- TNT      |
| E25TKLEDC 1996 | IGNITION SYSTEM - TEL       |
| E25TKLEDC 1996 | IGNITION SYSTEM - TNT       |
| E25TKLEDC 1996 | IGNITION SYSTEM - REMOTE    |
| E25TKLEUR 1997 | IGNITION SYSTEM - TE        |
| E25TKLEUR 1997 | IGNITION SYSTEM - TNT       |
| E25TKLEUR 1997 | IGNITION SYSTEM - REMOTE    |
| E28ESLEDR 1996 | BATTERY CABLE               |
| E28ESLEDR 1996 | ELECTRIC STARTER & SOLENOID |
| E28ESLENE 1992 | ELECTRIC STARTER & SOLENOID |
| E28ESLEOC 1995 | BATTERY CABLE               |
| E28ESLEOC 1995 | ELECTRIC STARTER & SOLENOID |
| E28ESLERS 1994 | BATTERY CABLES              |
| E28ESLERS 1994 | ELECTRIC STARTER & SOLENOID |
| E28ESLETD 1993 | BATTERY CABLES              |
| E28ESLETD 1993 | ELECTRIC STARTER & SOLENOID |
| E30EECS 1998   | BATTERY CABLE               |
| E30EECS 1998   | ELECTRIC STARTER & SOLENOID |
| E30EEDE 1996   | BATTERY CABLE               |
| E30EEDE 1996   | ELECTRIC STARTER & SOLENOID |
| E30EENR 1992   | ELECTRIC STARTER & SOLENOID |
| E30EEOB 1995   | BATTERY CABLE               |
| E30EEOB 1995   | ELECTRIC STARTER & SOLENOID |
| E30EERM 1994   | BATTERY CABLES              |
| E30EERM 1994   | ELECTRIC STARTER & SOLENOID |
| E30EETA 1993   | BATTERY CABLES              |
| E30EETA 1993   | ELECTRIC STARTER & SOLENOID |
| E30EEUD 1997   | BATTERY CABLE               |
| E30EEUD 1997   | ELECTRIC STARTER & SOLENOID |

|                |                             |
|----------------|-----------------------------|
| E30ELECS 1998  | BATTERY CABLE               |
| E30ELECS 1998  | ELECTRIC STARTER & SOLENOID |
| E30ELEDE 1996  | BATTERY CABLE               |
| E30ELEDE 1996  | ELECTRIC STARTER & SOLENOID |
| E30ELENR 1992  | ELECTRIC STARTER & SOLENOID |
| E30ELEOB 1995  | BATTERY CABLE               |
| E30ELEOB 1995  | ELECTRIC STARTER & SOLENOID |
| E30ELERM 1994  | BATTERY CABLES              |
| E30ELERM 1994  | ELECTRIC STARTER & SOLENOID |
| E30ELETA 1993  | BATTERY CABLES              |
| E30ELETA 1993  | ELECTRIC STARTER & SOLENOID |
| E30ELEUD 1997  | BATTERY CABLE               |
| E30ELEUD 1997  | ELECTRIC STARTER & SOLENOID |
| E30TEECS 1998  | ELECTRIC STARTER & SOLENOID |
| E30TEEDE 1996  | ELECTRIC STARTER & SOLENOID |
| E30TEEOB 1995  | ELECTRIC STARTER & SOLENOID |
| E30TEERM 1994  | ELECTRIC STARTER & SOLENOID |
| E30TEEUD 1997  | ELECTRIC STARTER & SOLENOID |
| E30TELECB 1998 | ELECTRIC STARTER & SOLENOID |
| E30TELEDE 1996 | ELECTRIC STARTER & SOLENOID |
| E30TELEOB 1995 | ELECTRIC STARTER & SOLENOID |
| E30TELERM 1994 | ELECTRIC STARTER & SOLENOID |
| E30TELEUD 1997 | ELECTRIC STARTER & SOLENOID |
| E35KLECA 1998  | IGNITION SYSTEM -- REMOTE   |
| E35KLECA 1998  | IGNITION SYSTEM -- TE       |
| E35KLECA 1998  | IGNITION SYSTEM -- TNT      |
| E35KLEDC 1996  | IGNITION SYSTEM - TEL       |
| E35KLEDC 1996  | IGNITION SYSTEM - TNT       |
| E35KLEDC 1996  | IGNITION SYSTEM - REMOTE    |
| E35KLEUR 1997  | IGNITION SYSTEM - TE        |
| E35KLEUR 1997  | IGNITION SYSTEM - TNT       |
| E35KLEUR 1997  | IGNITION SYSTEM - REMOTE    |
| E35QLECA 1998  | IGNITION SYSTEM -- REMOTE   |
| E35QLECA 1998  | IGNITION SYSTEM -- TE       |
| E35QLECA 1998  | IGNITION SYSTEM -- TNT      |

|                |                                                           |
|----------------|-----------------------------------------------------------|
| E35QLEDC 1996  | IGNITION SYSTEM - TEL                                     |
| E35QLEDC 1996  | IGNITION SYSTEM - TNT                                     |
| E35QLEDC 1996  | IGNITION SYSTEM - REMOTE                                  |
| E35QLEUR 1997  | IGNITION SYSTEM - TE                                      |
| E35QLEUR 1997  | IGNITION SYSTEM - TNT                                     |
| E35QLEUR 1997  | IGNITION SYSTEM - REMOTE                                  |
| E35RMLEDC 1996 | IGNITION SYSTEM - TEL                                     |
| E35RMLEDC 1996 | IGNITION SYSTEM - TNT                                     |
| E35RMLEDC 1996 | IGNITION SYSTEM - REMOTE                                  |
| E35RMLEUR 1997 | IGNITION SYSTEM - TE                                      |
| E35RMLEUR 1997 | IGNITION SYSTEM - TNT                                     |
| E35RMLEUR 1997 | IGNITION SYSTEM - REMOTE                                  |
| E35TKLECA 1998 | IGNITION SYSTEM -- REMOTE                                 |
| E35TKLECA 1998 | IGNITION SYSTEM -- TE                                     |
| E35TKLECA 1998 | IGNITION SYSTEM -- TNT                                    |
| E35TKLEDC 1996 | IGNITION SYSTEM - TEL                                     |
| E35TKLEDC 1996 | IGNITION SYSTEM - TNT                                     |
| E35TKLEDC 1996 | IGNITION SYSTEM - REMOTE                                  |
| E35TKLEUR 1997 | IGNITION SYSTEM - TE                                      |
| E35TKLEUR 1997 | IGNITION SYSTEM - TNT                                     |
| E35TKLEUR 1997 | IGNITION SYSTEM - REMOTE                                  |
| E40EEIA 1991   | ELECTRIC STARTER & SOLENOID                               |
| E40EENJ 1992   | ELECTRIC STARTER & SOLENOID                               |
| E40EENJ 1992   | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| E40EENJ 1992   | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |
| E40EENJ 1992   | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |
| E40EENJ 1992   | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |
| E40EENM 1992   | ELECTRIC STARTER & SOLENOID                               |
| E40EENM 1992   | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| E40EENM 1992   | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |
| E40EENM 1992   | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |

|               |                                                            |
|---------------|------------------------------------------------------------|
| E40EENM 1992  | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)  |
| E40EEOD 1995  | ELECTRIC STARTER & SOLENOID                                |
| E40EEOD 1995  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| E40EEOD 1995  | IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS       |
| E40EERE 1994  | ELECTRIC STARTER & SOLENOID                                |
| E40EERE 1994  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| E40EERE 1994  | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS    |
| E40EETB 1993  | ELECTRIC STARTER & SOLENOID                                |
| E40EETB 1993  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| E40EETB 1993  | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS    |
| E40EETB 1993  | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY        |
| E40ELECR 1998 | ELECTRIC STARTER & SOLENOID                                |
| E40ELECR 1998 | IGNITION SYSTEM -- 40-50 ELECTRIC START                    |
| E40ELEDs 1996 | ELECTRIC STARTER & SOLENOID                                |
| E40ELEDs 1996 | IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS |
| E40ELEDs 1996 | IGNITION SYSTEM - ELECTRIC START 40TE MODELS               |
| E40ELEIA 1991 | ELECTRIC STARTER & SOLENOID                                |
| E40ELENJ 1992 | ELECTRIC STARTER & SOLENOID                                |
| E40ELENJ 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)  |
| E40ELENJ 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)  |
| E40ELENJ 1992 | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)  |
| E40ELENJ 1992 | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)  |
| E40ELENM 1992 | ELECTRIC STARTER & SOLENOID                                |
| E40ELENM 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)  |
| E40ELENM 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)  |
| E40ELENM 1992 | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)  |
| E40ELENM 1992 | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)  |

|               |                                                            |
|---------------|------------------------------------------------------------|
| E40ELEOD 1995 | ELECTRIC STARTER & SOLENOID                                |
| E40ELEOD 1995 | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| E40ELEOD 1995 | IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS       |
| E40ELERE 1994 | ELECTRIC STARTER & SOLENOID                                |
| E40ELERE 1994 | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| E40ELERE 1994 | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS    |
| E40ELETB 1993 | ELECTRIC STARTER & SOLENOID                                |
| E40ELETB 1993 | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| E40ELETB 1993 | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS    |
| E40ELETB 1993 | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY        |
| E40ELEUC 1997 | ELECTRIC STARTER & SOLENOID                                |
| E40ELEUC 1997 | IGNITION SYSTEM - 40-50 ELECTRIC START                     |
| E40RECR 1998  | ELECTRIC STARTER & SOLENOID                                |
| E40RECR 1998  | IGNITION SYSTEM -- 40-50 ELECTRIC START                    |
| E40REDS 1996  | ELECTRIC STARTER & SOLENOID                                |
| E40REDS 1996  | IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS |
| E40REDS 1996  | IGNITION SYSTEM - ELECTRIC START 40TE MODELS               |
| E40REIA 1991  | ELECTRIC STARTER & SOLENOID                                |
| E40RENM 1992  | ELECTRIC STARTER & SOLENOID                                |
| E40RENM 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)  |
| E40RENM 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)  |
| E40RENM 1992  | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)  |
| E40RENM 1992  | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)  |
| E40REOD 1995  | ELECTRIC STARTER & SOLENOID                                |
| E40REOD 1995  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| E40REOD 1995  | IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS       |
| E40RERE 1994  | ELECTRIC STARTER & SOLENOID                                |
| E40RERE 1994  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |



|               |                                                            |
|---------------|------------------------------------------------------------|
| E40RERE 1994  | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS    |
| E40RETB 1993  | ELECTRIC STARTER & SOLENOID                                |
| E40RETB 1993  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| E40RETB 1993  | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS    |
| E40RETB 1993  | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY        |
| E40REUC 1997  | ELECTRIC STARTER & SOLENOID                                |
| E40REUC 1997  | IGNITION SYSTEM - 40-50 ELECTRIC START                     |
| E40RLECR 1998 | ELECTRIC STARTER & SOLENOID                                |
| E40RLECR 1998 | IGNITION SYSTEM -- 40-50 ELECTRIC START                    |
| E40RLEDS 1996 | ELECTRIC STARTER & SOLENOID                                |
| E40RLEDS 1996 | IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS |
| E40RLEDS 1996 | IGNITION SYSTEM - ELECTRIC START 40TE MODELS               |
| E40RLEIA 1991 | ELECTRIC STARTER & SOLENOID                                |
| E40RLENM 1992 | ELECTRIC STARTER & SOLENOID                                |
| E40RLENM 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)  |
| E40RLENM 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)  |
| E40RLENM 1992 | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)  |
| E40RLENM 1992 | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)  |
| E40RLEOD 1995 | ELECTRIC STARTER & SOLENOID                                |
| E40RLEOD 1995 | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| E40RLEOD 1995 | IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS       |
| E40RLERE 1994 | ELECTRIC STARTER & SOLENOID                                |
| E40RLERE 1994 | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| E40RLERE 1994 | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS    |
| E40RLETB 1993 | ELECTRIC STARTER & SOLENOID                                |
| E40RLETB 1993 | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| E40RLETB 1993 | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS    |

|               |                                                            |
|---------------|------------------------------------------------------------|
| E40RLETB 1993 | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY        |
| E40RLEUC 1997 | ELECTRIC STARTER & SOLENOID                                |
| E40RLEUC 1997 | IGNITION SYSTEM - 40-50 ELECTRIC START                     |
| E40TEECR 1998 | ELECTRIC STARTER & SOLENOID                                |
| E40TEECR 1998 | IGNITION SYSTEM -- 40-50 ELECTRIC START                    |
| E40TEEDS 1996 | ELECTRIC STARTER & SOLENOID                                |
| E40TEEDS 1996 | IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS |
| E40TEEDS 1996 | IGNITION SYSTEM - ELECTRIC START 40TE MODELS               |
| E40TEEIA 1991 | ELECTRIC STARTER & SOLENOID                                |
| E40TEENJ 1992 | ELECTRIC STARTER & SOLENOID                                |
| E40TEENJ 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)  |
| E40TEENJ 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)  |
| E40TEENJ 1992 | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)  |
| E40TEENJ 1992 | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)  |
| E40TEENM 1992 | ELECTRIC STARTER & SOLENOID                                |
| E40TEENM 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)  |
| E40TEENM 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)  |
| E40TEENM 1992 | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)  |
| E40TEENM 1992 | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)  |
| E40TEEOD 1995 | ELECTRIC STARTER & SOLENOID                                |
| E40TEEOD 1995 | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| E40TEEOD 1995 | IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS       |
| E40TEERE 1994 | ELECTRIC STARTER & SOLENOID                                |
| E40TEERE 1994 | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| E40TEERE 1994 | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS    |
| E40TEETB 1993 | ELECTRIC STARTER & SOLENOID                                |
| E40TEETB 1993 | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |

|                |                                                            |
|----------------|------------------------------------------------------------|
| E40TEETB 1993  | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS    |
| E40TEETB 1993  | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY        |
| E40TEEUC 1997  | ELECTRIC STARTER & SOLENOID                                |
| E40TEEUC 1997  | IGNITION SYSTEM - 40-50 ELECTRIC START                     |
| E40TELECR 1998 | ELECTRIC STARTER & SOLENOID                                |
| E40TELECR 1998 | IGNITION SYSTEM -- 40-50 ELECTRIC START                    |
| E40TELEDS 1996 | ELECTRIC STARTER & SOLENOID                                |
| E40TELEDS 1996 | IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS |
| E40TELEDS 1996 | IGNITION SYSTEM - ELECTRIC START 40TE MODELS               |
| E40TELEIA 1991 | ELECTRIC STARTER & SOLENOID                                |
| E40TELENJ 1992 | ELECTRIC STARTER & SOLENOID                                |
| E40TELENJ 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)  |
| E40TELENJ 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)  |
| E40TELENJ 1992 | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)  |
| E40TELENJ 1992 | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)  |
| E40TELENM 1992 | ELECTRIC STARTER & SOLENOID                                |
| E40TELENM 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)  |
| E40TELENM 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)  |
| E40TELENM 1992 | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)  |
| E40TELENM 1992 | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)  |
| E40TELEOD 1995 | ELECTRIC STARTER & SOLENOID                                |
| E40TELEOD 1995 | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| E40TELEOD 1995 | IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS       |
| E40TELERE 1994 | ELECTRIC STARTER & SOLENOID                                |
| E40TELERE 1994 | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| E40TELERE 1994 | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS    |
| E40TELETB 1993 | ELECTRIC STARTER & SOLENOID                                |
| E40TELETB 1993 | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |

|                |                                                            |
|----------------|------------------------------------------------------------|
| E40TELETB 1993 | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS    |
| E40TELETB 1993 | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY        |
| E40TELEUC 1997 | ELECTRIC STARTER & SOLENOID                                |
| E40TELEUC 1997 | IGNITION SYSTEM - 40-50 ELECTRIC START                     |
| E40TLECR 1998  | ELECTRIC STARTER & SOLENOID                                |
| E40TLECR 1998  | IGNITION SYSTEM -- 40-50 ELECTRIC START                    |
| E40TLEDS 1996  | ELECTRIC STARTER & SOLENOID                                |
| E40TLEDS 1996  | IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS |
| E40TLEDS 1996  | IGNITION SYSTEM - ELECTRIC START 40TE MODELS               |
| E40TLEIA 1991  | ELECTRIC STARTER & SOLENOID                                |
| E40TLENJ 1992  | ELECTRIC STARTER & SOLENOID                                |
| E40TLENJ 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)  |
| E40TLENJ 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)  |
| E40TLENJ 1992  | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)  |
| E40TLENJ 1992  | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)  |
| E40TLENM 1992  | ELECTRIC STARTER & SOLENOID                                |
| E40TLENM 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)  |
| E40TLENM 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)  |
| E40TLENM 1992  | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)  |
| E40TLENM 1992  | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)  |
| E40TLEOD 1995  | ELECTRIC STARTER & SOLENOID                                |
| E40TLEOD 1995  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| E40TLEOD 1995  | IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS       |
| E40TLERE 1994  | ELECTRIC STARTER & SOLENOID                                |
| E40TLERE 1994  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| E40TLERE 1994  | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS    |
| E40TLETB 1993  | ELECTRIC STARTER & SOLENOID                                |
| E40TLETB 1993  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |

|                |                                                            |
|----------------|------------------------------------------------------------|
| E40TLETB 1993  | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS    |
| E40TLETB 1993  | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY        |
| E40TLETF 1993  | ELECTRIC STARTER & SOLENOID                                |
| E40TLETF 1993  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| E40TLETF 1993  | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS    |
| E40TLETF 1993  | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY        |
| E40TLEUC 1997  | ELECTRIC STARTER & SOLENOID                                |
| E40TLEUC 1997  | IGNITION SYSTEM - 40-50 ELECTRIC START                     |
| E40TTLECR 1998 | ELECTRIC STARTER & SOLENOID                                |
| E40TTLECR 1998 | IGNITION SYSTEM -- 40-50 ELECTRIC START                    |
| E40TTLEDS 1996 | ELECTRIC STARTER & SOLENOID                                |
| E40TTLEDS 1996 | IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS |
| E40TTLEDS 1996 | IGNITION SYSTEM - ELECTRIC START 40TE MODELS               |
| E40TTLEIA 1991 | ELECTRIC STARTER & SOLENOID                                |
| E40TTLENM 1992 | ELECTRIC STARTER & SOLENOID                                |
| E40TTLENM 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)  |
| E40TTLENM 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)  |
| E40TTLENM 1992 | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)  |
| E40TTLENM 1992 | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)  |
| E40TTLEOD 1995 | ELECTRIC STARTER & SOLENOID                                |
| E40TTLEOD 1995 | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| E40TTLEOD 1995 | IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS       |
| E40TTLERE 1994 | ELECTRIC STARTER & SOLENOID                                |
| E40TTLERE 1994 | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| E40TTLERE 1994 | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS    |
| E40TTLETB 1993 | ELECTRIC STARTER & SOLENOID                                |
| E40TTLETB 1993 | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |

|                |                                                           |
|----------------|-----------------------------------------------------------|
| E40TTLETB 1993 | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS   |
| E40TTLETB 1993 | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY       |
| E40TTLETF 1993 | ELECTRIC STARTER & SOLENOID                               |
| E40TTLETF 1993 | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS   |
| E40TTLETF 1993 | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS   |
| E40TTLETF 1993 | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY       |
| E40TTLEUC 1997 | ELECTRIC STARTER & SOLENOID                               |
| E40TTLEUC 1997 | IGNITION SYSTEM - 40-50 ELECTRIC START                    |
| E45RCENM 1992  | REMOTE CONTROL                                            |
| E45RCLENM 1992 | REMOTE CONTROL                                            |
| E45WMLNEM 1992 | REMOTE CONTROL                                            |
| E48ESLEDC 1996 | BATTERY CABLE                                             |
| E48ESLEDC 1996 | ELECTRIC STARTER & SOLENOID                               |
| E48ESLEIM 1991 | ELECTRIC STARTER & SOLENOID                               |
| E48ESLENB 1992 | ELECTRIC STARTER & SOLENOID                               |
| E48ESLEOS 1995 | BATTERY CABLE                                             |
| E48ESLEOS 1995 | ELECTRIC STARTER & SOLENOID                               |
| E48ESLERD 1994 | BATTERY CABLES                                            |
| E48ESLERD 1994 | ELECTRIC STARTER & SOLENOID                               |
| E48ESLETE 1993 | BATTERY CABLES                                            |
| E48ESLETE 1993 | ELECTRIC STARTER & SOLENOID                               |
| E50BEEIA 1991  | ELECTRIC STARTER & SOLENOID                               |
| E50BEENJ 1992  | ELECTRIC STARTER & SOLENOID                               |
| E50BEENJ 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| E50BEENJ 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |
| E50BEENJ 1992  | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |
| E50BEENJ 1992  | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |
| E50BEENM 1992  | ELECTRIC STARTER & SOLENOID                               |
| E50BEENM 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| E50BEENM 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |

|                |                                                           |
|----------------|-----------------------------------------------------------|
| E50BEENM 1992  | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |
| E50BEENM 1992  | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |
| E50BEEOD 1995  | ELECTRIC STARTER & SOLENOID                               |
| E50BEEOD 1995  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS   |
| E50BEEOD 1995  | IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS      |
| E50BEERE 1994  | ELECTRIC STARTER & SOLENOID                               |
| E50BEERE 1994  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS   |
| E50BEERE 1994  | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS   |
| E50BEETB 1993  | ELECTRIC STARTER & SOLENOID                               |
| E50BEETB 1993  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS   |
| E50BEETB 1993  | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS   |
| E50BEETB 1993  | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY       |
| E50BELEIA 1991 | ELECTRIC STARTER & SOLENOID                               |
| E50BELENJ 1992 | ELECTRIC STARTER & SOLENOID                               |
| E50BELENJ 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| E50BELENJ 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |
| E50BELENJ 1992 | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |
| E50BELENJ 1992 | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |
| E50BELENM 1992 | ELECTRIC STARTER & SOLENOID                               |
| E50BELENM 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| E50BELENM 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |
| E50BELENM 1992 | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |
| E50BELENM 1992 | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |
| E50BELEOD 1995 | ELECTRIC STARTER & SOLENOID                               |
| E50BELEOD 1995 | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS   |
| E50BELEOD 1995 | IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS      |

|                |                                                            |
|----------------|------------------------------------------------------------|
| E50BELERE 1994 | ELECTRIC STARTER & SOLENOID                                |
| E50BELERE 1994 | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| E50BELERE 1994 | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS    |
| E50BELETB 1993 | ELECTRIC STARTER & SOLENOID                                |
| E50BELETB 1993 | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| E50BELETB 1993 | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS    |
| E50BELETB 1993 | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY        |
| E50DTLECA 1998 | BATTERY CABLE                                              |
| E50DTLECA 1998 | ELECTRIC STARTER                                           |
| E50DTLEDC 1996 | BATTERY CABLE                                              |
| E50DTLEDC 1996 | ELECTRIC STARTER                                           |
| E50DTLEOS 1995 | BATTERY CABLE                                              |
| E50DTLEOS 1995 | ELECTRIC STARTER                                           |
| E50DTLEUR 1997 | BATTERY CABLE                                              |
| E50DTLEUR 1997 | ELECTRIC STARTER                                           |
| E50ELED 1996   | BATTERY CABLE                                              |
| E50ELED 1996   | ELECTRIC STARTER                                           |
| E50ELEOS 1995  | BATTERY CABLE                                              |
| E50ELEOS 1995  | ELECTRIC STARTER                                           |
| E50ELEUR 1997  | BATTERY CABLE                                              |
| E50ELEUR 1997  | ELECTRIC STARTER                                           |
| E50ESLECC 1998 | ELECTRIC STARTER & SOLENOID                                |
| E50ESLECC 1998 | IGNITION SYSTEM -- 40-50 ELECTRIC START                    |
| E50ESLEUR 1997 | ELECTRIC STARTER & SOLENOID                                |
| E50ESLEUR 1997 | IGNITION SYSTEM - 40-50 ELECTRIC START                     |
| E50JEDS 1996   | ELECTRIC STARTER & SOLENOID                                |
| E50JEDS 1996   | IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS |
| E50JEDS 1996   | IGNITION SYSTEM - ELECTRIC START 40TE MODELS               |
| E50JEIA 1991   | ELECTRIC STARTER & SOLENOID                                |
| E50JENJ 1992   | ELECTRIC STARTER & SOLENOID                                |
| E50JENJ 1992   | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)  |



|                |                                                           |
|----------------|-----------------------------------------------------------|
| E50JENJ 1992   | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |
| E50JENJ 1992   | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |
| E50JENJ 1992   | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |
| E50JENM 1992   | ELECTRIC STARTER & SOLENOID                               |
| E50JENM 1992   | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| E50JENM 1992   | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |
| E50JENM 1992   | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |
| E50JENM 1992   | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |
| E50JEOD 1995   | ELECTRIC STARTER & SOLENOID                               |
| E50JEOD 1995   | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS   |
| E50JEOD 1995   | IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS      |
| E50JERE 1994   | ELECTRIC STARTER & SOLENOID                               |
| E50JERE 1994   | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS   |
| E50JERE 1994   | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS   |
| E50JETB 1993   | ELECTRIC STARTER & SOLENOID                               |
| E50JETB 1993   | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS   |
| E50JETB 1993   | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS   |
| E50JETB 1993   | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY       |
| E50JEUC 1997   | ELECTRIC STARTER & SOLENOID                               |
| E50JEUC 1997   | IGNITION SYSTEM - 40-50 ELECTRIC START                    |
| E50RNLIB 1992  | ELECTRIC STARTER & SOLENOID                               |
| E50TELEIA 1991 | ELECTRIC STARTER & SOLENOID                               |
| E50TELENM 1992 | ELECTRIC STARTER & SOLENOID                               |
| E50TELENM 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| E50TELENM 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |
| E50TELENM 1992 | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |

|                |                                                            |
|----------------|------------------------------------------------------------|
| E50TELENM 1992 | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)  |
| E50TELEOD 1995 | ELECTRIC STARTER & SOLENOID                                |
| E50TELEOD 1995 | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| E50TELEOD 1995 | IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS       |
| E50TELERE 1994 | ELECTRIC STARTER & SOLENOID                                |
| E50TELERE 1994 | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| E50TELERE 1994 | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS    |
| E50TELETB 1993 | ELECTRIC STARTER & SOLENOID                                |
| E50TELETB 1993 | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| E50TELETB 1993 | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS    |
| E50TELETB 1993 | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY        |
| E50TLECR 1998  | ELECTRIC STARTER & SOLENOID                                |
| E50TLECR 1998  | IGNITION SYSTEM -- 40-50 ELECTRIC START                    |
| E50TLEDS 1996  | ELECTRIC STARTER & SOLENOID                                |
| E50TLEDS 1996  | IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS |
| E50TLEDS 1996  | IGNITION SYSTEM - ELECTRIC START 40TE MODELS               |
| E50TLEIA 1991  | ELECTRIC STARTER & SOLENOID                                |
| E50TLENJ 1992  | ELECTRIC STARTER & SOLENOID                                |
| E50TLENJ 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)  |
| E50TLENJ 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)  |
| E50TLENJ 1992  | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)  |
| E50TLENJ 1992  | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)  |
| E50TLENM 1992  | ELECTRIC STARTER & SOLENOID                                |
| E50TLENM 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)  |
| E50TLENM 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)  |
| E50TLENM 1992  | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)  |
| E50TLENM 1992  | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)  |

|                |                                                         |
|----------------|---------------------------------------------------------|
| E50TLEOD 1995  | ELECTRIC STARTER & SOLENOID                             |
| E50TLEOD 1995  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS |
| E50TLEOD 1995  | IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS    |
| E50TLERE 1994  | ELECTRIC STARTER & SOLENOID                             |
| E50TLERE 1994  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS |
| E50TLERE 1994  | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS |
| E50TLETB 1993  | ELECTRIC STARTER & SOLENOID                             |
| E50TLETB 1993  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS |
| E50TLETB 1993  | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS |
| E50TLETB 1993  | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY     |
| E50TLETF 1993  | ELECTRIC STARTER & SOLENOID                             |
| E50TLETF 1993  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS |
| E50TLETF 1993  | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS |
| E50TLETF 1993  | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY     |
| E50TLEUC 1997  | ELECTRIC STARTER & SOLENOID                             |
| E50TLEUC 1997  | IGNITION SYSTEM - 40-50 ELECTRIC START                  |
| E50TSLECC 1998 | ELECTRIC STARTER & SOLENOID                             |
| E50TSLECC 1998 | IGNITION SYSTEM -- 40-50 ELECTRIC START                 |
| E50TSLEUS 1997 | ELECTRIC STARTER & SOLENOID                             |
| E50TSLEUS 1997 | IGNITION SYSTEM - 40-50 ELECTRIC START                  |
| E50TTLECA 1998 | ELECTRIC STARTER                                        |
| E50TTLECA 1998 | IGNITION SYSTEM                                         |
| E50TTLEDC 1996 | ELECTRIC STARTER                                        |
| E50TTLEDC 1996 | IGNITION SYSTEM                                         |
| E50TTLEOS 1995 | ELECTRIC STARTER                                        |
| E50TTLEOS 1995 | IGNITION SYSTEM                                         |
| E50TTLEUR 1997 | ELECTRIC STARTER                                        |
| E50TTLEUR 1997 | IGNITION SYSTEM                                         |
| E55RWLENM 1992 | REMOTE CONTROL                                          |
| E60ELEDR 1996  | BATTERY CABLE                                           |

|                 |                  |
|-----------------|------------------|
| E60ELED R 1996  | ELECTRIC STARTER |
| E60ELENE 1992   | ELECTRIC STARTER |
| E60ELEOC 1995   | BATTERY CABLE    |
| E60ELEOC 1995   | ELECTRIC STARTER |
| E60ELERS 1994   | BATTERY CABLES   |
| E60ELERS 1994   | ELECTRIC STARTER |
| E60ELERV 1994   | BATTERY CABLES   |
| E60ELERV 1994   | ELECTRIC STARTER |
| E60ELET D 1993  | BATTERY CABLES   |
| E60ELET D 1993  | ELECTRIC STARTER |
| E60ELEUA 1997   | BATTERY CABLE    |
| E60ELEUA 1997   | ELECTRIC STARTER |
| E60TLECM 1998   | BATTERY CABLE    |
| E60TLECM 1998   | ELECTRIC STARTER |
| E60TLED R 1996  | BATTERY CABLE    |
| E60TLED R 1996  | ELECTRIC STARTER |
| E60TLENE 1992   | ELECTRIC STARTER |
| E60TLEOC 1995   | BATTERY CABLE    |
| E60TLEOC 1995   | ELECTRIC STARTER |
| E60TLERS 1994   | BATTERY CABLES   |
| E60TLERS 1994   | ELECTRIC STARTER |
| E60TLERV 1994   | BATTERY CABLES   |
| E60TLERV 1994   | ELECTRIC STARTER |
| E60TLET D 1993  | BATTERY CABLES   |
| E60TLET D 1993  | ELECTRIC STARTER |
| E60TLEUA 1997   | BATTERY CABLE    |
| E60TLEUA 1997   | ELECTRIC STARTER |
| E60TTLECM 1998  | ELECTRIC STARTER |
| E60TTLECM 1998  | IGNITION SYSTEM  |
| E60TTLED R 1996 | ELECTRIC STARTER |
| E60TTLED R 1996 | IGNITION SYSTEM  |
| E60TTLENE 1992  | ELECTRIC STARTER |
| E60TTLEOC 1995  | ELECTRIC STARTER |
| E60TTLEOC 1995  | IGNITION SYSTEM  |
| E60TTLERS 1994  | ELECTRIC STARTER |

|                                                      |                  |
|------------------------------------------------------|------------------|
| E60TTLERS 1994                                       | IGNITION SYSTEM  |
| E60TTLERV 1994                                       | ELECTRIC STARTER |
| E60TTLERV 1994                                       | IGNITION SYSTEM  |
| E60TTLETD 1993                                       | ELECTRIC STARTER |
| E60TTLETD 1993                                       | IGNITION SYSTEM  |
| E60TTLEUA 1997                                       | ELECTRIC STARTER |
| E60TTLEUA 1997                                       | IGNITION SYSTEM  |
| E65WELEES 1999                                       | ELECTRIC STARTER |
| E65WELSIR Commercial, elec start, 20 in shaft 2001   | ELECTRIC STARTER |
| E65WELSSC Commercial, Elec. Start, 20 IN. shaft 2000 | ELECTRIC STARTER |
| E65WMLENE 1992                                       | ELECTRIC STARTER |
| E65WMLEOC 1995                                       | ELECTRIC STARTER |
| E65WMLERS 1994                                       | ELECTRIC STARTER |
| E65WMLETD 1993                                       | ELECTRIC STARTER |
| E70ELEND 1992                                        | ELECTRIC STARTER |
| E70ELEOR 1995                                        | BATTERY CABLE    |
| E70ELEOR 1995                                        | ELECTRIC STARTER |
| E70ELERC 1994                                        | BATTERY CABLES   |
| E70ELERC 1994                                        | ELECTRIC STARTER |
| E70ELERV 1994                                        | BATTERY CABLES   |
| E70ELERV 1994                                        | ELECTRIC STARTER |
| E70ELETs 1993                                        | BATTERY CABLES   |
| E70ELETs 1993                                        | ELECTRIC STARTER |
| E70TLECB 1998                                        | BATTERY CABLE    |
| E70TLECB 1998                                        | ELECTRIC STARTER |
| E70TLEDA 1996                                        | BATTERY CABLE    |
| E70TLEDA 1996                                        | ELECTRIC STARTER |
| E70TLEND 1992                                        | ELECTRIC STARTER |
| E70TLEOR 1995                                        | BATTERY CABLE    |
| E70TLEOR 1995                                        | ELECTRIC STARTER |
| E70TLERC 1994                                        | BATTERY CABLES   |
| E70TLERC 1994                                        | ELECTRIC STARTER |
| E70TLERV 1994                                        | BATTERY CABLES   |
| E70TLERV 1994                                        | ELECTRIC STARTER |
| E70TLETs 1993                                        | BATTERY CABLES   |

|                 |                                                       |
|-----------------|-------------------------------------------------------|
| E70TLETS 1993   | ELECTRIC STARTER                                      |
| E70TLEUM 1997   | BATTERY CABLE                                         |
| E70TLEUM 1997   | ELECTRIC STARTER                                      |
| E70TTLEND 1992  | ELECTRIC STARTER                                      |
| E70TTLEOR 1995  | ELECTRIC STARTER                                      |
| E70TTLEOR 1995  | IGNITION SYSTEM                                       |
| E70TTLERC 1994  | ELECTRIC STARTER                                      |
| E70TTLERC 1994  | IGNITION SYSTEM                                       |
| E70TTLERV 1994  | ELECTRIC STARTER                                      |
| E70TTLERV 1994  | IGNITION SYSTEM                                       |
| E70TTLETS 1993  | ELECTRIC STARTER                                      |
| E70TTLETS 1993  | IGNITION SYSTEM                                       |
| ELECTRICAL      | ELECTRIC START KIT - 40,50 HP (Johnson 2-Stroke)      |
| ELECTRICAL 1992 | ELECTRIC STARTING KIT 40,45,55                        |
| ELECTRICAL 1993 | ELECTRIC STARTING KIT - 45/55                         |
| ELECTRICAL 1994 | ELECTRIC STARTING KIT - 45/55                         |
| ELECTRICAL 1995 | REMOTE ELECTRIC START KIT - 25, 35 (3-CYLINDER ROPE)  |
| ELECTRICAL 1995 | TILLER ELECTRIC STARTING KIT - 45/55                  |
| ELECTRICAL 1995 | TILLER ELECTRIC START KIT - 25, 35 (3-CYLINDER ROPE)  |
| ELECTRICAL 1996 | REMOTE ELECTRIC START KIT - 25, 35 (3-CYLINDER ROPE)  |
| ELECTRICAL 1996 | TILLER ELECTRIC STARTING KIT - 40, 50                 |
| ELECTRICAL 1996 | TILLER ELECTRIC STARTING KIT - 45, 55                 |
| ELECTRICAL 1996 | TILLER ELECTRIC START KIT - 25, 35 (3-CYLINDER)       |
| ELECTRICAL 1997 | REMOTE ELECTRIC START KIT - 25, 35 (3-CYLINDER ROPE)  |
| ELECTRICAL 1997 | TILLER ELECTRIC STARTING KIT - 40, 50                 |
| ELECTRICAL 1997 | TILLER ELECTRIC STARTING KIT - 45, 55                 |
| ELECTRICAL 1997 | TILLER ELECTRIC START KIT - 25, 35 (3-CYLINDER)       |
| ELECTRICAL 1998 | REMOTE ELECTRIC START KIT -- 25, 35 (3-CYLINDER ROPE) |
| ELECTRICAL 1998 | TILLER ELECTRIC STARTING KIT -- 40, 50                |
| ELECTRICAL 1998 | TILLER ELECTRIC STARTING KIT -- 45, 55                |
| ELECTRICAL 1998 | TILLER ELECTRIC START KIT -- 25, 35 (3-CYLINDER)      |
| ELECTRICAL 1998 | TILLER ELECTRIC START KIT -- 65 MODELS                |
| ELECTRICAL 1999 | TILLER ELECTRIC STARTING KIT -- 40, 50                |

|                   |                                                            |
|-------------------|------------------------------------------------------------|
| ELECTRICAL 1999   | TILLER ELECTRIC START KIT -- 25, 35 (3-CYLINDER)           |
| ELECTRICAL 1999   | TILLER ELECTRIC STARTING KIT -- 40, 55                     |
| ELECTRICAL 1999   | TILLER ELECTRIC START KIT -- 65 MODELS                     |
| ELECTRICAL 1999   | REMOTE ELECTRIC START KIT -- 25, 35 (3-CYLINDER ROPE)      |
| ELECTRICAL 2000   | TILLER ELECTRIC STARTING KIT - 40, 50                      |
| ELECTRICAL 2000   | TILLER ELECTRIC STARTING KIT - 25, 35 (3-CYLINDER)         |
| ELECTRICAL 2000   | TILLER ELECTRIC STARTING KIT - 40, 55                      |
| ELECTRICAL 2000   | TILLER ELECTRIC START KIT - 65 MODELS                      |
| ELECTRICAL 2000   | REMOTE ELECTRIC START KIT - 25, 35 (3-CYLINDER ROPE)       |
| ELECTRICAL SYSTEM | Battery Cables                                             |
| HE25TELEDA 1996   | ELECTRIC STARTER & SOLENOID                                |
| HE35RMLEDC 1996   | IGNITION SYSTEM - TEL                                      |
| HE35RMLEDC 1996   | IGNITION SYSTEM - TNT                                      |
| HE35RMLEDC 1996   | IGNITION SYSTEM - REMOTE                                   |
| HE35RMLEUR 1997   | IGNITION SYSTEM - TE                                       |
| HE35RMLEUR 1997   | IGNITION SYSTEM - TNT                                      |
| HE35RMLEUR 1997   | IGNITION SYSTEM - REMOTE                                   |
| HE40REDS 1996     | ELECTRIC STARTER & SOLENOID                                |
| HE40REDS 1996     | IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS |
| HE40REDS 1996     | IGNITION SYSTEM - ELECTRIC START 40TE MODELS               |
| HE40REUC 1997     | ELECTRIC STARTER & SOLENOID                                |
| HE40REUC 1997     | IGNITION SYSTEM - 40-50 ELECTRIC START                     |
| HE40RLEDs 1996    | ELECTRIC STARTER & SOLENOID                                |
| HE40RLEDs 1996    | IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS |
| HE40RLEDs 1996    | IGNITION SYSTEM - ELECTRIC START 40TE MODELS               |
| HE40RLEUC 1997    | ELECTRIC STARTER & SOLENOID                                |
| HE40RLEUC 1997    | IGNITION SYSTEM - 40-50 ELECTRIC START                     |
| HE55WMLM 1996     | ELECTRIC STARTER & SOLENOID                                |
| HE55WMLM 1996     | REMOTE CONTROL                                             |
| HE55WMLZ 1997     | ELECTRIC STARTER & SOLENOID                                |
| HE70TXEDA 1996    | BATTERY CABLE                                              |
| HE70TXEDA 1996    | ELECTRIC STARTER                                           |
| HE70TXEUM 1997    | BATTERY CABLE                                              |

|                 |                                                            |
|-----------------|------------------------------------------------------------|
| HE70TXEUM 1997  | ELECTRIC STARTER                                           |
| HJ25TELEDA 1996 | ELECTRIC STARTER & SOLENOID                                |
| HJ35RMLEDC 1996 | IGNITION SYSTEM - TEL                                      |
| HJ35RMLEDC 1996 | IGNITION SYSTEM - TNT                                      |
| HJ35RMLEDC 1996 | IGNITION SYSTEM - REMOTE                                   |
| HJ35RMLEUR 1997 | IGNITION SYSTEM - TE                                       |
| HJ35RMLEUR 1997 | IGNITION SYSTEM - TNT                                      |
| HJ35RMLEUR 1997 | IGNITION SYSTEM - REMOTE                                   |
| HJ40REDS 1996   | ELECTRIC STARTER & SOLENOID                                |
| HJ40REDS 1996   | IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS |
| HJ40REDS 1996   | IGNITION SYSTEM - ELECTRIC START 40TE MODELS               |
| HJ40REUC 1997   | ELECTRIC STARTER & SOLENOID                                |
| HJ40REUC 1997   | IGNITION SYSTEM - 40-50 ELECTRIC START                     |
| HJ40RLEDS 1996  | ELECTRIC STARTER & SOLENOID                                |
| HJ40RLEDS 1996  | IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS |
| HJ40RLEDS 1996  | IGNITION SYSTEM - ELECTRIC START 40TE MODELS               |
| HJ40RLEUC 1997  | ELECTRIC STARTER & SOLENOID                                |
| HJ40RLEUC 1997  | IGNITION SYSTEM - 40-50 ELECTRIC START                     |
| HJ55WMLM 1996   | ELECTRIC STARTER & SOLENOID                                |
| HJ55WMLM 1996   | REMOTE CONTROL                                             |
| HJ55WMLZ 1997   | ELECTRIC STARTER & SOLENOID                                |
| HJ70TXEDA 1996  | BATTERY CABLE                                              |
| HJ70TXEDA 1996  | ELECTRIC STARTER                                           |
| HJ70TXEUM 1997  | BATTERY CABLE                                              |
| HJ70TXEUM 1997  | ELECTRIC STARTER                                           |
| J20EEND 1992    | ELECTRIC STARTER & SOLENOID                                |
| J20EEOR 1995    | BATTERY CABLE                                              |
| J20EEOR 1995    | ELECTRIC STARTER & SOLENOID                                |
| J20EERC 1994    | BATTERY CABLES                                             |
| J20EERC 1994    | ELECTRIC STARTER & SOLENOID                                |
| J20EETS 1993    | BATTERY CABLES                                             |
| J20EETS 1993    | ELECTRIC STARTER & SOLENOID                                |
| J20ELEND 1992   | ELECTRIC STARTER & SOLENOID                                |
| J20ELEOR 1995   | BATTERY CABLE                                              |



|               |                             |
|---------------|-----------------------------|
| J20ELEOR 1995 | ELECTRIC STARTER & SOLENOID |
| J20ELERC 1994 | BATTERY CABLES              |
| J20ELERC 1994 | ELECTRIC STARTER & SOLENOID |
| J20ELET5 1993 | BATTERY CABLES              |
| J20ELET5 1993 | ELECTRIC STARTER & SOLENOID |
| J25EECE 1998  | BATTERY CABLE               |
| J25EECE 1998  | ELECTRIC STARTER & SOLENOID |
| J25EEDM 1996  | BATTERY CABLE               |
| J25EEDM 1996  | ELECTRIC STARTER & SOLENOID |
| J25EEED 1999  | BATTERY CABLE               |
| J25EEED 1999  | ELECTRIC STARTER & SOLENOID |
| J25EEEN 1999  | BATTERY CABLE               |
| J25EEEN 1999  | ELECTRIC STARTER & SOLENOID |
| J25EENS 1992  | ELECTRIC STARTER & SOLENOID |
| J25EEOA 1995  | BATTERY CABLE               |
| J25EEOA 1995  | ELECTRIC STARTER & SOLENOID |
| J25EERR 1994  | BATTERY CABLES              |
| J25EERR 1994  | ELECTRIC STARTER & SOLENOID |
| J25EETC 1993  | BATTERY CABLES              |
| J25EETC 1993  | ELECTRIC STARTER & SOLENOID |
| J25EEUB 1997  | BATTERY CABLE               |
| J25EEUB 1997  | ELECTRIC STARTER & SOLENOID |
| J25ELECE 1998 | BATTERY CABLE               |
| J25ELECE 1998 | ELECTRIC STARTER & SOLENOID |
| J25ELEDM 1996 | BATTERY CABLE               |
| J25ELEDM 1996 | ELECTRIC STARTER & SOLENOID |
| J25ELEED 1999 | BATTERY CABLE               |
| J25ELEED 1999 | ELECTRIC STARTER & SOLENOID |
| J25ELEEN 1999 | BATTERY CABLE               |
| J25ELEEN 1999 | ELECTRIC STARTER & SOLENOID |
| J25ELENS 1992 | ELECTRIC STARTER & SOLENOID |
| J25ELEOA 1995 | BATTERY CABLE               |
| J25ELEOA 1995 | ELECTRIC STARTER & SOLENOID |
| J25ELERR 1994 | BATTERY CABLES              |
| J25ELERR 1994 | ELECTRIC STARTER & SOLENOID |

|                                                                      |                             |
|----------------------------------------------------------------------|-----------------------------|
| J25ELETG 1993                                                        | BATTERY CABLES              |
| J25ELETG 1993                                                        | ELECTRIC STARTER & SOLENOID |
| J25ELEUB 1997                                                        | BATTERY CABLE               |
| J25ELEUB 1997                                                        | ELECTRIC STARTER & SOLENOID |
| J25ELSIC elec start, remote, 20 in shaft 2001                        | BATTERY CABLE               |
| J25ELSIC elec start, remote, 20 in shaft 2001                        | ELECTRIC STARTER & SOLENOID |
| J25ELSNF - FR                                                        | 22-8_CÂBLE DE BATTERIE      |
| J25ELSNF Electric start, Carb, White, Remote, 20 in., 4 Amp Alt 2002 | BATTERY CABLE               |
| J25ELSOB                                                             | BATTERY CABLE               |
| J25ELSOB - FR                                                        | 22-8_CÂBLE DE BATTERIE      |
| J25ELSRM                                                             | BATTERY CABLE               |
| J25ELSRM - FR                                                        | 22-8_CÂBLE DE BATTERIE      |
| J25ELSSS Elec. Start, 20 IN. shaft 2000                              | BATTERY CABLE               |
| J25ELSSS Elec. Start, 20 IN. shaft 2000                              | ELECTRIC STARTER & SOLENOID |
| J25ELSTA                                                             | BATTERY CABLE               |
| J25ELSTA - FR                                                        | 22-8_CÂBLE DE BATTERIE      |
| J25ESIC elec start, remote, 15 in shaft 2001                         | BATTERY CABLE               |
| J25ESIC elec start, remote, 15 in shaft 2001                         | ELECTRIC STARTER & SOLENOID |
| J25ESSS Elec. Start, 15 IN. shaft 2000                               | BATTERY CABLE               |
| J25ESSS Elec. Start, 15 IN. shaft 2000                               | ELECTRIC STARTER & SOLENOID |
| J25EVLSIC elec start, remote, 120 in shaft, wht 2001                 | BATTERY CABLE               |
| J25EVLSIC elec start, remote, 120 in shaft, wht 2001                 | ELECTRIC STARTER & SOLENOID |
| J25EVSIC elec start, remote, 15 in shaft, wht 2001                   | BATTERY CABLE               |
| J25EVSIC elec start, remote, 15 in shaft, wht 2001                   | ELECTRIC STARTER & SOLENOID |
| J25KLECA 1998                                                        | IGNITION SYSTEM -- REMOTE   |
| J25KLECA 1998                                                        | IGNITION SYSTEM -- TE       |
| J25KLECA 1998                                                        | IGNITION SYSTEM -- TNT      |
| J25KLEDC 1996                                                        | IGNITION SYSTEM - TEL       |
| J25KLEDC 1996                                                        | IGNITION SYSTEM - TNT       |
| J25KLEDC 1996                                                        | IGNITION SYSTEM - REMOTE    |
| J25KLEUR 1997                                                        | IGNITION SYSTEM - TE        |
| J25KLEUR 1997                                                        | IGNITION SYSTEM - TNT       |
| J25KLEUR 1997                                                        | IGNITION SYSTEM - REMOTE    |
| J25PL3EEM 1999                                                       | IGNITION SYSTEM -- E, EL    |

|                                                        |                                         |
|--------------------------------------------------------|-----------------------------------------|
| J25PL3EEM 1999                                         | IGNITION SYSTEM -- PL                   |
| J25PL3EEM 1999                                         | IGNITION SYSTEM -- TEL                  |
| J25PL3SIE elec start, TNT, 20 in shaft 2001            | IGNITION SYSTEM - K - E - EL - EV - EVL |
| J25PL3SIE elec start, TNT, 20 in shaft 2001            | IGNITION SYSTEM - PL - VL               |
| J25PL3SIE elec start, TNT, 20 in shaft 2001            | IGNITION SYSTEM - TEL - TVL             |
| J25PL3SSB 3 Cyl, Elec. Start, TNT, 20 IN. shaft 2000   | IGNITION SYSTEM - K, E, EL              |
| J25PL3SSB 3 Cyl, Elec. Start, TNT, 20 IN. shaft 2000   | IGNITION SYSTEM - PL                    |
| J25PL3SSB 3 Cyl, Elec. Start, TNT, 20 IN. shaft 2000   | IGNITION SYSTEM - TEL                   |
| J25QLECA 1998                                          | IGNITION SYSTEM -- REMOTE               |
| J25QLECA 1998                                          | IGNITION SYSTEM -- TE                   |
| J25QLECA 1998                                          | IGNITION SYSTEM -- TNT                  |
| J25QLEDC 1996                                          | IGNITION SYSTEM - TEL                   |
| J25QLEDC 1996                                          | IGNITION SYSTEM - TNT                   |
| J25QLEDC 1996                                          | IGNITION SYSTEM - REMOTE                |
| J25QLEUR 1997                                          | IGNITION SYSTEM - TE                    |
| J25QLEUR 1997                                          | IGNITION SYSTEM - TNT                   |
| J25QLEUR 1997                                          | IGNITION SYSTEM - REMOTE                |
| J25R3EEM 1999                                          | IGNITION SYSTEM -- E, EL                |
| J25R3EEM 1999                                          | IGNITION SYSTEM -- PL                   |
| J25R3EEM 1999                                          | IGNITION SYSTEM -- TEL                  |
| J25R3SIE rope start, tiller, 15 in shaft 2001          | IGNITION SYSTEM - K - E - EL - EV - EVL |
| J25R3SIE rope start, tiller, 15 in shaft 2001          | IGNITION SYSTEM - PL - VL               |
| J25R3SIE rope start, tiller, 15 in shaft 2001          | IGNITION SYSTEM - TEL - TVL             |
| J25R3SSB 3 Cyl, Rope Start, Tiller, 15 IN. shaft 2000  | IGNITION SYSTEM - K, E, EL              |
| J25R3SSB 3 Cyl, Rope Start, Tiller, 15 IN. shaft 2000  | IGNITION SYSTEM - PL                    |
| J25R3SSB 3 Cyl, Rope Start, Tiller, 15 IN. shaft 2000  | IGNITION SYSTEM - TEL                   |
| J25RL3EEM 1999                                         | IGNITION SYSTEM -- E, EL                |
| J25RL3EEM 1999                                         | IGNITION SYSTEM -- PL                   |
| J25RL3EEM 1999                                         | IGNITION SYSTEM -- TEL                  |
| J25RL3SIE rope start, tiller, 20 in shaft 2001         | IGNITION SYSTEM - K - E - EL - EV - EVL |
| J25RL3SIE rope start, tiller, 20 in shaft 2001         | IGNITION SYSTEM - PL - VL               |
| J25RL3SIE rope start, tiller, 20 in shaft 2001         | IGNITION SYSTEM - TEL - TVL             |
| J25RL3SSB 3 Cyl, Rope Start, Tiller, 20 IN. shaft 2000 | IGNITION SYSTEM - K, E, EL              |
| J25RL3SSB 3 Cyl, Rope Start, Tiller, 20 IN. shaft 2000 | IGNITION SYSTEM - PL                    |
| J25RL3SSB 3 Cyl, Rope Start, Tiller, 20 IN. shaft 2000 | IGNITION SYSTEM - TEL                   |

|                                                              |                                         |
|--------------------------------------------------------------|-----------------------------------------|
| J25RMECA 1998                                                | IGNITION SYSTEM -- REMOTE               |
| J25RMECA 1998                                                | IGNITION SYSTEM -- TE                   |
| J25RMECA 1998                                                | IGNITION SYSTEM -- TNT                  |
| J25RMEDC 1996                                                | IGNITION SYSTEM - TEL                   |
| J25RMEDC 1996                                                | IGNITION SYSTEM - TNT                   |
| J25RMEDC 1996                                                | IGNITION SYSTEM - REMOTE                |
| J25RMEUR 1997                                                | IGNITION SYSTEM - TE                    |
| J25RMEUR 1997                                                | IGNITION SYSTEM - TNT                   |
| J25RMEUR 1997                                                | IGNITION SYSTEM - REMOTE                |
| J25RMLECA 1998                                               | IGNITION SYSTEM -- REMOTE               |
| J25RMLECA 1998                                               | IGNITION SYSTEM -- TE                   |
| J25RMLECA 1998                                               | IGNITION SYSTEM -- TNT                  |
| J25RMLEDC 1996                                               | IGNITION SYSTEM - TEL                   |
| J25RMLEDC 1996                                               | IGNITION SYSTEM - TNT                   |
| J25RMLEDC 1996                                               | IGNITION SYSTEM - REMOTE                |
| J25RMLEUR 1997                                               | IGNITION SYSTEM - TE                    |
| J25RMLEUR 1997                                               | IGNITION SYSTEM - TNT                   |
| J25RMLEUR 1997                                               | IGNITION SYSTEM - REMOTE                |
| J25RV3SIE rope start, tiller, 15 in shaft, wht, n/a usa 2001 | IGNITION SYSTEM - K - E - EL - EV - EVL |
| J25RV3SIE rope start, tiller, 15 in shaft, wht, n/a usa 2001 | IGNITION SYSTEM - PL - VL               |
| J25RV3SIE rope start, tiller, 15 in shaft, wht, n/a usa 2001 | IGNITION SYSTEM - TEL - TVL             |
| J25RVL3SIE rope start, tiller, 20 in shaft, wht 2001         | IGNITION SYSTEM - K - E - EL - EV - EVL |
| J25RVL3SIE rope start, tiller, 20 in shaft, wht 2001         | IGNITION SYSTEM - PL - VL               |
| J25RVL3SIE rope start, tiller, 20 in shaft, wht 2001         | IGNITION SYSTEM - TEL - TVL             |
| J25TEECB 1998                                                | ELECTRIC STARTER & SOLENOID             |
| J25TEEDA 1996                                                | ELECTRIC STARTER & SOLENOID             |
| J25TEEOR 1995                                                | ELECTRIC STARTER & SOLENOID             |
| J25TEERC 1994                                                | ELECTRIC STARTER & SOLENOID             |
| J25TEEUM 1997                                                | ELECTRIC STARTER & SOLENOID             |
| J25TEL3EEM 1999                                              | IGNITION SYSTEM -- E, EL                |
| J25TEL3EEM 1999                                              | IGNITION SYSTEM -- PL                   |
| J25TEL3EEM 1999                                              | IGNITION SYSTEM -- TEL                  |
| J25TEL3SIE elec start, tiller, 20 in shaft 2001              | IGNITION SYSTEM - K - E - EL - EV - EVL |
| J25TEL3SIE elec start, tiller, 20 in shaft 2001              | IGNITION SYSTEM - PL - VL               |
| J25TEL3SIE elec start, tiller, 20 in shaft 2001              | IGNITION SYSTEM - TEL - TVL             |

|                                                           |                                         |
|-----------------------------------------------------------|-----------------------------------------|
| J25TEL3SSB 3 Cyl, Elec. Start, Tiller, 20 IN. shaft 2000  | IGNITION SYSTEM - K, E, EL              |
| J25TEL3SSB 3 Cyl, Elec. Start, Tiller, 20 IN. shaft 2000  | IGNITION SYSTEM - PL                    |
| J25TEL3SSB 3 Cyl, Elec. Start, Tiller, 20 IN. shaft 2000  | IGNITION SYSTEM - TEL                   |
| J25TELECB 1998                                            | ELECTRIC STARTER & SOLENOID             |
| J25TELEDA 1996                                            | ELECTRIC STARTER & SOLENOID             |
| J25TELEOR 1995                                            | ELECTRIC STARTER & SOLENOID             |
| J25TELERC                                                 | ELECTRIC STARTER & SOLENOID             |
| J25TELEUM 1997                                            | ELECTRIC STARTER & SOLENOID             |
| J25TKECA 1998                                             | IGNITION SYSTEM -- REMOTE               |
| J25TKECA 1998                                             | IGNITION SYSTEM -- TE                   |
| J25TKECA 1998                                             | IGNITION SYSTEM -- TNT                  |
| J25TKEDC 1996                                             | IGNITION SYSTEM - TEL                   |
| J25TKEDC 1996                                             | IGNITION SYSTEM - TNT                   |
| J25TKEDC 1996                                             | IGNITION SYSTEM - REMOTE                |
| J25TKEUR 1997                                             | IGNITION SYSTEM - TE                    |
| J25TKEUR 1997                                             | IGNITION SYSTEM - TNT                   |
| J25TKEUR 1997                                             | IGNITION SYSTEM - REMOTE                |
| J25TKLECA 1998                                            | IGNITION SYSTEM -- REMOTE               |
| J25TKLECA 1998                                            | IGNITION SYSTEM -- TE                   |
| J25TKLECA 1998                                            | IGNITION SYSTEM -- TNT                  |
| J25TKLEDC 1996                                            | IGNITION SYSTEM - TEL                   |
| J25TKLEDC 1996                                            | IGNITION SYSTEM - TNT                   |
| J25TKLEDC 1996                                            | IGNITION SYSTEM - REMOTE                |
| J25TKLEUR 1997                                            | IGNITION SYSTEM - TE                    |
| J25TKLEUR 1997                                            | IGNITION SYSTEM - TNT                   |
| J25TKLEUR 1997                                            | IGNITION SYSTEM - REMOTE                |
| J25TVL3SIE elec start, tiller, 20 in shaft, wht 2001      | IGNITION SYSTEM - K - E - EL - EV - EVL |
| J25TVL3SIE elec start, tiller, 20 in shaft, wht 2001      | IGNITION SYSTEM - PL - VL               |
| J25TVL3SIE elec start, tiller, 20 in shaft, wht 2001      | IGNITION SYSTEM - TEL - TVL             |
| J25VL3SIE elec start, TNT, 20 in shaft, wht, n/a usa 2001 | IGNITION SYSTEM - K - E - EL - EV - EVL |
| J25VL3SIE elec start, TNT, 20 in shaft, wht, n/a usa 2001 | IGNITION SYSTEM - PL - VL               |
| J25VL3SIE elec start, TNT, 20 in shaft, wht, n/a usa 2001 | IGNITION SYSTEM - TEL - TVL             |
| J28ESLEDR 1996                                            | BATTERY CABLE                           |
| J28ESLEDR 1996                                            | ELECTRIC STARTER & SOLENOID             |
| J28ESLENE 1992                                            | ELECTRIC STARTER & SOLENOID             |

|                |                             |
|----------------|-----------------------------|
| J28ESLEOC 1995 | BATTERY CABLE               |
| J28ESLEOC 1995 | ELECTRIC STARTER & SOLENOID |
| J28ESLERS 1994 | BATTERY CABLES              |
| J28ESLERS 1994 | ELECTRIC STARTER & SOLENOID |
| J28ESLETD 1993 | BATTERY CABLES              |
| J28ESLETD 1993 | ELECTRIC STARTER & SOLENOID |
| J30EECS 1998   | BATTERY CABLE               |
| J30EECS 1998   | ELECTRIC STARTER & SOLENOID |
| J30EEDE 1996   | BATTERY CABLE               |
| J30EEDE 1996   | ELECTRIC STARTER & SOLENOID |
| J30EEEC 1999   | BATTERY CABLE               |
| J30EEEC 1999   | ELECTRIC STARTER & SOLENOID |
| J30EEEN 1999   | BATTERY CABLE               |
| J30EEEN 1999   | ELECTRIC STARTER & SOLENOID |
| J30EENR 1992   | ELECTRIC STARTER & SOLENOID |
| J30EEOB 1995   | BATTERY CABLE               |
| J30EEOB 1995   | ELECTRIC STARTER & SOLENOID |
| J30EERM 1994   | BATTERY CABLES              |
| J30EERM 1994   | ELECTRIC STARTER & SOLENOID |
| J30EETA 1993   | BATTERY CABLES              |
| J30EETA 1993   | ELECTRIC STARTER & SOLENOID |
| J30EEUD 1997   | BATTERY CABLE               |
| J30EEUD 1997   | ELECTRIC STARTER & SOLENOID |
| J30ELECS 1998  | BATTERY CABLE               |
| J30ELECS 1998  | ELECTRIC STARTER & SOLENOID |
| J30ELEDE 1996  | BATTERY CABLE               |
| J30ELEDE 1996  | ELECTRIC STARTER & SOLENOID |
| J30ELEEC 1999  | BATTERY CABLE               |
| J30ELEEC 1999  | ELECTRIC STARTER & SOLENOID |
| J30ELEEN 1999  | BATTERY CABLE               |
| J30ELEEN 1999  | ELECTRIC STARTER & SOLENOID |
| J30ELENR 1992  | ELECTRIC STARTER & SOLENOID |
| J30ELEOB 1995  | BATTERY CABLE               |
| J30ELEOB 1995  | ELECTRIC STARTER & SOLENOID |
| J30ELERM 1994  | BATTERY CABLES              |

|                                                                       |                             |
|-----------------------------------------------------------------------|-----------------------------|
| J30ELERM 1994                                                         | ELECTRIC STARTER & SOLENOID |
| J30ELET 1993                                                          | BATTERY CABLES              |
| J30ELET 1993                                                          | ELECTRIC STARTER & SOLENOID |
| J30ELEUD 1997                                                         | BATTERY CABLE               |
| J30ELEUD 1997                                                         | ELECTRIC STARTER & SOLENOID |
| J30ELSIA elec start, remote, 20 in shaft 2001                         | BATTERY CABLE               |
| J30ELSIA elec start, remote, 20 in shaft 2001                         | ELECTRIC STARTER & SOLENOID |
| J30ELSNF - FR                                                         | 22-8_CÂBLE DE BATTERIE      |
| J30ELSNF Electric start, Carb, White, Remote, 20 in., 4 Amp Alt, 2002 | BATTERY CABLE               |
| J30ELSOD                                                              | BATTERY CABLE               |
| J30ELSOD - FR                                                         | 22-8_CÂBLE DE BATTERIE      |
| J30ELSRE                                                              | BATTERY CABLE               |
| J30ELSRE - FR                                                         | 22-8_CÂBLE DE BATTERIE      |
| J30ELSSR Elec. Start, 20 IN. shaft 2000                               | BATTERY CABLE               |
| J30ELSSR Elec. Start, 20 IN. shaft 2000                               | ELECTRIC STARTER & SOLENOID |
| J30ELSTB                                                              | BATTERY CABLE               |
| J30ELSTB - FR                                                         | 22-8_CÂBLE DE BATTERIE      |
| J30ESIA elec start, remote, 15 in shaft 2001                          | BATTERY CABLE               |
| J30ESIA elec start, remote, 15 in shaft 2001                          | ELECTRIC STARTER & SOLENOID |
| J30ESSR Elec. Start, 15 IN. shaft 2000                                | BATTERY CABLE               |
| J30ESSR Elec. Start, 15 IN. shaft 2000                                | ELECTRIC STARTER & SOLENOID |
| J30EVLSIA elec start, remote, 20 in shaft, wht 2001                   | BATTERY CABLE               |
| J30EVLSIA elec start, remote, 20 in shaft, wht 2001                   | ELECTRIC STARTER & SOLENOID |
| J30TEECS 1998                                                         | ELECTRIC STARTER & SOLENOID |
| J30TEEDE 1996                                                         | ELECTRIC STARTER & SOLENOID |
| J30TEEOB 1995                                                         | ELECTRIC STARTER & SOLENOID |
| J30TEERM 1994                                                         | ELECTRIC STARTER & SOLENOID |
| J30TEEUD 1997                                                         | ELECTRIC STARTER & SOLENOID |
| J30TELECS 1998                                                        | ELECTRIC STARTER & SOLENOID |
| J30TELEDE 1996                                                        | ELECTRIC STARTER & SOLENOID |
| J30TELEOB 1995                                                        | ELECTRIC STARTER & SOLENOID |
| J30TELERM 1994                                                        | ELECTRIC STARTER & SOLENOID |
| J30TELEUD 1997                                                        | ELECTRIC STARTER & SOLENOID |
| J35E3EEM 1999                                                         | IGNITION SYSTEM -- E, EL    |

|                                                      |                                         |
|------------------------------------------------------|-----------------------------------------|
| J35E3EEM 1999                                        | IGNITION SYSTEM -- PL                   |
| J35E3EEM 1999                                        | IGNITION SYSTEM -- TEL                  |
| J35EL3EEM 1999                                       | IGNITION SYSTEM -- E, EL                |
| J35EL3EEM 1999                                       | IGNITION SYSTEM -- PL                   |
| J35EL3EEM 1999                                       | IGNITION SYSTEM -- TEL                  |
| J35KLECA 1998                                        | IGNITION SYSTEM -- REMOTE               |
| J35KLECA 1998                                        | IGNITION SYSTEM -- TE                   |
| J35KLECA 1998                                        | IGNITION SYSTEM -- TNT                  |
| J35KLEDC 1996                                        | IGNITION SYSTEM - TEL                   |
| J35KLEDC 1996                                        | IGNITION SYSTEM - TNT                   |
| J35KLEDC 1996                                        | IGNITION SYSTEM - REMOTE                |
| J35KLEUR 1997                                        | IGNITION SYSTEM - TE                    |
| J35KLEUR 1997                                        | IGNITION SYSTEM - TNT                   |
| J35KLEUR 1997                                        | IGNITION SYSTEM - REMOTE                |
| J35PL3EEM 1999                                       | IGNITION SYSTEM -- E, EL                |
| J35PL3EEM 1999                                       | IGNITION SYSTEM -- PL                   |
| J35PL3EEM 1999                                       | IGNITION SYSTEM -- TEL                  |
| J35PL3SIE elec start, TNT, 20 in shaft 2001          | IGNITION SYSTEM - K - E - EL - EV - EVL |
| J35PL3SIE elec start, TNT, 20 in shaft 2001          | IGNITION SYSTEM - PL - VL               |
| J35PL3SIE elec start, TNT, 20 in shaft 2001          | IGNITION SYSTEM - TEL - TVL             |
| J35PL3SSB 3 Cyl, Elec. Start, TNT, 20 IN. shaft 2000 | IGNITION SYSTEM - K, E, EL              |
| J35PL3SSB 3 Cyl, Elec. Start, TNT, 20 IN. shaft 2000 | IGNITION SYSTEM - PL                    |
| J35PL3SSB 3 Cyl, Elec. Start, TNT, 20 IN. shaft 2000 | IGNITION SYSTEM - TEL                   |
| J35QLECA 1998                                        | IGNITION SYSTEM -- REMOTE               |
| J35QLECA 1998                                        | IGNITION SYSTEM -- TE                   |
| J35QLECA 1998                                        | IGNITION SYSTEM -- TNT                  |
| J35QLEDC 1996                                        | IGNITION SYSTEM - TEL                   |
| J35QLEDC 1996                                        | IGNITION SYSTEM - TNT                   |
| J35QLEDC 1996                                        | IGNITION SYSTEM - REMOTE                |
| J35QLEUR 1997                                        | IGNITION SYSTEM - TE                    |
| J35QLEUR 1997                                        | IGNITION SYSTEM - TNT                   |
| J35QLEUR 1997                                        | IGNITION SYSTEM - REMOTE                |
| J35R3EEM 1999                                        | IGNITION SYSTEM -- E, EL                |
| J35R3EEM 1999                                        | IGNITION SYSTEM -- PL                   |
| J35R3EEM 1999                                        | IGNITION SYSTEM -- TEL                  |



|                                                               |                                         |
|---------------------------------------------------------------|-----------------------------------------|
| J35R3SIE rope start, tiller, 15 in shaft 2001                 | IGNITION SYSTEM - K - E - EL - EV - EVL |
| J35R3SIE rope start, tiller, 15 in shaft 2001                 | IGNITION SYSTEM - PL - VL               |
| J35R3SIE rope start, tiller, 15 in shaft 2001                 | IGNITION SYSTEM - TEL - TVL             |
| J35R3SSB 3 Cyl, Rope Start, Tiller, 15 IN. shaft 2000         | IGNITION SYSTEM - K, E, EL              |
| J35R3SSB 3 Cyl, Rope Start, Tiller, 15 IN. shaft 2000         | IGNITION SYSTEM - PL                    |
| J35R3SSB 3 Cyl, Rope Start, Tiller, 15 IN. shaft 2000         | IGNITION SYSTEM - TEL                   |
| J35RL3EEM 1999                                                | IGNITION SYSTEM -- E, EL                |
| J35RL3EEM 1999                                                | IGNITION SYSTEM -- PL                   |
| J35RL3EEM 1999                                                | IGNITION SYSTEM -- TEL                  |
| J35RL3SIE rope start, tiller, 20 in shaft 2001                | IGNITION SYSTEM - K - E - EL - EV - EVL |
| J35RL3SIE rope start, tiller, 20 in shaft 2001                | IGNITION SYSTEM - PL - VL               |
| J35RL3SIE rope start, tiller, 20 in shaft 2001                | IGNITION SYSTEM - TEL - TVL             |
| J35RL3SSB 3 Cyl, Rope Start, Tiller, 20 IN. shaft 2000        | IGNITION SYSTEM - K, E, EL              |
| J35RL3SSB 3 Cyl, Rope Start, Tiller, 20 IN. shaft 2000        | IGNITION SYSTEM - PL                    |
| J35RL3SSB 3 Cyl, Rope Start, Tiller, 20 IN. shaft 2000        | IGNITION SYSTEM - TEL                   |
| J35RMLEDC 1996                                                | IGNITION SYSTEM - TEL                   |
| J35RMLEDC 1996                                                | IGNITION SYSTEM - TNT                   |
| J35RMLEDC 1996                                                | IGNITION SYSTEM - REMOTE                |
| J35RMLEUR 1997                                                | IGNITION SYSTEM - TE                    |
| J35RMLEUR 1997                                                | IGNITION SYSTEM - TNT                   |
| J35RMLEUR 1997                                                | IGNITION SYSTEM - REMOTE                |
| J35RV3SIE rope start, 15 in shaft, wht 2001                   | IGNITION SYSTEM - K - E - EL - EV - EVL |
| J35RV3SIE rope start, 15 in shaft, wht 2001                   | IGNITION SYSTEM - PL - VL               |
| J35RV3SIE rope start, 15 in shaft, wht 2001                   | IGNITION SYSTEM - TEL - TVL             |
| J35RVL3SIE rope start, 20 in shaft, wht 2001                  | IGNITION SYSTEM - K - E - EL - EV - EVL |
| J35RVL3SIE rope start, 20 in shaft, wht 2001                  | IGNITION SYSTEM - PL - VL               |
| J35RVL3SIE rope start, 20 in shaft, wht 2001                  | IGNITION SYSTEM - TEL - TVL             |
| J35TEL3EEM 1999                                               | IGNITION SYSTEM -- E, EL                |
| J35TEL3EEM 1999                                               | IGNITION SYSTEM -- PL                   |
| J35TEL3EEM 1999                                               | IGNITION SYSTEM -- TEL                  |
| J35TEL3SIE elec start, TNT, 20 in shaft 2001                  | IGNITION SYSTEM - K - E - EL - EV - EVL |
| J35TEL3SIE elec start, TNT, 20 in shaft 2001                  | IGNITION SYSTEM - PL - VL               |
| J35TEL3SIE elec start, TNT, 20 in shaft 2001                  | IGNITION SYSTEM - TEL - TVL             |
| J35TEL3SSB 3 Cyl, Elec. Start, TNT, Tiller, 20 IN. shaft 2000 | IGNITION SYSTEM - K, E, EL              |
| J35TEL3SSB 3 Cyl, Elec. Start, TNT, Tiller, 20 IN. shaft 2000 | IGNITION SYSTEM - PL                    |

|                                                               |                                                           |
|---------------------------------------------------------------|-----------------------------------------------------------|
| J35TEL3SSB 3 Cyl, Elec. Start, TNT, Tiller, 20 IN. shaft 2000 | IGNITION SYSTEM - TEL                                     |
| J35TKLECA 1998                                                | IGNITION SYSTEM -- REMOTE                                 |
| J35TKLECA 1998                                                | IGNITION SYSTEM -- TE                                     |
| J35TKLECA 1998                                                | IGNITION SYSTEM -- TNT                                    |
| J35TKLEDC 1996                                                | IGNITION SYSTEM - TEL                                     |
| J35TKLEDC 1996                                                | IGNITION SYSTEM - TNT                                     |
| J35TKLEDC 1996                                                | IGNITION SYSTEM - REMOTE                                  |
| J35TKLEUR 1997                                                | IGNITION SYSTEM - TE                                      |
| J35TKLEUR 1997                                                | IGNITION SYSTEM - TNT                                     |
| J35TKLEUR 1997                                                | IGNITION SYSTEM - REMOTE                                  |
| J35TVL3SIE elec start, tiller, 20 in shaft, wht 2001          | IGNITION SYSTEM - K - E - EL - EV - EVL                   |
| J35TVL3SIE elec start, tiller, 20 in shaft, wht 2001          | IGNITION SYSTEM - PL - VL                                 |
| J35TVL3SIE elec start, tiller, 20 in shaft, wht 2001          | IGNITION SYSTEM - TEL - TVL                               |
| J35VL3SIE elec start, TNT, 20 in shaft, wht 2001              | IGNITION SYSTEM - K - E - EL - EV - EVL                   |
| J35VL3SIE elec start, TNT, 20 in shaft, wht 2001              | IGNITION SYSTEM - PL - VL                                 |
| J35VL3SIE elec start, TNT, 20 in shaft, wht 2001              | IGNITION SYSTEM - TEL - TVL                               |
| J40EEIA 1991                                                  | ELECTRIC STARTER & SOLENOID                               |
| J40EENJ 1992                                                  | ELECTRIC STARTER & SOLENOID                               |
| J40EENJ 1992                                                  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| J40EENJ 1992                                                  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |
| J40EENJ 1992                                                  | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |
| J40EENJ 1992                                                  | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |
| J40EENM 1992                                                  | ELECTRIC STARTER & SOLENOID                               |
| J40EENM 1992                                                  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| J40EENM 1992                                                  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |
| J40EENM 1992                                                  | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |
| J40EENM 1992                                                  | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |
| J40EEOD 1995                                                  | ELECTRIC STARTER & SOLENOID                               |
| J40EEOD 1995                                                  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS   |
| J40EEOD 1995                                                  | IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS      |

|               |                                                            |
|---------------|------------------------------------------------------------|
| J40EERE 1994  | ELECTRIC STARTER & SOLENOID                                |
| J40EERE 1994  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| J40EERE 1994  | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS    |
| J40EETB 1993  | ELECTRIC STARTER & SOLENOID                                |
| J40EETB 1993  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| J40EETB 1993  | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS    |
| J40EETB 1993  | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY        |
| J40ELECR 1998 | ELECTRIC STARTER & SOLENOID                                |
| J40ELECR 1998 | IGNITION SYSTEM -- 40-50 ELECTRIC START                    |
| J40ELEDs 1996 | ELECTRIC STARTER & SOLENOID                                |
| J40ELEDs 1996 | IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS |
| J40ELEDs 1996 | IGNITION SYSTEM - ELECTRIC START 40TE MODELS               |
| J40ELEIA 1991 | ELECTRIC STARTER & SOLENOID                                |
| J40ELENJ 1992 | ELECTRIC STARTER & SOLENOID                                |
| J40ELENJ 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)  |
| J40ELENJ 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)  |
| J40ELENJ 1992 | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)  |
| J40ELENJ 1992 | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)  |
| J40ELENM 1992 | ELECTRIC STARTER & SOLENOID                                |
| J40ELENM 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)  |
| J40ELENM 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)  |
| J40ELENM 1992 | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)  |
| J40ELENM 1992 | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)  |
| J40ELEOD 1995 | ELECTRIC STARTER & SOLENOID                                |
| J40ELEOD 1995 | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| J40ELEOD 1995 | IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS       |
| J40ELERE 1994 | ELECTRIC STARTER & SOLENOID                                |

|                                                                |                                                         |
|----------------------------------------------------------------|---------------------------------------------------------|
| J40ELERE 1994                                                  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS |
| J40ELERE 1994                                                  | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS |
| J40ELETB 1993                                                  | ELECTRIC STARTER & SOLENOID                             |
| J40ELETB 1993                                                  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS |
| J40ELETB 1993                                                  | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS |
| J40ELETB 1993                                                  | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY     |
| J40ELEUC 1997                                                  | ELECTRIC STARTER & SOLENOID                             |
| J40ELEUC 1997                                                  | IGNITION SYSTEM - 40-50 ELECTRIC START                  |
| J40JPLEEC 1999                                                 | ELECTRIC STARTER                                        |
| J40JPLEEC 1999                                                 | BATTERY CABLE                                           |
| J40JPLSIA jet drive,elec start, TNT, 20 in shaft 2001          | ELECTRIC STARTER                                        |
| J40JPLSIA jet drive,elec start, TNT, 20 in shaft 2001          | BATTERY CABLE                                           |
| J40JPLSSR Jet Drive, Elec Start, TNT, 20 IN. shaft 2000        | ELECTRIC STARTER                                        |
| J40JPLSSR Jet Drive, Elec Start, TNT, 20 IN. shaft 2000        | BATTERY CABLE                                           |
| J40JVLZIA jet drive,elec start, TNT, 20 in shaft, wht 2001     | ELECTRIC STARTER                                        |
| J40JVLZIA jet drive,elec start, TNT, 20 in shaft, wht 2001     | BATTERY CABLE                                           |
| J40PLEEA 1999                                                  | IGNITION SYSTEM -- ELECTRIC START                       |
| J40PLEEA 1999                                                  | ELECTRIC STARTER & SOLENOID                             |
| J40PLSIF elec start, TNT, 20 in shaft 2001                     | IGNITION SYSTEM - ELECTRIC START                        |
| J40PLSIF elec start, TNT, 20 in shaft 2001                     | ELECTRIC STARTER & SOLENOID                             |
| J40PLSNF - FR                                                  | 22-4_ÉLÉMENTS ÉLECTRIQUES                               |
| J40PLSNF - FR                                                  | 22-1_MOTEUR DE DÉMARREUR                                |
| J40PLSNF Oil Injection, 20 in., White, Remote, Elec, TNT, 2002 | ELECTRICAL / IGNITION SYSTEM                            |
| J40PLSNF Oil Injection, 20 in., White, Remote, Elec, TNT, 2002 | STARTER MOTOR                                           |
| J40PLSOC                                                       | ELECTRICAL / IGNITION SYSTEM                            |
| J40PLSOC                                                       | STARTER MOTOR                                           |
| J40PLSOC - FR                                                  | 22-5_SYSTÈME D'ALLUMAGE                                 |
| J40PLSOC - FR                                                  | 22-1_MOTEUR DE DÉMARREUR                                |
| J40PLSRS                                                       | ELECTRICAL / IGNITION SYSTEM                            |
| J40PLSRS                                                       | STARTER MOTOR                                           |
| J40PLSRS - FR                                                  | 22-4_ÉLÉMENTS ÉLECTRIQUES                               |
| J40PLSRS - FR                                                  | 22-1_MOTEUR DE DÉMARREUR                                |
| J40PLSSM Elec. Start, TNT, 20 IN. shaft 2000                   | IGNITION SYSTEM - ELECTRIC START                        |

|                                              |                                                            |
|----------------------------------------------|------------------------------------------------------------|
| J40PLSSM Elec. Start, TNT, 20 IN. shaft 2000 | ELECTRIC STARTER & SOLENOID                                |
| J40PLSTD                                     | ELECTRICAL / IGNITION SYSTEM                               |
| J40PLSTD                                     | STARTER MOTOR                                              |
| J40PLSTD - FR                                | 22-4_ÉLÉMENTS ÉLECTRIQUES                                  |
| J40PLSTD - FR                                | 22-1_MOTEUR DE DÉMARREUR                                   |
| J40RECR 1998                                 | ELECTRIC STARTER & SOLENOID                                |
| J40RECR 1998                                 | IGNITION SYSTEM -- 40-50 ELECTRIC START                    |
| J40REDS 1996                                 | ELECTRIC STARTER & SOLENOID                                |
| J40REDS 1996                                 | IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS |
| J40REDS 1996                                 | IGNITION SYSTEM - ELECTRIC START 40TE MODELS               |
| J40REEA 1999                                 | IGNITION SYSTEM -- ELECTRIC START                          |
| J40REEA 1999                                 | ELECTRIC STARTER & SOLENOID                                |
| J40REIA 1991                                 | ELECTRIC STARTER & SOLENOID                                |
| J40RENM 1992                                 | ELECTRIC STARTER & SOLENOID                                |
| J40RENM 1992                                 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)  |
| J40RENM 1992                                 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)  |
| J40RENM 1992                                 | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)  |
| J40RENM 1992                                 | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)  |
| J40REOD 1995                                 | ELECTRIC STARTER & SOLENOID                                |
| J40REOD 1995                                 | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| J40REOD 1995                                 | IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS       |
| J40RERE 1994                                 | ELECTRIC STARTER & SOLENOID                                |
| J40RERE 1994                                 | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| J40RERE 1994                                 | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS    |
| J40RETB 1993                                 | ELECTRIC STARTER & SOLENOID                                |
| J40RETB 1993                                 | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| J40RETB 1993                                 | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS    |
| J40RETB 1993                                 | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY        |
| J40REUC 1997                                 | ELECTRIC STARTER & SOLENOID                                |

|                                                |                                                            |
|------------------------------------------------|------------------------------------------------------------|
| J40REUC 1997                                   | IGNITION SYSTEM - 40-50 ELECTRIC START                     |
| J40RLECR 1998                                  | ELECTRIC STARTER & SOLENOID                                |
| J40RLECR 1998                                  | IGNITION SYSTEM -- 40-50 ELECTRIC START                    |
| J40RLEDS 1996                                  | ELECTRIC STARTER & SOLENOID                                |
| J40RLEDS 1996                                  | IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS |
| J40RLEDS 1996                                  | IGNITION SYSTEM - ELECTRIC START 40TE MODELS               |
| J40RLEEA 1999                                  | IGNITION SYSTEM -- ELECTRIC START                          |
| J40RLEEA 1999                                  | ELECTRIC STARTER & SOLENOID                                |
| J40RLEIA 1991                                  | ELECTRIC STARTER & SOLENOID                                |
| J40RLENM 1992                                  | ELECTRIC STARTER & SOLENOID                                |
| J40RLENM 1992                                  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)  |
| J40RLENM 1992                                  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)  |
| J40RLENM 1992                                  | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)  |
| J40RLENM 1992                                  | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)  |
| J40RLEOD 1995                                  | ELECTRIC STARTER & SOLENOID                                |
| J40RLEOD 1995                                  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| J40RLEOD 1995                                  | IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS       |
| J40RLERE 1994                                  | ELECTRIC STARTER & SOLENOID                                |
| J40RLERE 1994                                  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| J40RLERE 1994                                  | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS    |
| J40RLETB 1993                                  | ELECTRIC STARTER & SOLENOID                                |
| J40RLETB 1993                                  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| J40RLETB 1993                                  | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS    |
| J40RLETB 1993                                  | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY        |
| J40REUC 1997                                   | ELECTRIC STARTER & SOLENOID                                |
| J40REUC 1997                                   | IGNITION SYSTEM - 40-50 ELECTRIC START                     |
| J40RLSIF rope start, 20 in shaft 2001          | IGNITION SYSTEM - ELECTRIC START                           |
| J40RLSIF rope start, 20 in shaft 2001          | ELECTRIC STARTER & SOLENOID                                |
| J40RLSSM Rope Start, Tiller, 20 IN. shaft 2000 | IGNITION SYSTEM - ELECTRIC START                           |

|                                                |                                                            |
|------------------------------------------------|------------------------------------------------------------|
| J40RLSSM Rope Start, Tiller, 20 IN. shaft 2000 | ELECTRIC STARTER & SOLENOID                                |
| J40RSIF rope start, 15 in shaft 2001           | IGNITION SYSTEM - ELECTRIC START                           |
| J40RSIF rope start, 15 in shaft 2001           | ELECTRIC STARTER & SOLENOID                                |
| J40RSSM Rope Start, Tiller, 15 IN. shaft 2000  | IGNITION SYSTEM - ELECTRIC START                           |
| J40RSSM Rope Start, Tiller, 15 IN. shaft 2000  | ELECTRIC STARTER & SOLENOID                                |
| J40TEECR 1998                                  | ELECTRIC STARTER & SOLENOID                                |
| J40TEECR 1998                                  | IGNITION SYSTEM -- 40-50 ELECTRIC START                    |
| J40TEEDS 1996                                  | ELECTRIC STARTER & SOLENOID                                |
| J40TEEDS 1996                                  | IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS |
| J40TEEDS 1996                                  | IGNITION SYSTEM - ELECTRIC START 40TE MODELS               |
| J40TEEIA 1991                                  | ELECTRIC STARTER & SOLENOID                                |
| J40TEENJ 1992                                  | ELECTRIC STARTER & SOLENOID                                |
| J40TEENJ 1992                                  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)  |
| J40TEENJ 1992                                  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)  |
| J40TEENJ 1992                                  | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)  |
| J40TEENJ 1992                                  | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)  |
| J40TEENM 1992                                  | ELECTRIC STARTER & SOLENOID                                |
| J40TEENM 1992                                  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)  |
| J40TEENM 1992                                  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)  |
| J40TEENM 1992                                  | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)  |
| J40TEENM 1992                                  | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)  |
| J40TEEOD 1995                                  | ELECTRIC STARTER & SOLENOID                                |
| J40TEEOD 1995                                  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| J40TEEOD 1995                                  | IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS       |
| J40TEERE 1994                                  | ELECTRIC STARTER & SOLENOID                                |
| J40TEERE 1994                                  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| J40TEERE 1994                                  | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS    |
| J40TEETB 1993                                  | ELECTRIC STARTER & SOLENOID                                |
| J40TEETB 1993                                  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |

|                |                                                            |
|----------------|------------------------------------------------------------|
| J40TEETB 1993  | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS    |
| J40TEETB 1993  | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY        |
| J40TEEUC 1997  | ELECTRIC STARTER & SOLENOID                                |
| J40TEEUC 1997  | IGNITION SYSTEM - 40-50 ELECTRIC START                     |
| J40TELECR 1998 | ELECTRIC STARTER & SOLENOID                                |
| J40TELECR 1998 | IGNITION SYSTEM -- 40-50 ELECTRIC START                    |
| J40TELEDS 1996 | ELECTRIC STARTER & SOLENOID                                |
| J40TELEDS 1996 | IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS |
| J40TELEDS 1996 | IGNITION SYSTEM - ELECTRIC START 40TE MODELS               |
| J40TELEIA 1991 | ELECTRIC STARTER & SOLENOID                                |
| J40TELENJ 1992 | ELECTRIC STARTER & SOLENOID                                |
| J40TELENJ 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)  |
| J40TELENJ 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)  |
| J40TELENJ 1992 | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)  |
| J40TELENJ 1992 | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)  |
| J40TELENM 1992 | ELECTRIC STARTER & SOLENOID                                |
| J40TELENM 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)  |
| J40TELENM 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)  |
| J40TELENM 1992 | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)  |
| J40TELENM 1992 | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)  |
| J40TELEOD 1995 | ELECTRIC STARTER & SOLENOID                                |
| J40TELEOD 1995 | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| J40TELEOD 1995 | IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS       |
| J40TELERE 1994 | ELECTRIC STARTER & SOLENOID                                |
| J40TELERE 1994 | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| J40TELERE 1994 | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS    |
| J40TELETB 1993 | ELECTRIC STARTER & SOLENOID                                |
| J40TELETB 1993 | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |



|                |                                                            |
|----------------|------------------------------------------------------------|
| J40TELETB 1993 | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS    |
| J40TELETB 1993 | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY        |
| J40TELEUC 1997 | ELECTRIC STARTER & SOLENOID                                |
| J40TELEUC 1997 | IGNITION SYSTEM - 40-50 ELECTRIC START                     |
| J40TLECR 1998  | ELECTRIC STARTER & SOLENOID                                |
| J40TLECR 1998  | IGNITION SYSTEM -- 40-50 ELECTRIC START                    |
| J40TLEDS 1996  | ELECTRIC STARTER & SOLENOID                                |
| J40TLEDS 1996  | IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS |
| J40TLEDS 1996  | IGNITION SYSTEM - ELECTRIC START 40TE MODELS               |
| J40TLEIA 1991  | ELECTRIC STARTER & SOLENOID                                |
| J40TLENJ 1992  | ELECTRIC STARTER & SOLENOID                                |
| J40TLENJ 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)  |
| J40TLENJ 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)  |
| J40TLENJ 1992  | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)  |
| J40TLENJ 1992  | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)  |
| J40TLENM 1992  | ELECTRIC STARTER & SOLENOID                                |
| J40TLENM 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)  |
| J40TLENM 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)  |
| J40TLENM 1992  | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)  |
| J40TLENM 1992  | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)  |
| J40TLEOD 1995  | ELECTRIC STARTER & SOLENOID                                |
| J40TLEOD 1995  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| J40TLEOD 1995  | IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS       |
| J40TLERE 1994  | ELECTRIC STARTER & SOLENOID                                |
| J40TLERE 1994  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| J40TLERE 1994  | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS    |
| J40TLETB 1993  | ELECTRIC STARTER & SOLENOID                                |
| J40TLETB 1993  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |

|                                                       |                                                            |
|-------------------------------------------------------|------------------------------------------------------------|
| J40TLETB 1993                                         | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS    |
| J40TLETB 1993                                         | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY        |
| J40TLETF 1993                                         | ELECTRIC STARTER & SOLENOID                                |
| J40TLETF 1993                                         | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| J40TLETF 1993                                         | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS    |
| J40TLETF 1993                                         | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY        |
| J40TLEUC 1997                                         | ELECTRIC STARTER & SOLENOID                                |
| J40TLEUC 1997                                         | IGNITION SYSTEM - 40-50 ELECTRIC START                     |
| J40TPLEEA 1999                                        | IGNITION SYSTEM -- ELECTRIC START                          |
| J40TPLEEA 1999                                        | ELECTRIC STARTER & SOLENOID                                |
| J40TPLSIF elec start, tiller, TNT, 20 in shaft 2001   | IGNITION SYSTEM - ELECTRIC START                           |
| J40TPLSIF elec start, tiller, TNT, 20 in shaft 2001   | ELECTRIC STARTER & SOLENOID                                |
| J40TPLSSM Elec. Start, TNT, Tiller, 20 IN. shaft 2000 | IGNITION SYSTEM - ELECTRIC START                           |
| J40TPLSSM Elec. Start, TNT, Tiller, 20 IN. shaft 2000 | ELECTRIC STARTER & SOLENOID                                |
| J40TTLECR 1998                                        | ELECTRIC STARTER & SOLENOID                                |
| J40TTLECR 1998                                        | IGNITION SYSTEM -- 40-50 ELECTRIC START                    |
| J40TTLEDS 1996                                        | ELECTRIC STARTER & SOLENOID                                |
| J40TTLEDS 1996                                        | IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS |
| J40TTLEDS 1996                                        | IGNITION SYSTEM - ELECTRIC START 40TE MODELS               |
| J40TTLEIA 1991                                        | ELECTRIC STARTER & SOLENOID                                |
| J40TTLENM 1992                                        | ELECTRIC STARTER & SOLENOID                                |
| J40TTLENM 1992                                        | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)  |
| J40TTLENM 1992                                        | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)  |
| J40TTLENM 1992                                        | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)  |
| J40TTLENM 1992                                        | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)  |
| J40TTLEOD 1995                                        | ELECTRIC STARTER & SOLENOID                                |
| J40TTLEOD 1995                                        | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| J40TTLEOD 1995                                        | IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS       |
| J40TTLERE 1994                                        | ELECTRIC STARTER & SOLENOID                                |

|                |                                                           |
|----------------|-----------------------------------------------------------|
| J40TTLRE 1994  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS   |
| J40TTLRE 1994  | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS   |
| J40TTLETB 1993 | ELECTRIC STARTER & SOLENOID                               |
| J40TTLETB 1993 | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS   |
| J40TTLETB 1993 | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS   |
| J40TTLETB 1993 | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY       |
| J40TTLETF 1993 | ELECTRIC STARTER & SOLENOID                               |
| J40TTLETF 1993 | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS   |
| J40TTLETF 1993 | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS   |
| J40TTLETF 1993 | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY       |
| J40TTLEUC 1997 | ELECTRIC STARTER & SOLENOID                               |
| J40TTLEUC 1997 | IGNITION SYSTEM - 40-50 ELECTRIC START                    |
| J45RCENM 1992  | REMOTE CONTROL                                            |
| J45RCLENM 1992 | REMOTE CONTROL                                            |
| J45WMLNEM 1992 | REMOTE CONTROL                                            |
| J48ESLEDC 1996 | BATTERY CABLE                                             |
| J48ESLEDC 1996 | ELECTRIC STARTER & SOLENOID                               |
| J48ESLEIM 1991 | ELECTRIC STARTER & SOLENOID                               |
| J48ESLENB 1992 | ELECTRIC STARTER & SOLENOID                               |
| J48ESLEOS 1995 | BATTERY CABLE                                             |
| J48ESLEOS 1995 | ELECTRIC STARTER & SOLENOID                               |
| J48ESLERD 1994 | BATTERY CABLES                                            |
| J48ESLERD 1994 | ELECTRIC STARTER & SOLENOID                               |
| J48ESLETE 1993 | BATTERY CABLES                                            |
| J48ESLETE 1993 | ELECTRIC STARTER & SOLENOID                               |
| J50BEEIA 1991  | ELECTRIC STARTER & SOLENOID                               |
| J50BEENJ 1992  | ELECTRIC STARTER & SOLENOID                               |
| J50BEENJ 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| J50BEENJ 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |
| J50BEENJ 1992  | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |

|                |                                                           |
|----------------|-----------------------------------------------------------|
| J50BEENJ 1992  | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |
| J50BEENM 1992  | ELECTRIC STARTER & SOLENOID                               |
| J50BEENM 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| J50BEENM 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |
| J50BEENM 1992  | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |
| J50BEENM 1992  | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |
| J50BEEOD 1995  | ELECTRIC STARTER & SOLENOID                               |
| J50BEEOD 1995  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS   |
| J50BEEOD 1995  | IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS      |
| J50BEERE 1994  | ELECTRIC STARTER & SOLENOID                               |
| J50BEERE 1994  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS   |
| J50BEERE 1994  | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS   |
| J50BEETB 1993  | ELECTRIC STARTER & SOLENOID                               |
| J50BEETB 1993  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS   |
| J50BEETB 1993  | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS   |
| J50BEETB 1993  | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY       |
| J50BELEIA 1991 | ELECTRIC STARTER & SOLENOID                               |
| J50BELENJ 1992 | ELECTRIC STARTER & SOLENOID                               |
| J50BELENJ 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| J50BELENJ 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |
| J50BELENJ 1992 | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |
| J50BELENJ 1992 | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |
| J50BELENM 1992 | ELECTRIC STARTER & SOLENOID                               |
| J50BELENM 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| J50BELENM 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |
| J50BELENM 1992 | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |

|                                                 |                                                           |
|-------------------------------------------------|-----------------------------------------------------------|
| J50BELENM 1992                                  | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |
| J50BELEOD 1995                                  | ELECTRIC STARTER & SOLENOID                               |
| J50BELEOD 1995                                  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS   |
| J50BELEOD 1995                                  | IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS      |
| J50BELERE 1994                                  | ELECTRIC STARTER & SOLENOID                               |
| J50BELERE 1994                                  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS   |
| J50BELERE 1994                                  | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS   |
| J50BELETB 1993                                  | ELECTRIC STARTER & SOLENOID                               |
| J50BELETB 1993                                  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS   |
| J50BELETB 1993                                  | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS   |
| J50BELETB 1993                                  | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY       |
| J50DTLECA 1998                                  | BATTERY CABLE                                             |
| J50DTLECA 1998                                  | ELECTRIC STARTER                                          |
| J50DTLEDC 1996                                  | BATTERY CABLE                                             |
| J50DTLEDC 1996                                  | ELECTRIC STARTER                                          |
| J50DTLEOS 1995                                  | BATTERY CABLE                                             |
| J50DTLEOS 1995                                  | ELECTRIC STARTER                                          |
| J50DTLEUR 1997                                  | BATTERY CABLE                                             |
| J50DTLEUR 1997                                  | ELECTRIC STARTER                                          |
| J50ELED 1996                                    | BATTERY CABLE                                             |
| J50ELED 1996                                    | ELECTRIC STARTER                                          |
| J50ELEER 1999                                   | IGNITION SYSTEM -- ELECTRIC START                         |
| J50ELEER 1999                                   | ELECTRIC STARTER & SOLENOID                               |
| J50ELEOS 1995                                   | BATTERY CABLE                                             |
| J50ELEOS 1995                                   | ELECTRIC STARTER                                          |
| J50ELEUR 1997                                   | BATTERY CABLE                                             |
| J50ELEUR 1997                                   | ELECTRIC STARTER                                          |
| J50ELSIF elec start, 20 in shaft 2001           | IGNITION SYSTEM - ELECTRIC START                          |
| J50ELSIF elec start, 20 in shaft 2001           | ELECTRIC STARTER & SOLENOID                               |
| J50ELSSA Elec. Start, Tiller, 15 IN. shaft 2000 | IGNITION SYSTEM - ELECTRIC START                          |
| J50ELSSA Elec. Start, Tiller, 15 IN. shaft 2000 | ELECTRIC STARTER & SOLENOID                               |

|                |                                                            |
|----------------|------------------------------------------------------------|
| J50ESLECC 1998 | ELECTRIC STARTER & SOLENOID                                |
| J50ESLECC 1998 | IGNITION SYSTEM -- 40-50 ELECTRIC START                    |
| J50ESLEUR 1997 | ELECTRIC STARTER & SOLENOID                                |
| J50ESLEUR 1997 | IGNITION SYSTEM - 40-50 ELECTRIC START                     |
| J50JEDS 1996   | ELECTRIC STARTER & SOLENOID                                |
| J50JEDS 1996   | IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS |
| J50JEDS 1996   | IGNITION SYSTEM - ELECTRIC START 40TE MODELS               |
| J50JEIA 1991   | ELECTRIC STARTER & SOLENOID                                |
| J50JENJ 1992   | ELECTRIC STARTER & SOLENOID                                |
| J50JENJ 1992   | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)  |
| J50JENJ 1992   | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)  |
| J50JENJ 1992   | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)  |
| J50JENJ 1992   | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)  |
| J50JENM 1992   | ELECTRIC STARTER & SOLENOID                                |
| J50JENM 1992   | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)  |
| J50JENM 1992   | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)  |
| J50JENM 1992   | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)  |
| J50JENM 1992   | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)  |
| J50JEOD 1995   | ELECTRIC STARTER & SOLENOID                                |
| J50JEOD 1995   | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| J50JEOD 1995   | IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS       |
| J50JERE 1994   | ELECTRIC STARTER & SOLENOID                                |
| J50JERE 1994   | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| J50JERE 1994   | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS    |
| J50JETB 1993   | ELECTRIC STARTER & SOLENOID                                |
| J50JETB 1993   | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| J50JETB 1993   | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS    |

|                                                                |                                                           |
|----------------------------------------------------------------|-----------------------------------------------------------|
| J50JETB 1993                                                   | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY       |
| J50JEUC 1997                                                   | ELECTRIC STARTER & SOLENOID                               |
| J50JEUC 1997                                                   | IGNITION SYSTEM - 40-50 ELECTRIC START                    |
| J50PLEEA 1999                                                  | IGNITION SYSTEM -- ELECTRIC START                         |
| J50PLEEA 1999                                                  | ELECTRIC STARTER & SOLENOID                               |
| J50PLSIF elec start, TNT, 20 in shaft 2001                     | IGNITION SYSTEM - ELECTRIC START                          |
| J50PLSIF elec start, TNT, 20 in shaft 2001                     | ELECTRIC STARTER & SOLENOID                               |
| J50PLSNF - FR                                                  | 22-4_ÉLÉMENTS ÉLECTRIQUES                                 |
| J50PLSNF - FR                                                  | 22-1_MOTEUR DE DÉMARREUR                                  |
| J50PLSNF Oil Injection, 20 in., White, Remote, Elec, TNT, 2002 | ELECTRICAL / IGNITION SYSTEM                              |
| J50PLSNF Oil Injection, 20 in., White, Remote, Elec, TNT, 2002 | STARTER MOTOR                                             |
| J50PLSOC                                                       | ELECTRICAL / IGNITION SYSTEM                              |
| J50PLSOC                                                       | STARTER MOTOR                                             |
| J50PLSOC - FR                                                  | 22-5_SYSTÈME D'ALLUMAGE                                   |
| J50PLSOC - FR                                                  | 22-1_MOTEUR DE DÉMARREUR                                  |
| J50PLSRS                                                       | ELECTRICAL / IGNITION SYSTEM                              |
| J50PLSRS                                                       | STARTER MOTOR                                             |
| J50PLSRS - FR                                                  | 22-4_ÉLÉMENTS ÉLECTRIQUES                                 |
| J50PLSRS - FR                                                  | 22-1_MOTEUR DE DÉMARREUR                                  |
| J50PLSSM Elec. Start, TNT, Tiller, 20 IN. shaft 2000           | IGNITION SYSTEM - ELECTRIC START                          |
| J50PLSSM Elec. Start, TNT, Tiller, 20 IN. shaft 2000           | ELECTRIC STARTER & SOLENOID                               |
| J50PLSTD                                                       | ELECTRICAL / IGNITION SYSTEM                              |
| J50PLSTD                                                       | STARTER MOTOR                                             |
| J50PLSTD - FR                                                  | 22-4_ÉLÉMENTS ÉLECTRIQUES                                 |
| J50PLSTD - FR                                                  | 22-1_MOTEUR DE DÉMARREUR                                  |
| J50TELEIA 1991                                                 | ELECTRIC STARTER & SOLENOID                               |
| J50TELENM 1992                                                 | ELECTRIC STARTER & SOLENOID                               |
| J50TELENM 1992                                                 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| J50TELENM 1992                                                 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |
| J50TELENM 1992                                                 | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |
| J50TELENM 1992                                                 | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |
| J50TELEOD 1995                                                 | ELECTRIC STARTER & SOLENOID                               |
| J50TELEOD 1995                                                 | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS   |

|                |                                                            |
|----------------|------------------------------------------------------------|
| J50TELEOD 1995 | IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS       |
| J50TELERE 1994 | ELECTRIC STARTER & SOLENOID                                |
| J50TELERE 1994 | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| J50TELERE 1994 | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS    |
| J50TELETB 1993 | ELECTRIC STARTER & SOLENOID                                |
| J50TELETB 1993 | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| J50TELETB 1993 | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS    |
| J50TELETB 1993 | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY        |
| J50TLECR 1998  | ELECTRIC STARTER & SOLENOID                                |
| J50TLECR 1998  | IGNITION SYSTEM -- 40-50 ELECTRIC START                    |
| J50TLEDS 1996  | ELECTRIC STARTER & SOLENOID                                |
| J50TLEDS 1996  | IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS |
| J50TLEDS 1996  | IGNITION SYSTEM - ELECTRIC START 40TE MODELS               |
| J50TLEIA 1991  | ELECTRIC STARTER & SOLENOID                                |
| J50TLENJ 1992  | ELECTRIC STARTER & SOLENOID                                |
| J50TLENJ 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)  |
| J50TLENJ 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)  |
| J50TLENJ 1992  | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)  |
| J50TLENJ 1992  | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)  |
| J50TLENM 1992  | ELECTRIC STARTER & SOLENOID                                |
| J50TLENM 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)  |
| J50TLENM 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX)  |
| J50TLENM 1992  | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)  |
| J50TLENM 1992  | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX)  |
| J50TLEOD 1995  | ELECTRIC STARTER & SOLENOID                                |
| J50TLEOD 1995  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS    |
| J50TLEOD 1995  | IGNITION SYSTEM - ELECTRIC START 40TE - 40TTL MODELS       |



|                |                                                         |
|----------------|---------------------------------------------------------|
| J50TLERE 1994  | ELECTRIC STARTER & SOLENOID                             |
| J50TLERE 1994  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS |
| J50TLERE 1994  | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS |
| J50TLETB 1993  | ELECTRIC STARTER & SOLENOID                             |
| J50TLETB 1993  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS |
| J50TLETB 1993  | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS |
| J50TLETB 1993  | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY     |
| J50TLETF 1993  | ELECTRIC STARTER & SOLENOID                             |
| J50TLETF 1993  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS |
| J50TLETF 1993  | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS |
| J50TLETF 1993  | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY     |
| J50TLEUC 1997  | ELECTRIC STARTER & SOLENOID                             |
| J50TLEUC 1997  | IGNITION SYSTEM - 40-50 ELECTRIC START                  |
| J50TSLECC 1998 | ELECTRIC STARTER & SOLENOID                             |
| J50TSLECC 1998 | IGNITION SYSTEM -- 40-50 ELECTRIC START                 |
| J50TSLEUS 1997 | ELECTRIC STARTER & SOLENOID                             |
| J50TSLEUS 1997 | IGNITION SYSTEM - 40-50 ELECTRIC START                  |
| J50TTLECA 1998 | ELECTRIC STARTER                                        |
| J50TTLECA 1998 | IGNITION SYSTEM                                         |
| J50TTLEDC 1996 | ELECTRIC STARTER                                        |
| J50TTLEDC 1996 | IGNITION SYSTEM                                         |
| J50TTLEOS 1995 | ELECTRIC STARTER                                        |
| J50TTLEOS 1995 | IGNITION SYSTEM                                         |
| J50TTLEUR 1997 | ELECTRIC STARTER                                        |
| J50TTLEUR 1997 | IGNITION SYSTEM                                         |
| J55RWLENM 1992 | REMOTE CONTROL                                          |
| J60ELEDR 1996  | BATTERY CABLE                                           |
| J60ELEDR 1996  | ELECTRIC STARTER                                        |
| J60ELENE 1992  | ELECTRIC STARTER                                        |
| J60ELEOC 1995  | BATTERY CABLE                                           |
| J60ELEOC 1995  | ELECTRIC STARTER                                        |

|                                             |                  |
|---------------------------------------------|------------------|
| J60ELERS 1994                               | BATTERY CABLES   |
| J60ELERS 1994                               | ELECTRIC STARTER |
| J60ELERV 1994                               | BATTERY CABLES   |
| J60ELERV 1994                               | ELECTRIC STARTER |
| J60ELETD 1993                               | BATTERY CABLES   |
| J60ELETD 1993                               | ELECTRIC STARTER |
| J60ELEUA 1997                               | BATTERY CABLE    |
| J60ELEUA 1997                               | ELECTRIC STARTER |
| J60PLEEB 1999                               | ELECTRIC STARTER |
| J60PLEEB 1999                               | BATTERY CABLE    |
| J60PLSID elec start, TNT, 20 in shaft 2001  | ELECTRIC STARTER |
| J60PLSID elec start, TNT, 20 in shaft 2001  | BATTERY CABLE    |
| J60PLSSE Elec Start, TNT, 20 IN. shaft 2000 | ELECTRIC STARTER |
| J60PLSSE Elec Start, TNT, 20 IN. shaft 2000 | BATTERY CABLE    |
| J60TLECM 1998                               | BATTERY CABLE    |
| J60TLECM 1998                               | ELECTRIC STARTER |
| J60TLEDR 1996                               | BATTERY CABLE    |
| J60TLEDR 1996                               | ELECTRIC STARTER |
| J60TLENE 1992                               | ELECTRIC STARTER |
| J60TLEOC 1995                               | BATTERY CABLE    |
| J60TLEOC 1995                               | ELECTRIC STARTER |
| J60TLERS 1994                               | BATTERY CABLES   |
| J60TLERS 1994                               | ELECTRIC STARTER |
| J60TLERV 1994                               | BATTERY CABLES   |
| J60TLERV 1994                               | ELECTRIC STARTER |
| J60TLETD 1993                               | BATTERY CABLES   |
| J60TLETD 1993                               | ELECTRIC STARTER |
| J60TLEUA 1997                               | BATTERY CABLE    |
| J60TLEUA 1997                               | ELECTRIC STARTER |
| J60TTLECM 1998                              | ELECTRIC STARTER |
| J60TTLECM 1998                              | IGNITION SYSTEM  |
| J60TTLEDR 1996                              | ELECTRIC STARTER |
| J60TTLEDR 1996                              | IGNITION SYSTEM  |
| J60TTLENE 1992                              | ELECTRIC STARTER |
| J60TTLEOC 1995                              | ELECTRIC STARTER |

|                                                      |                  |
|------------------------------------------------------|------------------|
| J60TTLEOC 1995                                       | IGNITION SYSTEM  |
| J60TTLERS 1994                                       | ELECTRIC STARTER |
| J60TTLERS 1994                                       | IGNITION SYSTEM  |
| J60TTLERV 1994                                       | ELECTRIC STARTER |
| J60TTLERV 1994                                       | IGNITION SYSTEM  |
| J60TTLETD 1993                                       | ELECTRIC STARTER |
| J60TTLETD 1993                                       | IGNITION SYSTEM  |
| J60TTLEUA 1997                                       | ELECTRIC STARTER |
| J60TTLEUA 1997                                       | IGNITION SYSTEM  |
| J60VLSID elec start, TNT, 20 in shaft, wht 2001      | ELECTRIC STARTER |
| J60VLSID elec start, TNT, 20 in shaft, wht 2001      | BATTERY CABLE    |
| J65WELEES 1999                                       | ELECTRIC STARTER |
| J65WELSIR Commercial, elec start, 20 in shaft 2001   | ELECTRIC STARTER |
| J65WELSSC Commercial, Elec. Start, 20 IN. shaft 2000 | ELECTRIC STARTER |
| J65WMLENE 1992                                       | ELECTRIC STARTER |
| J65WMLEOC 1995                                       | ELECTRIC STARTER |
| J65WMLERS 1994                                       | ELECTRIC STARTER |
| J65WMLETD 1993                                       | ELECTRIC STARTER |
| J70ELEND 1992                                        | ELECTRIC STARTER |
| J70ELEOR 1995                                        | BATTERY CABLE    |
| J70ELEOR 1995                                        | ELECTRIC STARTER |
| J70ELERC 1994                                        | BATTERY CABLES   |
| J70ELERC 1994                                        | ELECTRIC STARTER |
| J70ELERV 1994                                        | BATTERY CABLES   |
| J70ELERV 1994                                        | ELECTRIC STARTER |
| J70ELETS 1993                                        | BATTERY CABLES   |
| J70ELETS 1993                                        | ELECTRIC STARTER |
| J70JLEOS 1995                                        | BATTERY CABLE    |
| J70JLEOS 1995                                        | ELECTRIC STARTER |
| J70PLEEE 1999                                        | ELECTRIC STARTER |
| J70PLEEE 1999                                        | BATTERY CABLE    |
| J70PLSIS elec start, TNT, 20 in shaft 2001           | ELECTRIC STARTER |
| J70PLSIS elec start, TNT, 20 in shaft 2001           | BATTERY CABLE    |
| J70PLSSD Elec Start, TNT, 20 IN. shaft 2000          | ELECTRIC STARTER |
| J70PLSSD Elec Start, TNT, 20 IN. shaft 2000          | BATTERY CABLE    |

|                                              |                                                            |
|----------------------------------------------|------------------------------------------------------------|
| J70TLECB 1998                                | BATTERY CABLE                                              |
| J70TLECB 1998                                | ELECTRIC STARTER                                           |
| J70TLEDA 1996                                | BATTERY CABLE                                              |
| J70TLEDA 1996                                | ELECTRIC STARTER                                           |
| J70TLEND 1992                                | ELECTRIC STARTER                                           |
| J70TLEOR 1995                                | BATTERY CABLE                                              |
| J70TLEOR 1995                                | ELECTRIC STARTER                                           |
| J70TLERC 1994                                | BATTERY CABLES                                             |
| J70TLERC 1994                                | ELECTRIC STARTER                                           |
| J70TLERV 1994                                | BATTERY CABLES                                             |
| J70TLERV 1994                                | ELECTRIC STARTER                                           |
| J70TLETS 1993                                | BATTERY CABLES                                             |
| J70TLETS 1993                                | ELECTRIC STARTER                                           |
| J70TLEUM 1997                                | BATTERY CABLE                                              |
| J70TLEUM 1997                                | ELECTRIC STARTER                                           |
| J70TTLEND 1992                               | ELECTRIC STARTER                                           |
| J70TTLEOR 1995                               | ELECTRIC STARTER                                           |
| J70TTLEOR 1995                               | IGNITION SYSTEM                                            |
| J70TTLERC 1994                               | ELECTRIC STARTER                                           |
| J70TTLERC 1994                               | IGNITION SYSTEM                                            |
| J70TTLERV 1994                               | ELECTRIC STARTER                                           |
| J70TTLERV 1994                               | IGNITION SYSTEM                                            |
| J70TTLETS 1993                               | ELECTRIC STARTER                                           |
| J70TTLETS 1993                               | IGNITION SYSTEM                                            |
| J70VLSIS elec start, TNT, 20 in shaft 2001   | ELECTRIC STARTER                                           |
| J70VLSIS elec start, TNT, 20 in shaft 2001   | BATTERY CABLE                                              |
| RJ50ELSIF elec start, TNT, 20 in shaft 2001  | IGNITION SYSTEM - ELECTRIC START                           |
| RJ50ELSIF elec start, TNT, 20 in shaft 2001  | ELECTRIC STARTER & SOLENOID                                |
| RJ70PLSIS elec start, TNT, 20 in shaft 2001  | ELECTRIC STARTER                                           |
| RJ70PLSIS elec start, TNT, 20 in shaft 2001  | BATTERY CABLE                                              |
| RJ70PLSSD Elec Start, TNT, 20 IN. shaft 2000 | ELECTRIC STARTER                                           |
| RJ70PLSSD Elec Start, TNT, 20 IN. shaft 2000 | BATTERY CABLE                                              |
| SE50TLEDS 1996                               | ELECTRIC STARTER & SOLENOID                                |
| SE50TLEDS 1996                               | IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS |

|                |                                                            |
|----------------|------------------------------------------------------------|
| SE50TLEDS 1996 | IGNITION SYSTEM - ELECTRIC START 40TE MODELS               |
| SE65WMLD 1998  | ELECTRIC STARTER                                           |
| SE65WMLM 1996  | ELECTRIC STARTER                                           |
| SE65WMLZ2 1997 | ELECTRIC STARTER                                           |
| SE65WMYD 1998  | ELECTRIC STARTER                                           |
| SE65WMYM 1996  | ELECTRIC STARTER                                           |
| SE65WMYZ2 1997 | ELECTRIC STARTER                                           |
| SJ25TEEDA 1996 | ELECTRIC STARTER & SOLENOID                                |
| SJ25TEEUM 1997 | ELECTRIC STARTER & SOLENOID                                |
| SJ30EEDE 1996  | BATTERY CABLE                                              |
| SJ30EEDE 1996  | ELECTRIC STARTER & SOLENOID                                |
| SJ30TEEUD 1997 | ELECTRIC STARTER & SOLENOID                                |
| SJ40EEDS 1996  | ELECTRIC STARTER & SOLENOID                                |
| SJ40EEDS 1996  | IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS |
| SJ40EEDS 1996  | IGNITION SYSTEM - ELECTRIC START 40TE MODELS               |
| SJ40REDS 1996  | ELECTRIC STARTER & SOLENOID                                |
| SJ40REDS 1996  | IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS |
| SJ40REDS 1996  | IGNITION SYSTEM - ELECTRIC START 40TE MODELS               |
| SJ40RLEDS 1996 | ELECTRIC STARTER & SOLENOID                                |
| SJ40RLEDS 1996 | IGNITION SYSTEM - 40-50 ELECTRIC START EL, TL & TTL MODELS |
| SJ40RLEDS 1996 | IGNITION SYSTEM - ELECTRIC START 40TE MODELS               |
| SJ60TLEDR 1996 | BATTERY CABLE                                              |
| SJ60TLEDR 1996 | ELECTRIC STARTER                                           |
| SJ65WMLD 1998  | ELECTRIC STARTER                                           |
| SJ65WMLM 1996  | ELECTRIC STARTER                                           |
| SJ65WMLZ2 1997 | ELECTRIC STARTER                                           |
| SJ65WMYD 1998  | ELECTRIC STARTER                                           |
| SJ65WMYM 1996  | ELECTRIC STARTER                                           |
| SJ65WMYZ2 1997 | ELECTRIC STARTER                                           |
| SJ70TLEDA 1996 | BATTERY CABLE                                              |
| SJ70TLEDA 1996 | ELECTRIC STARTER                                           |
| TE25ELENS 1992 | ELECTRIC STARTER & SOLENOID                                |
| TE25ELETG 1993 | BATTERY CABLES                                             |
| TE25ELETG 1993 | ELECTRIC STARTER & SOLENOID                                |

|                 |                                                           |
|-----------------|-----------------------------------------------------------|
| TE40ELEIA 1991  | ELECTRIC STARTER & SOLENOID                               |
| TE40ELENJ 1992  | ELECTRIC STARTER & SOLENOID                               |
| TE40ELENJ 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| TE40ELENJ 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |
| TE40ELENJ 1992  | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |
| TE40ELENJ 1992  | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |
| TE40ELENM 1992  | ELECTRIC STARTER & SOLENOID                               |
| TE40ELENM 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| TE40ELENM 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |
| TE40ELENM 1992  | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |
| TE40ELENM 1992  | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |
| TE40ELETB 1993  | ELECTRIC STARTER & SOLENOID                               |
| TE40ELETB 1993  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS   |
| TE40ELETB 1993  | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS   |
| TE40ELETB 1993  | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY       |
| TE48ESLETE 1993 | BATTERY CABLES                                            |
| TE48ESLETE 1993 | ELECTRIC STARTER & SOLENOID                               |
| TE60TLENE 1992  | ELECTRIC STARTER                                          |
| TE60TLETD 1993  | BATTERY CABLES                                            |
| TE60TLETD 1993  | ELECTRIC STARTER                                          |
| TJ25ELEN 1992   | ELECTRIC STARTER & SOLENOID                               |
| TJ25ELET 1993   | BATTERY CABLES                                            |
| TJ25ELET 1993   | ELECTRIC STARTER & SOLENOID                               |
| TJ40ELEIA 1991  | ELECTRIC STARTER & SOLENOID                               |
| TJ40ELENJ 1992  | ELECTRIC STARTER & SOLENOID                               |
| TJ40ELENJ 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| TJ40ELENJ 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |
| TJ40ELENJ 1992  | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |

|                 |                                                           |
|-----------------|-----------------------------------------------------------|
| TJ40ELENJ 1992  | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |
| TJ40ELENM 1992  | ELECTRIC STARTER & SOLENOID                               |
| TJ40ELENM 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| TJ40ELENM 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |
| TJ40ELENM 1992  | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |
| TJ40ELENM 1992  | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |
| TJ40ELETB 1993  | ELECTRIC STARTER & SOLENOID                               |
| TJ40ELETB 1993  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS   |
| TJ40ELETB 1993  | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS   |
| TJ40ELETB 1993  | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY       |
| TJ48ESLETE 1993 | BATTERY CABLES                                            |
| TJ48ESLETE 1993 | ELECTRIC STARTER & SOLENOID                               |
| TJ60TLENE 1992  | ELECTRIC STARTER                                          |
| TJ60TLETD 1993  | BATTERY CABLES                                            |
| TJ60TLETD 1993  | ELECTRIC STARTER                                          |
| VE25ELENM 1992  | ELECTRIC STARTER & SOLENOID                               |
| VE25ELETB 1993  | BATTERY CABLES                                            |
| VE25ELETB 1993  | ELECTRIC STARTER & SOLENOID                               |
| VE30EENR 1992   | ELECTRIC STARTER & SOLENOID                               |
| VE30EETA 1993   | BATTERY CABLES                                            |
| VE30EETA 1993   | ELECTRIC STARTER & SOLENOID                               |
| VE30ELENR 1992  | ELECTRIC STARTER & SOLENOID                               |
| VE30ELETB 1993  | BATTERY CABLES                                            |
| VE30ELETB 1993  | ELECTRIC STARTER & SOLENOID                               |
| VE40EEIA 1991   | ELECTRIC STARTER & SOLENOID                               |
| VE40EENJ 1992   | ELECTRIC STARTER & SOLENOID                               |
| VE40EENJ 1992   | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| VE40EENJ 1992   | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |
| VE40EENJ 1992   | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |

|                |                                                           |
|----------------|-----------------------------------------------------------|
| VE40EENJ 1992  | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |
| VE40EENM 1992  | ELECTRIC STARTER & SOLENOID                               |
| VE40EENM 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| VE40EENM 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |
| VE40EENM 1992  | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |
| VE40EENM 1992  | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |
| VE40EETB 1993  | ELECTRIC STARTER & SOLENOID                               |
| VE40EETB 1993  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS   |
| VE40EETB 1993  | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS   |
| VE40EETB 1993  | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY       |
| VE40ELEIA 1991 | ELECTRIC STARTER & SOLENOID                               |
| VE40ELENJ 1992 | ELECTRIC STARTER & SOLENOID                               |
| VE40ELENJ 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| VE40ELENJ 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |
| VE40ELENJ 1992 | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |
| VE40ELENJ 1992 | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |
| VE40ELENM 1992 | ELECTRIC STARTER & SOLENOID                               |
| VE40ELENM 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| VE40ELENM 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |
| VE40ELENM 1992 | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |
| VE40ELENM 1992 | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |
| VE40ELETB 1993 | ELECTRIC STARTER & SOLENOID                               |
| VE40ELETB 1993 | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS   |
| VE40ELETB 1993 | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS   |
| VE40ELETB 1993 | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY       |



|                 |                                                           |
|-----------------|-----------------------------------------------------------|
| VE40TELEIA 1991 | ELECTRIC STARTER & SOLENOID                               |
| VE40TELENJ 1992 | ELECTRIC STARTER & SOLENOID                               |
| VE40TELENJ 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| VE40TELENJ 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |
| VE40TELENJ 1992 | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |
| VE40TELENJ 1992 | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |
| VE40TELENM 1992 | ELECTRIC STARTER & SOLENOID                               |
| VE40TELENM 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| VE40TELENM 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |
| VE40TELENM 1992 | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |
| VE40TELENM 1992 | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |
| VE40TELETB 1993 | ELECTRIC STARTER & SOLENOID                               |
| VE40TELETB 1993 | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS   |
| VE40TELETB 1993 | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS   |
| VE40TELETB 1993 | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY       |
| VE40TLEIA 1991  | ELECTRIC STARTER & SOLENOID                               |
| VE40TLENJ 1992  | ELECTRIC STARTER & SOLENOID                               |
| VE40TLENJ 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| VE40TLENJ 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |
| VE40TLENJ 1992  | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |
| VE40TLENJ 1992  | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |
| VE40TLENM 1992  | ELECTRIC STARTER & SOLENOID                               |
| VE40TLENM 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| VE40TLENM 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |
| VE40TLENM 1992  | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |
| VE40TLENM 1992  | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |

|                 |                                                           |
|-----------------|-----------------------------------------------------------|
| VE40TLETB 1993  | ELECTRIC STARTER & SOLENOID                               |
| VE40TLETB 1993  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS   |
| VE40TLETB 1993  | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS   |
| VE40TLETB 1993  | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY       |
| VE40TLETF 1993  | ELECTRIC STARTER & SOLENOID                               |
| VE40TLETF 1993  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS   |
| VE40TLETF 1993  | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS   |
| VE40TLETF 1993  | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY       |
| VE48ESLENB 1992 | ELECTRIC STARTER & SOLENOID                               |
| VE48ESLETE 1993 | BATTERY CABLES                                            |
| VE48ESLETE 1993 | ELECTRIC STARTER & SOLENOID                               |
| VE50BEEIA 1991  | ELECTRIC STARTER & SOLENOID                               |
| VE50BEENJ 1992  | ELECTRIC STARTER & SOLENOID                               |
| VE50BEENJ 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| VE50BEENJ 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |
| VE50BEENJ 1992  | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |
| VE50BEENJ 1992  | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |
| VE50BEENM 1992  | ELECTRIC STARTER & SOLENOID                               |
| VE50BEENM 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| VE50BEENM 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |
| VE50BEENM 1992  | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |
| VE50BEENM 1992  | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |
| VE50BEETB 1993  | ELECTRIC STARTER & SOLENOID                               |
| VE50BEETB 1993  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS   |
| VE50BEETB 1993  | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS   |
| VE50BEETB 1993  | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY       |

|                 |                                                           |
|-----------------|-----------------------------------------------------------|
| VE50BELEIA 1991 | ELECTRIC STARTER & SOLENOID                               |
| VE50BELENJ 1992 | ELECTRIC STARTER & SOLENOID                               |
| VE50BELENJ 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| VE50BELENJ 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |
| VE50BELENJ 1992 | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |
| VE50BELENJ 1992 | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |
| VE50BELENM 1992 | ELECTRIC STARTER & SOLENOID                               |
| VE50BELENM 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| VE50BELENM 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |
| VE50BELENM 1992 | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |
| VE50BELENM 1992 | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |
| VE50BELETB 1993 | ELECTRIC STARTER & SOLENOID                               |
| VE50BELETB 1993 | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS   |
| VE50BELETB 1993 | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS   |
| VE50BELETB 1993 | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY       |
| VE50TELENM 1992 | ELECTRIC STARTER & SOLENOID                               |
| VE50TELENM 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| VE50TELENM 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |
| VE50TELENM 1992 | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |
| VE50TELENM 1992 | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |
| VE50TLEIA 1991  | ELECTRIC STARTER & SOLENOID                               |
| VE50TLENJ 1992  | ELECTRIC STARTER & SOLENOID                               |
| VE50TLENJ 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| VE50TLENJ 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |
| VE50TLENJ 1992  | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |
| VE50TLENJ 1992  | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |

|                |                                                           |
|----------------|-----------------------------------------------------------|
| VE50TLENM 1992 | ELECTRIC STARTER & SOLENOID                               |
| VE50TLENM 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| VE50TLENM 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |
| VE50TLENM 1992 | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |
| VE50TLENM 1992 | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |
| VE50TLETB 1993 | ELECTRIC STARTER & SOLENOID                               |
| VE50TLETB 1993 | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS   |
| VE50TLETB 1993 | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS   |
| VE50TLETB 1993 | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY       |
| VE50TLETF 1993 | ELECTRIC STARTER & SOLENOID                               |
| VE50TLETF 1993 | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS   |
| VE50TLETF 1993 | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS   |
| VE50TLETF 1993 | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY       |
| VE60ELENE 1992 | ELECTRIC STARTER                                          |
| VE60ELETB 1993 | BATTERY CABLES                                            |
| VE60ELETB 1993 | ELECTRIC STARTER                                          |
| VE60TLENE 1992 | ELECTRIC STARTER                                          |
| VE70ELEND 1992 | ELECTRIC STARTER                                          |
| VE70ELETB 1993 | BATTERY CABLES                                            |
| VE70ELETB 1993 | ELECTRIC STARTER                                          |
| VE70TLEND 1992 | ELECTRIC STARTER                                          |
| VE70TLETB 1993 | BATTERY CABLES                                            |
| VE70TLETB 1993 | ELECTRIC STARTER                                          |
| VJ25ELENB 1992 | ELECTRIC STARTER & SOLENOID                               |
| VJ25ELETB 1993 | BATTERY CABLES                                            |
| VJ25ELETB 1993 | ELECTRIC STARTER & SOLENOID                               |
| VJ30EENR 1992  | ELECTRIC STARTER & SOLENOID                               |
| VJ30EETA 1993  | BATTERY CABLES                                            |
| VJ30EETA 1993  | ELECTRIC STARTER & SOLENOID                               |
| VJ30ELENR 1992 | ELECTRIC STARTER & SOLENOID                               |

|                |                                                           |
|----------------|-----------------------------------------------------------|
| VJ30ELETA 1993 | BATTERY CABLES                                            |
| VJ30ELETA 1993 | ELECTRIC STARTER & SOLENOID                               |
| VJ40EEIA 1991  | ELECTRIC STARTER & SOLENOID                               |
| VJ40EENJ 1992  | ELECTRIC STARTER & SOLENOID                               |
| VJ40EENJ 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| VJ40EENJ 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |
| VJ40EENJ 1992  | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |
| VJ40EENJ 1992  | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |
| VJ40EENM 1992  | ELECTRIC STARTER & SOLENOID                               |
| VJ40EENM 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| VJ40EENM 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |
| VJ40EENM 1992  | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |
| VJ40EENM 1992  | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |
| VJ40EETB 1993  | ELECTRIC STARTER & SOLENOID                               |
| VJ40EETB 1993  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS   |
| VJ40EETB 1993  | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS   |
| VJ40EETB 1993  | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY       |
| VJ40ELEIA 1991 | ELECTRIC STARTER & SOLENOID                               |
| VJ40ELENJ 1992 | ELECTRIC STARTER & SOLENOID                               |
| VJ40ELENJ 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| VJ40ELENJ 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |
| VJ40ELENJ 1992 | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |
| VJ40ELENJ 1992 | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |
| VJ40ELENM 1992 | ELECTRIC STARTER & SOLENOID                               |
| VJ40ELENM 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| VJ40ELENM 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |

|                 |                                                           |
|-----------------|-----------------------------------------------------------|
| VJ40ELENM 1992  | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |
| VJ40ELENM 1992  | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |
| VJ40ELETB 1993  | ELECTRIC STARTER & SOLENOID                               |
| VJ40ELETB 1993  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS   |
| VJ40ELETB 1993  | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS   |
| VJ40ELETB 1993  | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY       |
| VJ40TELEIA 1991 | ELECTRIC STARTER & SOLENOID                               |
| VJ40TELENJ 1992 | ELECTRIC STARTER & SOLENOID                               |
| VJ40TELENJ 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| VJ40TELENJ 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |
| VJ40TELENJ 1992 | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |
| VJ40TELENJ 1992 | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |
| VJ40TELENM 1992 | ELECTRIC STARTER & SOLENOID                               |
| VJ40TELENM 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| VJ40TELENM 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |
| VJ40TELENM 1992 | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |
| VJ40TELENM 1992 | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |
| VJ40TELETB 1993 | ELECTRIC STARTER & SOLENOID                               |
| VJ40TELETB 1993 | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS   |
| VJ40TELETB 1993 | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS   |
| VJ40TELETB 1993 | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY       |
| VJ40TLEIA 1991  | ELECTRIC STARTER & SOLENOID                               |
| VJ40TLENJ 1992  | ELECTRIC STARTER & SOLENOID                               |
| VJ40TLENJ 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| VJ40TLENJ 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |
| VJ40TLENJ 1992  | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |

|                 |                                                           |
|-----------------|-----------------------------------------------------------|
| VJ40TLENJ 1992  | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |
| VJ40TLENM 1992  | ELECTRIC STARTER & SOLENOID                               |
| VJ40TLENM 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| VJ40TLENM 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |
| VJ40TLENM 1992  | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |
| VJ40TLENM 1992  | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |
| VJ40TLETB 1993  | ELECTRIC STARTER & SOLENOID                               |
| VJ40TLETB 1993  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS   |
| VJ40TLETB 1993  | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS   |
| VJ40TLETB 1993  | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY       |
| VJ40TLETF 1993  | ELECTRIC STARTER & SOLENOID                               |
| VJ40TLETF 1993  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS   |
| VJ40TLETF 1993  | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS   |
| VJ40TLETF 1993  | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY       |
| VJ48ESLENB 1992 | ELECTRIC STARTER & SOLENOID                               |
| VJ48ESLETE 1993 | BATTERY CABLES                                            |
| VJ48ESLETE 1993 | ELECTRIC STARTER & SOLENOID                               |
| VJ50BEEIA 1991  | ELECTRIC STARTER & SOLENOID                               |
| VJ50BEENJ 1992  | ELECTRIC STARTER & SOLENOID                               |
| VJ50BEENJ 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| VJ50BEENJ 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |
| VJ50BEENJ 1992  | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |
| VJ50BEENJ 1992  | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |
| VJ50BEENM 1992  | ELECTRIC STARTER & SOLENOID                               |
| VJ50BEENM 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| VJ50BEENM 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |

|                 |                                                           |
|-----------------|-----------------------------------------------------------|
| VJ50BEENM 1992  | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |
| VJ50BEENM 1992  | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |
| VJ50BEETB 1993  | ELECTRIC STARTER & SOLENOID                               |
| VJ50BEETB 1993  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS   |
| VJ50BEETB 1993  | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS   |
| VJ50BEETB 1993  | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY       |
| VJ50BELEIA 1991 | ELECTRIC STARTER & SOLENOID                               |
| VJ50BELENJ 1992 | ELECTRIC STARTER & SOLENOID                               |
| VJ50BELENJ 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| VJ50BELENJ 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |
| VJ50BELENJ 1992 | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |
| VJ50BELENJ 1992 | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |
| VJ50BELENM 1992 | ELECTRIC STARTER & SOLENOID                               |
| VJ50BELENM 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| VJ50BELENM 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |
| VJ50BELENM 1992 | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |
| VJ50BELENM 1992 | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |
| VJ50BELETB 1993 | ELECTRIC STARTER & SOLENOID                               |
| VJ50BELETB 1993 | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS   |
| VJ50BELETB 1993 | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS   |
| VJ50BELETB 1993 | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY       |
| VJ50TELENM 1992 | ELECTRIC STARTER & SOLENOID                               |
| VJ50TELENM 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| VJ50TELENM 1992 | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |
| VJ50TELENM 1992 | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |



|                 |                                                           |
|-----------------|-----------------------------------------------------------|
| VJ50TELENM 1992 | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |
| VJ50TLEIA 1991  | ELECTRIC STARTER & SOLENOID                               |
| VJ50TLENJ 1992  | ELECTRIC STARTER & SOLENOID                               |
| VJ50TLENJ 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| VJ50TLENJ 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |
| VJ50TLENJ 1992  | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |
| VJ50TLENJ 1992  | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |
| VJ50TLENM 1992  | ELECTRIC STARTER & SOLENOID                               |
| VJ50TLENM 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX) |
| VJ50TLENM 1992  | IGNITION SYSTEM - ELECTRIC START & TL MODELS ("J" SUFFIX) |
| VJ50TLENM 1992  | IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX) |
| VJ50TLENM 1992  | IGNITION SYSTEM-ELECTRIC START TE-TTL MODELS ("J" SUFFIX) |
| VJ50TLETB 1993  | ELECTRIC STARTER & SOLENOID                               |
| VJ50TLETB 1993  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS   |
| VJ50TLETB 1993  | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS   |
| VJ50TLETB 1993  | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY       |
| VJ50TLETF 1993  | ELECTRIC STARTER & SOLENOID                               |
| VJ50TLETF 1993  | IGNITION SYSTEM - 40-50 ELECTRIC START EL AND TL MODELS   |
| VJ50TLETF 1993  | IGNITION SYSTEM - ELECTRIC START 40-50TE - 40TTL MODELS   |
| VJ50TLETF 1993  | IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY       |
| VJ60ELENE 1992  | ELECTRIC STARTER                                          |
| VJ60ELETD 1993  | BATTERY CABLES                                            |
| VJ60ELETD 1993  | ELECTRIC STARTER                                          |
| VJ60TLENE 1992  | ELECTRIC STARTER                                          |
| VJ70ELEND 1992  | ELECTRIC STARTER                                          |
| VJ70ELETS 1993  | BATTERY CABLES                                            |
| VJ70ELETS 1993  | ELECTRIC STARTER                                          |
| VJ70TLEND 1992  | ELECTRIC STARTER                                          |

VJ70TLETS 1993

VJ70TLETS 1993

X50ESLECC 1998

X50ESLECC 1998

BATTERY CABLES

ELECTRIC STARTER

ELECTRIC STARTER & SOLENOID

IGNITION SYSTEM -- 40-50 ELECTRIC START